EEAM008501

Operation & Maintenance Manual

PC160-6K
PC180LC-6K
PC180NLC-6K
PC200EN-6K
PC200EL-6K
HYDRAULIC EXCAVATOR

SERIAL NUMBERS	PC160-6K	- K30001	
	PC180LC-6K	- K30001	AND UP
	PC180NLC-6K	- K30001	
	PC200EN-6K	- K30001	
	PC200EL-6K	- K30001	

⚠ — WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept inside the cab for reference and periodically reviewed by all personel who will come into contact with the machine.

KOMATSU®

MidWestTech | Komatsu PC160-6K, PC180LC-6K, PC180NLC-6K, PC200EN-6K, PC200EL... Order the manual at mid-west-tech.com >

5. CONTENTS

1. Foreword 0-1

2. Safety information 0-2

3. Introduction 0-4

4. Location of plates, table to enter serial No. and distributor 0-5

SAFETY

6. General Precautions 1-2

7. Precautions during operation 1-8
   - 7.1 Before starting engine 1-8
   - 7.2 Operating machine 1-10
   - 7.3 Transportation 1-15
   - 7.4 Battery 1-16
   - 7.5 Towing 1-17
   - 7.6 Bucket with hook 1-18

8. Precautions for maintenance 1-21
   - 8.1 Before carrying out maintenance 1-21
   - 8.2 During maintenance 1-24

9. Position for attaching safety labels 1-28

OPERATION

10. General view
    - 10.1 General view of machine 2-2
    - 10.2 General view of controls and gauges 2-3

11. Explanation of components
    - 11.1 Machine monitor 2-4
    - 11.2 Switches 2-15
    - 11.3 Control levers, pedals 2-19
    - 11.4 Roof hatch 2-24
    - 11.5 Front window 2-25
    - 11.6 Door lock 2-27
    - 11.7 Cap, cover with lock 2-28
    - 11.8 Luggage box 2-29
    - 11.9 Ashtray 2-29
    - 11.10 Heater 2-29
    - 11.11 Air conditioner 2-30
    - 11.12 Car radio 2-33
    - 11.13 Fuse 2-34
    - 11.14 Fusible link 2-35
    - 11.15 Controllers 2-35
    - 11.16 Tool box 2-35
    - 11.17 Refuelling pump 2-35
    - 11.18 Handling the accumulator 2-36

MidWestTech | Komatsu PC160-6K, PC180LC-6K, PC180NLC-6K, PC200EN-6K, PC2... Order the manual at mid-west-tech.com >

12. Operation
12.1 Check before starting engine 2-38
12.2 Starting engine 2-48
12.3 Operations and checks after starting engine 2-51
12.4 Moving machine off 2-57
12.5 Steering machine 2-60
12.6 Stopping machine 2-62
12.7 Swinging 2-63
12.8 Operation of work equipment 2-64
12.9 Working mode selection 2-65
12.10 Prohibitions for operation 2-67
12.11 Precaution for operation 2-69
12.12 Precaution when travelling up or down hills 2-70
12.13 How to escape from mud 2-72
12.14 Work possible using hydraulic excavator 2-73
12.15 Replacement and inversion of bucket 2-74
12.16 Parking the machine 2-76
12.17 Check after finishing work 2-77
12.18 Stopping engine 2-78
12.19 Check after stopping engine 2-79
12.20 Locking 2-79
12.21 Overload warning device 2-79

13 Transportation
13.1 Loading, unloading work 2-80
13.2 Precautions for loading 2-82
13.3 Precautions for transportation 2-83
13.4 Lifting the machine 2-83

14. Cold weather operation
14.1 Precaution for low temperature 2-85
14.2 Precautions after completion of work 2-86
14.3 After cold weather 2-86

15. Long-term storage
15.1 Before storage 2-87
15.2 During storage 2-88
15.3 After storage 2-88
15.4 Starting machine after long-term storage 2-88

16. Troubleshooting
16.1 Phenomena that are not failures 2-89
16.2 Method of towing machine 2-89
16.3 Using method for light-weight towing hole 2-89
16.4 Precautions on particular jobsites 2-90
16.5 If battery is discharged 2-90
16.6 Other trouble 2-94

MidWestTech | Komatsu PC160-6K, PC180LC-6K, PC180NLC-6K, PC200EN-6K, PC2... Order the manual at mid-west-tech.com >

MAINTENANCE

17. Guides to maintenance 3-2

18. Outlines of service 3-5
18.1 Outline of oil, fuel, coolant 3-5
18.2 Outline of electric system 3-9
18.3 Outline of hydraulic system 3-10

19. Wear parts list 3-11

20. Use of fuel, coolant and lubricants according to ambient temperature 3-12

21. Standard tightening torques for bolts and nuts 3-16
21.1 Introduction of necessary tools 3-16
21.2 Torque list 3-17

22. Periodic replacement of safety critical parts 3-18

23. Maintenance schedule chart 3-20
23.1 Maintenance schedule chart 3-20
23.2 Maintenance interval when using hydraulic breaker 3-22

24. Service procedure 3-23
24.1 When required 3-24
24.2 Check before starting 3-45
24.3 Every 100 hours service 3-51
24.4 Every 250 hours service 3-54
24.5 Every 500 hours service 3-61
24.6 Every 1000 hours service 3-67
24.7 Every 2000 hours service 3-73
24.8 Every 4000 hours 3-79

SPECIFICATIONS

25. SPECIFICATIONS 4-2
25.1 Machine specifications 4-2
25.2 Explanation of lifting capacity chart 4-5

MidWestTech | Komatsu PC160-6K, PC180LC-6K, PC180NLC-6K, PC200EN-6K, PC2... Order the manual at mid-west-tech.com >