PART No. EM178 – EN1 – 7

OPERATOR'S MANUAL

EX1100

EXCAVATOR

Serial No. 01177 and up

HITACHI

MidWestTech | Hitachi EX1100 Excavator Operator's Manual | Publication EM178-EN1-7 Order the manual at mid-west-tech.com >

CONTENTS

SAFETY
- Recognize Safety Information ... 1
- Understand Signal Words ... 1
- Follow Safety Instructions ... 2
- Wear Protective Clothing ... 3
- Protect Against Noise ... 3
- Prepare for Emergencies ... 3
- Inspect Machine ... 4
- Use Handholds and Steps ... 4
- Adjust the Seat ... 4
- Fasten Your Seat Belt ... 5
- Operate Only from Operator's Seat ... 5
- Keep Riders Off Machine ... 5
- Avoid Power Lines ... 5
- Avoid Injury from Back-over and Swing Accidents ... 6
- Crane Operation is Prohibited ... 6
- Dig with Caution ... 7
- Move and Operate Machine Safely ... 7
- Operate Machine Safely ... 7
- Avoid Tipping ... 8
- Drive Machine Safely ... 8
- Beware of Exhaust Fumes ... 8
- Operate with Caution ... 9
- Avoid Injury from Runaway Accidents ... 9
- Park Machine Safely ... 10
- Handle Fluids Safely-Avoid Fires ... 10
- Practice Safe Maintenance ... 11
- Clean Trash from Machine ... 12
- Warn Others of Service Work ... 12
- Clean the Machine Regularly ... 12
- Store Attachments Safely ... 12
- Prevent Battery Explosions ... 13
- Avoid Harmful Asbestos Dust ... 13
- Protect Against Flying Debris ... 13
- Prevent Parts from Flying ... 14
- Stay Clear of Moving Parts ... 14
- Support Machine Properly ... 14
- Prevent Burns ... 15
- Remove Paint Before Welding or Heating ... 15
- Avoid Heating Near Pressurized Fluid Lines ... 16
- Avoid Applying Heat to Lines Containing Flammable Fluids ... 16
- Avoid High-Pressure Fluids ... 17
- Fire Prevention ... 18
- Replace Rubber Hoses Periodically ... 21
- Handle Chemical Products Safely ... 21
- Service the Air Conditioning System Safety ... 21
- Dispose of Waste Properly ... 22
- Handle Starting Fluid Safely ... 22

SAFETY SIGNS ... 23

OPERATIONAL SAFETY ... 27

GETTING ON / OFF THE MACHINE ... 29

EMERGENCY ROPE ... 30

EMERGENCY EVACUATION HAMMER ... 31

OPERATOR'S STATION
- Pedals and Levers ... 32
- Monitor Panels and Switch Panels ... 33
- Engine Speed Control Lever ... 34
- Gauges and Indicators on the Monitor Panel ... 35
- Clock ... 36
- Coolant Temperature Gauge ... 36
- Coolant Temperature (Overheat) Indicator ... 36
- Fuel Gauge ... 37
- Fuel Level Indicator ... 37
- Service Meter ... 37
- Alternator Indicator ... 37
- Engine Oil Pressure Indicator ... 38
- Auto-Lubrication Indicator ... 38
- Air Filter Restriction Indicator ... 38
- Pump Transmission Oil Pressure Indicator ... 38
- Head Light Indicator ... 39
- Engine Oil Level Indicator ... 39
- Coolant Level Indicator ... 39
- Hydraulic Oil Level Indicator ... 39
- Buzzer Stop Switch ... 40
- Wiper Switch ... 41
- Air Conditioner ... 42
- Operator's Seat Adjustment ... 47
- Seat Belt ... 49
- Cab Door Release Lever ... 51
- Doom Light ... 51
- Opening Cab Door Window ... 51
- Emergency Exit ... 52
- Extinguisher --- If equipped ... 52
- Hazard Warning Lamp --- Location ... 53

BREAK-IN
- Observe Machine Closely ... 54
- Every Ten Hours or Daily ... 54
- After the First 50 Hours ... 54

PRE-START INSPECTION
- Inspect Machine Daily Before Starting ... 55

OPERATING THE ENGINE
- Check Instruments Before Starting ... 56
- Check Oil and Coolant Level ... 56
- Starting the Engine ... 57
- Starting in Cold Weather ... 58

MidWestTech | Hitachi EX1100 Excavator Operator's Manual | Publication EM178-EN... Order the manual at mid-west-tech.com >

CONTENTS

Using Booster Batteries 59
Check Instruments after Starting 60
Stopping the Engine 60

DRIVING THE MACHINE
Drive Machine Carefully 61
Travel Speed Switch 61
Travel Alarm - - - If equipped 62
Steering the Machine Using Pedals 62
Steering the Machine Using Levers 63

OPERATING THE MACHINE
Horn 65
Control Lever 65
Bucket Open-Close Pedals 70
Control Lever Adjustment 70
Pilot Control Shut-Off Lever 71
Warming Machine 72
Warming Up Operation Procedure in Cold Weather 72
Auto-Idle Switch 73
Quick Idle Switch 73
Power Mode Selection Switch 74
Heavy Lift Button — If Equipped 75
Traveling 76
Raise One Track Using Boom and Arm 77
Operating On Soft Ground 77
Going Up / Down Hill 78
Avoid Tipping 78
Parking and Stopping On A Slope 79
Operating In Water or Mud 79
Backhoe Operation 80
Grading Operation 81
Avoid Abusive Operation 81
Operating Tips 82
Loading Shovel Operation 83
Prohibited Operations 84
Crane Operation is Prohibited 85
Towing a Short Distance 86
After Finishing Work 87

MAINTENANCE
Correct Maintenance and Inspection Procedure 89
Service Your Machine at Specified Intervals 90
Check the Service Meter Regularly 90
Use Correct Fuels and Lubricants 90
Prepare Machine for Maintenance 91
Open Access Doors for Service 91
Open Hood for Service 92
Use Electrical Outlet 92
Construction Outline 93
Backhoe Front Attachment 93
Loading Shovel Front Attachment 93
Hydraulic System (Loader) 94
Hydraulic System (Backhoe) 96
Air System 98
Electrical Circuit – Cab 99
Electrical Circuit – Body 101
Periodic Replacement of Rubber Hoses 103
Maintenance Interval Guide 106
A. Greasing 109
B. Engine Oil 117
C. Gear Oil 120
D. Hydraulic System 125
E. Fuel System 138
F. Air Cleaner 142
G. Cooling System 143
H. Air Conditioner 151
I. Electrical System 155
J. Miscellaneous 161
Maintenance Under Special Environmental Conditions 185

STORAGE
Storing the Machine 186
Removing the Machine from Storage 186

ASSEMBLY OF BUCKET
Mount The Backhoe Bucket 187

TRANSPORTING
Transporting Positions 188

TROUBLESHOOTING
Engine 190
Electrical System 192
Heater 192
Accelerator Lever 192
Control Levers 193
Hydraulic System 193
Mode Selection, Auto-Idle 196

SPECIFICATIONS
Specifications 197
Working Range (Backhoe) 198
Working Range (Loader) 199
Backhoe Shoe Types and Applications 200
Sound Level Results 201
Vibration Transmission to the Operator 201
Lifting Capacities 202

MACHINE NUMBERS 203

INDEX 206

MidWestTech | Hitachi EX1100 Excavator Operator's Manual | Publication EM178-EN... Order the manual at mid-west-tech.com >