PART No. EM17C – 5 – 1

Operator's Manual

EX750-5
EX800H-5
Excavator

Serial No.
EX750-5 005412 and up
EX800H-5 005412 and up

HITACHI

MidWestTech | Hitachi EX750-5, EX800H-5 Excavator Operator's Manual | Publication EM... Order the manual at mid-west-tech.com >

CONTENTS

MACHINE NUMBERS

SAFETY

Recognize Safety Information S-1
Understand Signal Words S-1
Follow Safety Instructions S-2
Prepare for Emergencies S-2
Wear Protective Clothing S-3
Protect Against Noise S-3
Inspect Machine S-3
Use Handholds and Steps S-4
Adjust the Operator's Seat S-4
Fasten Your Seat Belt S-5
Move and Operate Machine Safely S-5
Operate Only from Operator's Seat S-6
Jump Starting S-6
Keep Riders Off Machine S-6
Investigate Job Site Beforehand S-7
Protect Against Falling Stones and Debris S-7
Provide Signals for Jobs Involving Multiple Numbers of Machines S-8
Confirm Direction of Machine to be Driven S-8
Handle Starting Aids Safely S-8
Drive Machine Safely S-9
Avoid Injury from Rollaway Accidents S-10
Avoid Injury from Back-Over and Swing Accidents S-11
Keep Personnel Clear from Working Area S-12
Never Position Bucket Over Anyone S-12
Avoid Undercutting S-12
Avoid Tipping S-13
Never Undercut a High Bank S-13
Dig with Caution S-14
Operate with Caution S-14
Avoid Power Lines S-14
Object Handling S-15
Protect Against Flying Debris S-15
Park Machine Safely S-16
Handle Fluids Safely – Avoid Fires S-16
Safety Transporting S-17
Practice Safe Maintenance S-18
Warn Others of Service Work S-19
Support Machine Properly S-19
Stay Clear of Moving Parts S-19
Prevent Parts from Flying S-20
Store Attachments Safely S-20
Prevent Burns S-21
Replace Rubber Hoses Periodically S-21
Avoid High-Pressure Fluids S-22
Prevent Fires S-13
Evacuating in Case of Fire S-24
Beware of Exhaust Fumes S-24
Avoid Heating Near Pressurized Fluid Lines S-25
Avoid Applying Heat to Lines Containing Flammable Fluids S-25
Remove Paint Before Welding or Heating S-25
Prevent Battery Explosions S-26
Service Air Conditioning System Safely S-26
Handle Chemical Products Safely S-27
Dispose of Waste Properly S-27

SAFETY SIGNS S-28

COMPONENTS NAME 1-1

GETTING ON/OFF THE MACHINE 1-2

OPERATOR'S STATION

Cab Features 1-3
Front Right Panel and Right Console 1-4
Monitor Panel 1-5
- Coolant Temperature Gauge 1-5
- Warm Up Complete Indicator 1-5
- Fuel Gauge 1-6
- S/P Mode Indicator 1-6
- E Mode Indicator 1-6
- Auto-Idle Indicator 1-6
- Coolant Level Indicator (Warning) 1-7
- Hydraulic Oil Level Indicator 1-7
- Fuel Level Indicator 1-7
- Air Filter Restriction Indicator 1-7
- Work Light Indicator 1-8
- Quick Idle Indicator 1-8
- Auto-Lubrication Indicator 1-8
- Overheat Indicator 1-8
- Engine Oil Pressure Indicator 1-9
- Alternator Indicator 1-9
- Engine Oil Level Indicator 1-9
- Coolant Level Indicator 1-9

Switch Panel 1-10
- Level Check Switch 1-11
- Work Mode Switch (Backhoe) 1-11
- Buzzer and Buzzer Stop Switch 1-12
- Auto-Idle Switch 1-13
- Travel Mode Switch 1-13
- Wiper Switch 1-14
- Washer Switch 1-14
- Work Light Switch 1-15

Cab Light 1-15
Key Switch 1-16
Engine Control Dial 1-16
S/P Mode Switch 1-16
E Mode Switch 1-17
Horn Switch 1-17
Pilot Control Shut-Off Lever 1-18
Fuse Box 1-18
Hour Meter 1-19
Quick Idle Switch 1-20
Auto Air Conditioner 1-21
Left Console 1-28
Starting Aid Switch 1-28

MidWestTech | Hitachi EX750-5, EX800H-5 Excavator Operator's Manual | Publication EM... Order the manual at mid-west-tech.com >

CONTENTS

Travel Alarm Stop Switch 1-28
AM/FM Radio Operation 1-29
Digital Clock Setting Procedure 1-30
Cab Door Release Lever 1-31
Opening Upper Front Windows 1-31
Closing Upper Front Window 1-32
Removing and Storing Lower Front Window 1-32
Opening Side Window 1-33
Opening/Closing Overhead Window 1-34
Emergency Exit 1-35
Headguard-Integrated Cab 1-36
Emergency Exit (Headguard-Integrated Cab) 1-37
Adjusting the Seat 1-38
Seat Belt 1-40

BREAK-IN
Observe Engine Operation Closely 2-1

PRE-START INSPECTION
Inspect Machine Daily Before Starting 3-1

OPERATING THE ENGINE
Before Starting Engine 3-2
Level Check 3-3
Starting the Engine 3-4
Starting in Cold Weather 3-5
Check Instruments After Starting 3-6
Using Booster Batteries 3-7
Stopping the Engine 3-9

DRIVING THE MACHINE
Drive the Machine Carefully 4-1
Steering the Machine Using Pedals 4-2
Steering the Machine Using Levers 4-3
Travel Mode Switch 4-4
Travel Alarm 4-5
Traveling 4-6
Operating on Soft Ground 4-7
Raise One Track Using Boom and Arm 4-7
Towing Machine a Short Distance 4-8
Operating in Water or Mud 4-9
Precautions for Traveling on Slopes 4-10
Parking the Machine on Slopes 4-11
Parking the Machine 4-11

OPERATING THE MACHINE
Control Lever (HITACHI Pattern Backhoe) 5-1
Control Lever (ISO Pattern Backhoe) 5-2
Control Lever (HITACHI Pattern Loading Shovel) 5-3
Control Lever (ISO Pattern Loading Shovel) 5-4
Bucket Open-Close Pedals (Loading Shovel) 5-5
Pilot Control Shut-Off Lever 5-6
Warming-Up Operation 5-7
Warming-Up the Motor and the Cylinders 5-8
Auto-Idle 5-9
Quick-Idle 5-10
Engine Speed Control 5-11
Work Mode (Backhoe) 5-12
E (Economy) Mode 5-13
S/P (High Power) Mode 5-14
Precautions for Operations 5-15
Operate the Machine Safely 5-16
Operating Backhoe 5-17
Grading Operation 5-17
Avoid Abusive Operation 5-18
Operating Tips 5-19
Select Correct Track Shoes 5-19
Loading Shovel Operation 5-20
Prohibited Operation 5-20
Object Handling 5-23
Overnight Storage Instructions 5-24

ASSEMBLING TRANSPORTING
Precautions for Assembling 6-1
Precautions for Slinging Work 6-3
Precautions for Operating Machine 6-4
Installing Counterweight 6-5
Installing Boom Cylinder (Backhoe) 6-6
Installing Boom (Backhoe) 6-8
Connecting Hoses Between Boom Cylinder and Machine (Backhoe) 6-9
Installing Boom Cylinder Rod (Backhoe) 6-10
Installing Arm (Backhoe) 6-11
Connecting Arm Cylinder Rod (Backhoe) 6-12
Connecting Bucket Cylinder Hoses (Backhoe) 6-13
Installing Bucket (Backhoe) 6-14
Connecting Pipings (Loading Shovel) 6-15
Installing Loading Shovel Front 6-16
Removing Stopper and Wire (Loading Shovel) 6-17
Connecting Hoses Between Boom and Machine (Loading Shovel) 6-17
Installing Boom Cylinder (Loading Shovel) 6-18
Bleeding Air From Arm and Bucket Cylinders (Loading Shovel) 6-20
Installing Loading Shovel Bucket 6-21
Connecting Dump Cylinder Hose (Loading Shovel) 6-22
Extending the Side Frame 6-23
Final Inspection 6-26
Transporting by Road 6-27
Transporting the Machine by Trailer 6-27
Loading/Unloading on a Trailer 6-27
Types of Packing for Transportation 6-29
Packing Dimensions and Weights for Transportation 6-30
Retracting or Extending the Side Frame 6-45
Retracting the Side Frame 6-46
Extending the Side Frame 6-47

MidWestTech | Hitachi EX750-5, EX800H-5 Excavator Operator's Manual | Publication EM... Order the manual at mid-west-tech.com >

CONTENTS

MAINTENANCE

Correct Maintenance and Inspection Procedures 7-1
Check the Hour Meter Regularly 7-2
Use Correct Fuels and Lubricants 7-2
Prepare Machine for Maintenance 7-3
Hood and Access Covers 7-4
Periodic Replacement of Parts 7-5
Maintenance Guide 7-6
A. Greasing 7-9
Front Joint Pins 7-10
Swing Bearing 7-15
Lubricator 7-16
Swing Internal Gear 7-18
B. Engine Oil 7-19
Engine Oil Level 7-20
Change Engine Oil 7-20
Replace Engine Oil Filters 7-20
C. Oil 7-22
Pump Transmission 7-23
Swing Reduction Gear 7-25
Travel Reduction Gear 7-27
D. Hydraulic System 7-29
Inspection and Maintenance of Hydraulic Equipment 7-30
Check Hydraulic Oil Level 7-32
Drain Hydraulic Oil Tank Sump 7-34
Change Hydraulic Oil 7-35
Suction Filter Cleaning 7-35
Replace Hydraulic Oil Tank Filter 7-38
Replace Pump Drain Filter 7-39
Replace Pilot Oil Filter 7-40
Check Hoses and Lines 7-42
E. Fuel System 7-47
Refueling 7-47
Drain Fuel Tank Sump 7-49
Drain Fuel Filter Sediment 7-49
Replace Fuel Filter 7-50
Check Fuel Hoses 7-51
F. Air Cleaner 7-52
Clean Air Cleaner Outer Element 7-52
Replace Air Cleaner Outer and Inner Elements 7-52
G. Cooling System 7-54
Check Coolant Level 7-56
Check Fan Belt for Wear 7-56
Check DCA4 Concentration in Coolant 7-57
Replace Coolant Filter 7-63
Change Coolant 7-64
Clean Radiator and Oil Cooler Core 7-65
Clean Oil Cooler Front Screen 7-65
H. Air Conditioner 7-66
Clean and Replace Air Conditioner Filter 7-66
Check Refrigerant (Gas) Quantity 7-68
Check Compressor Belt Tension 7-68
Clean Condenser Core 7-69
Check Looseness at Each of Fastened Areas 7-69
Check In-Season and Off-Season 7-70
I. Electrical System 7-71
Batteries 7-71
Replace Batteries 7-74
Replacing Fuses 7-74
Connecting Batteries 7-75
J Miscellaneous 7-76
Check Bucket Teeth 7-77
Adjust Bucket Linkage 7-83
Check and Replace Seat Belt 7-84
Check Windshield Washer Fluid Level 7-84
Check Track Sag 7-85
Adjust Track Sag 7-85
Loosen the Track 7-86
Tighten the Track 7-86
Check Tightening Torque of Bolts and Nuts 7-91

Maintenance Under Special Environmental Conditions 9-1

STORAGE

Storing the Machine 10-1
Removing the Machine from Storage 10-2
Installing Vandal-Proof Covers 10-3
Help Prevent Crime 10-4
Record Identification Numbers 10-4
Keep Proof of Ownership 10-4
Park Indoors out of sight 10-4
When Parking Outdoors 10-5
Reduce Vandalism 10-5
Report Thefts Immediately 10-5

TROUBLESHOOTING

Engine 11-1
Electrical System 11-6
Mode Selection 11-8
Control Levers 11-9
Hydraulic System 11-9
Pump Control System 11-12

SPECIFICATIONS

Specifications (Backhoe) 12-1
Working Ranges (Backhoe) 12-3
Shoe Types and Applications 12-4
Bucket Types and Applications (Backhoe) 12-5
Specifications (Loading Shovel) 12-6
Working Ranges (Loading Shovel) 12-8
Bucket Types and Applications (Loading Shovel) 12-9

MidWestTech | Hitachi EX750-5, EX800H-5 Excavator Operator's Manual | Publication EM... Order the manual at mid-west-tech.com >