PART No. EM17F –EN 1 – 1

Operator's Manual

EX1200-5 Excavator

Serial No. 001001 and up

HITACHI

MidWestTech | Hitachi EX1200-5 Excavator Operator's Manual | Publication EM17F-EN1-1 Order the manual at mid-west-tech.com >

CONTENTS

MACHINE NUMBERS

SAFETY

Recognize Safety Information S-1
Understand Signal Words S-1
Follow Safety Instructions S-2
Prepare for Emergencies S-2
Wear Protective Clothing S-3
Protect Against Noise S-3
Inspect Machine S-3
General Precautions for Cab S-4
Use Handholds and Steps S-5
Adjust the Operator's Seat S-5
Fasten Your Seat Belt S-6
Move and Operate Machine Safely S-6
Operate Only from Operator's Seat S-7
Jump Starting S-7
Keep Riders Off Machine S-7
Investigate Job Site Beforehand S-8
Protect Against Falling Stones and Debris S-8
Provide Signals for Jobs Involving Multiple Numbers of Machines S-9
Confirm Direction of Machine to be Driven S-9
Drive Machine Safely S-10
Avoid Injury from Rollaway Accidents S-11
Avoid Injury from Back-Over and Swing Accidents S-12
Keep Person Clear from Working Area S-13
Never Position Bucket Over Anyone S-13
Avoid Undercutting S-13
Avoid Tipping S-14
Never Undercut a High Bank S-14
Dig with Caution S-15
Operate with Caution S-15
Avoid Power Lines S-15
Crane Operation is Prohibited S-16
Protect Against Flying Debris S-16
Park Machine Safely S-17
Handle Fluids Safely – Avoid Fires S-17
Practice Safe Maintenance S-18
Warn Others of Service Work S-19
Support Machine Properly S-19
Stay Clear of Moving Parts S-19
Prevent Parts from Flying S-20
Store Attachments Safely S-20
Prevent Burns S-21
Replace Rubber Hoses Periodically S-21
Avoid High-Pressure Fluids S-22
Prevent Fires S-23
Evacuating in Case of Fire S-24
Beware of Exhaust Fumes S-24
Precautions for Welding and Grinding S-25
Avoid Heating Near Pressurized Fluid Lines S-26
Avoid Applying Heat to Lines Containing Flammable Fluids S-26
Remove Paint Before Welding or Heating S-26
Prevent Battery Explosions S-27
Service Air Conditioning System Safely S-27
Handle Chemical Products Safely S-28
Dispose of Waste Properly S-28

SAFETY SIGNS S-29

COMPONENTS NAME 1-1

GETTING ON/OFF THE MACHINE 1-2

OPERATOR'S STATION

Emergency Rope (Elevated Cab) 1-3
Cab Features 1-4
Monitor Panel 1-5
- Coolant Temperature Gauge 1-5
- Fuel Gauge 1-6
- Fuel Level Indicator 1-6
- Alternator Indicator 1-6
- Engine Exhaust Temperature Indicator 1-6
- Hydraulic Oil Level Indicator 1-7
- Engine Warning Indicator 1-7
- Coolant Level Indicator 1-7
- Engine Stop Indicator 1-8
- Auto-Lubrication Indicator 1-8
- Engine Oil Level Indicator (Warning) 1-8
- Pump Transmission Oil Pressure Indicator (Warning) 1-8
- Engine Oil Pressure Indicator 1-9
- Preheat Indicator 1-9
- Download Indicator 1-9
- Overheat Indicator 1-10
- Air Filter Restriction Indicator 1-10
- Lubrication Mode Indicator 1-10
- Display 1-11
- Auto-Idle Indicator 1-11
- Quick Idle Indicator 1-11

Switch Panel 1 1-12
- Display Selection Switch 1-12
- Hour Meter 1-12
- Trip Meter 1 And Trip Meter 2 1-13
- User's Mode 1-13
- Set Switch 1-14
- Lubrication Mode Switch 1-15

Switch Panel 2 1-16
- Engine Control Dial 1-16
- Auto-Idle Switch 1-17
- Power Mode Switch 1-17
- Travel Mode Switch 1-18
- Work Light Switch 1-19
- Wiper/Washer Switch 1-20
- Right Console 1-21
- Key Switch 1-21
- ALU Timer Switch (Auto-Lubrication Timer Switch) 1-21
- Heavy Lift Switch 1-22

MidWestTech | Hitachi EX1200-5 Excavator Operator's Manual | Publication EM17F-E... Order the manual at mid-west-tech.com >

CONTENTS

Boom Mode Switch 1-22
Auto Air Conditioner 1-23
Cab Heater Operation 1-27
Cooling Operation 1-27
Defroster Operation 1-28
Tips for Optimal Air Conditioner Usage 1-29
Left Console 1-31
Preheat Switch 1-31
Step Light Switch 1-32
AM/FM Radio Operation 1-33
Digital Clock Setting Procedure 1-34
Rear Console 1-35
Engine Diagnostic Switch 1-35
Buzzer and Buzzer Stop Switch 1-36
Travel Alarm Stop Switch (Optional) 1-36
Quick Idle Switch 1-37
Download Indicator 1-37
Horn Switch 1-37
Pilot Control Shut-Off Lever 1-38
Cab Light 1-38
Fuse Box (Left) 1-39
Fuse Box (Right) 1-39
Cab Door Release Lever 1-40
Opening Cab Door Window 1-40
Hazard Warning Lamp 1-40
Extinguisher --- If Equipped 1-40
Emergency Exit 1-41
Emergency Exit (Elevated Cab) 1-42
Operator's Seat Adjustment 1-44
Seat Belt 1-46

BREAK-IN

Observe Engine Operation Closely 2-1
Every 10 Hours or Daily 2-1
After the First 50 Hours 2-1

OPERATING THE ENGINE

Inspect Machine Daily Before Starting 3-1
Before Starting Engine 3-2
Level Check 3-3
Starting the Engine 3-4
Starting in Cold Weather 3-5
Check Instruments After Starting 3-7
Using Booster Batteries 3-8
Stopping the Engine 3-10

DRIVING THE MACHINE

Drive the Machine Carefully 4-1
Steering the Machine Using Pedals 4-2
Steering the Machine Using Levers 4-3
Travel Mode Switch 4-4
Travel Alarm (Optional) 4-4
Traveling 4-5
Operating on Soft Ground 4-6
Raise One Track Using Boom and Arm 4-6
Towing Machine a Short Distance 4-7
Operating in Water or Mud 4-8
Precautions for Traveling on Slopes 4-9
Parking the Machine on Slopes 4-10
Parking the Machine 4-10

OPERATING THE MACHINE

Control Lever (ISO Pattern Backhoe) 5-1
Control Lever (ISO Pattern Loading Shovel) 5-2
Control Lever (HITACHI Pattern Backhoe) 5-3
Control Lever (HITACHI Pattern Loading Shovel) 5-4
Bucket Open-Close Pedals (Loading Shovel) 5-5
Pilot Control Shut-Off Lever 5-6
Auto-Idle 5-8
Quick Idle 5-9
Engine Speed Control 5-10
Power Mode 5-11
E (Economy) Mode 5-12
P (Power) Mode 5-13
S/P (Super Power) Mode 5-14
Heavy Lift 5-15
Precautions for Operations 5-16
Operate the Machine Safely 5-17
Operating Backhoe 5-18
Grading Operation 5-18
Avoid Abusive Operation 5-19
Operating Tips 5-20
Select Correct Track Shoes 5-20
Loading Shovel Operation 5-21
Prohibited Operation 5-21
Crane Operation is Prohibited 5-24
Overnight Storage Instructions 5-25

TRANSPORTING

Packing Dimensions and Weights for Transportation 6-1

MAINTENANCE

Correct Maintenance and Inspection Procedures 7-1
Check the Hour Meter Regularly 7-2
Use Correct Fuels and Lubricants 7-2
Prepare Machine for Maintenance 7-3
Hood and Access Covers 7-4
Use Electrical Outlet 7-4
Construction Outline 7-6
Hydraulic System 7-7
Loading Shovel 7-8
Backhoe 7-10
Electrical Circuit Diagram 7-11
Periodic Replacement of Parts 7-13
Maintenance Interval Guide 7-16
A. Greasing 7-19
Front Joint Pins 7-20
Swing Bearing 7-24
Swing Internal Gear 7-27

MidWestTech | Hitachi EX1200-5 Excavator Operator's Manual | Publication EM17F-E... Order the manual at mid-west-tech.com >

CONTENTS

B. Engine 7-28
Engine Oil Level 7-30
Change Engine Oil 7-30
Replace Engine Oil Main Filters 7-30
Replace Engine Oil Bypass Filter 7-30
Check Injection Nozzle 7-32
Inspect Bolts and Nuts Outside Engine 7-32
Inspect and Adjust Valve Clearance 7-32
Check Fuel Injection Timing 7-32
Check Starter and Alternator 7-32
Check Turbocharger 7-32
C. Transmission 7-33
Pump Transmission 7-34
Swing Reduction Gear 7-37
Travel Reduction Gear 7-39
D. Hydraulic System 7-41
Inspection and Maintenance of Hydraulic Equipment 7-42
Check Hydraulic Oil Level 7-44
Drain Hydraulic Tank Sump 7-45
Change Hydraulic Oil 7-46
Suction Filter Cleaning 7-49
Replace Drain Filter Element 7-50
Replace Full-Flow Filter 7-52
Replace Pilot Oil Filter Element 7-54
Check Hoses and Lines 7-56
Service Recommendations for Hydraulic Fittings 7-59
E. Fuel System 7-62
Drain Fuel Tank Sump 7-64
Drain Water Separator Filter Sediment 7-65
Replace Water Separator Filter 7-66
Replace Fuel Filter 7-67
Check Fuel Hoses 7-69
F. Air Cleaner 7-71
Clean the Air Cleaner Outer Element 7-71
Replace the Air Cleaner Outer and Inner Elements 7-71
G. Cooling System 7-73
Check Coolant Level 7-75
Check Fan Belt for Wear 7-76
Change Coolant 7-77
Clean Radiator Core and Oil Cooler Core 7-79
Clean Inter Cooler Front Screen 7-79
H. Air Conditioner 7-80
Ventilation Air Filter 7-80
Recirculation Air Filter 7-81
Check Refrigerant Quantity 7-82
Check Compressor Belt Tension 7-83
Clean Condenser Core 7-83
Check Tightening Torque 7-84
Seasonal Maintenance 7-85
I. Electrical System 7-86
Replace Batteries 7-89
Replacing Fuses 7-90
J. Miscellaneous 7-95
Check Bucket Teeth 7-96
Change Bucket (Buckhoe) 7-101
Check and Replace Seat Belt 7-102
Check Windshield Washer Fluid Level 7-102
Check Track Sag 7-103
Auto-Lubrication System 7-104
Check Tightening Torque of Bolts and Nuts 7-108

MAINTENANCE UNDER SPECIAL ENVIRONMENTAL CONDITIONS

Maintenance Under Special Environmental Conditions 9-1

STORAGE

Storing the Machine 10-1
Removing the Machine from Storage 10-2

TROUBLESHOOTING

Engine 11-1
Electrical System 11-6
Mode Selection 11-8
Control Levers 11-9
Hydraulic System 11-9

SPECIFICATIONS

Specifications 12-1
Working Range (Backhoe) 12-3
Working Range (BE Backhoe) 12-4
Working Range (Loading Shovel) 12-5
Backhoe Shoe Types and Applications 12-6


INDEX 14-1

MidWestTech | Hitachi EX1200-5 Excavator Operator's Manual | Publication EM17F-E... Order the manual at mid-west-tech.com >

Attach to Vol. No. : TT183E-00

EX1200-5 ELECTLICAL CIRCUIT DIAGRAM

Authorized Hitachi Dealer Use Only
Parts numbers on the drawing are provided only for reference purpose.
To order parts on drawing, be sure to consult the Parts Catalog.



MidWestTech | Hitachi EX1200-5 Excavator Operator's Manual | Publication EM17F-EN1-1

Order the manual at mid-west-tech.com >