EX1800-2 EXCAVATOR

OPERATOR'S MANUAL

Serial No. 0201 and up

HITACHI

MidWestTech | Hitachi EX1800-2 Excavator Operator's Manual | Publication EM182-2-5 Order the manual at mid-west-tech.com >

CONTENTS

Safety 1

Safety Signs 23

Handling Ladder / Emergency Rope 27

Operator's Station
Pedals and Levers 29
Monitor Panels and Switch Panels 30
Indicator Light Check Switch, Buzzer Stop Switch
Level Check Switch 39
Operating Wiper and Washer, Hour Meter,
Light Switches 40
Air Conditioner 42
Adjusting the Seat, Seat Belt 48

Break-In 51

Pre-Start Inspection 52

Operating the Engine
Check Instrument before Starting 53
Starting the Engine 54
Starting in cold weather 55
Using Booster Batteries 56
Check Instrument after Starting,
Stopping the Engine 57
Emergency Engine Stop Switch, Engine stop
Switches 58

Driving the Machine
Drive Machine Carefully, Travel Speed
Select / Pilot Control Shut-off Lever 59
Travel Alarm, Steering the Machine Using Pedals,
Steering the Machine Using Levers 60

Operating the Machine
Horn, Control Lever 62
Bucket Open-Close, Arm Retraction 67
Warming Machine 68
Auto-Idle Switch 69
Power Mode Selection Switch 70
Traveling 71
Craning 76
Backhoe Operation 77
Loading Shovel Operation 80

Maintenance
Correct Maintenance and Inspection
Procedure 85
Periodic Replacement of Rubber Hoses 96
Maintenance Interval Guide 101
A. Greasing 105
B. Engine Oil 113
C. Gear Oil 117
D. Hydraulic System 124
E. Fuel System 141
F. Air Cleaner 146
G. Air System 148
H. Cooling System 151
I. Air Conditioner 158
J. Electrical System 163
K. Miscellaneous
Check Seat Belt 169
Inspect Emergency Rope and
Rope Mounting Hardware 170
Auto-Lubrication System (Option) 170
Check Bucket Teeth 173
Check and Adjust Track Sag 175
Check Accumulator and
Track Adjuster Cylinder Circuit 177
Clean Side Frame 177
Check Tightening Torque of Bolts
and Nuts 178

Maintenance Under Special Environmental
Conditions 189

Storage 190

Troubleshooting
Engine 191
Electrical System 195
Control Levers 197
Hydraulic System 198
Mode Selection, Auto-Idle 201

Specifications 202

Machine Numbers 209

MidWestTech | Hitachi EX1800-2 Excavator Operator's Manual | Publication EM182-2-5 Order the manual at mid-west-tech.com >