PART No. EM184 – 1 – 4

OPERATOR'S MANUAL

EX2500

HYDRAULIC EXCAVATOR

Serial No. 0105 and up

HITACHI

MidWestTech | Hitachi EX2500 Excavator Operator's Manual | Publication EM184-1- 4

Order the manual at mid-west-tech.com >

CONTENTS

SAFETY

Recognize Safety Information S1
Understand Signal Words S1
Follow Safety Instructions S2
Prepare for Emergencies S2
Wear Protective Clothing S3
Protect Against Noise S3
Inspect Machine S3
Use Handholds and Steps S4
Adjust the Operator's Seat S4
Fasten Your Seat Belt S5
Move and Operate Machine Safely S5
Operate only from Operator's Seat S6
Handle Starting Aids Safely S6
Jump Starting S7
Keep Riders Off Machine S7
Investigate Job Site Beforehand S8
Protect Against Falling Stones and Debris S8
Provide Signals for Jobs Involving Multiple Numbers of Machines S9
Confirm Direction of Machine to be Driven S9
Drive Machine Safely S10
Avoid Injury from Rollaway Accidents S11
Avoid Injury from Back-Over and Swing Accidents S12
Keep Personnel Clear from Working Area S13
Never Position Bucket Over Anyone S13
Avoid Undercutting S13
Avoid Tipping S14
Never Undercut a High Bank S14
Dig with Caution S15
Operate with Caution S15
Avoid Power Lines S15
Object Handling S16
Protect Against Flying Debris S16
Park Machine Safely S17
Handle Fluids Safely-Avoid Fires S17
Practice Safe Maintenance S18
Warn Others of Service Work S19
Support Machine Properly S19
Stay Clear of Moving Parts S19
Prevent Parts from Flying S20
Store Attachments Safely S20
Prevent Burns S21
Replace Rubber Hoses Periodically S21
Avoid High-Pressure Fluids S22
Prevent Fires S23
Evacuating in Case of Fire S24
Beware of Exhaust Fumes S25
Avoid Heating Near Pressurized Fluid Lines S25
Avoid Applying Heat to Lines Containing Flammable Fluids S25
Remove Paint before Welding or Heating S26
Prevent Battery Explosions S26
Service Air Conditioning System Safely S27
Avoid Harmful Asbestos Dust S27
Handle Chemical Products Safely S28
Dispose of Waste Properly S28

SAFETY SIGNS S29

COMPONENTS NAME 1

HANDLING LADDER/EMERGENCY ROPE

Using Ladder 2
Operating Ladder on the Ground 3
Operating Ladder on the Upperstructure 3
Emergency Rope 4
Emergency Exit 4
Evacuating in Case of Fire 5

OPERATOR'S STATION

Cab Features 7
Monitor Panel and Switch Panels (Left) 8
Monitor Panel 9
Fuel Gauge 10
Hydraulic Oil Temperature Gauge 10
Coolant Temperature Gauge 10
Tachometer 10
Alternator Indicator 11
Pump Transmission Oil Pressure Indicator (Warning) 11
Engine Oil Pressure Indicator (Warning) ... 11
Overheat Indicator (Warning) 11
Hydraulic Oil Level Indicator (Warning) 12
Fuel Level Indicator 12
Engine Oil Level Indicator 12
Coolant Level Indicator 12
Hydraulic Oil Level Indicator 13
Travel Mode Indicator (Slow Speed) 13
Auto-Idle Indicator 13
Engine Room Light Indicator 13
Entrance Light Indicator 14
Prelub Indicator 14
Travel Mode Indicator (Fast Speed) 14
Coolant Level Indicator (Warning) 14
Auto-Lubrication Indicator 15
Engine Controller Indicator 15
Air Cleaner Restriction Indicator 15
Pump Contamination Indicator 15
Engine Stop Indicator 16
Stop Valve Indicator (Warning) 16
Ladder Position Indicator 16
CENTRY™ Diag. Test Indicator 16

Order the manual at mid-west-tech.com >

CONTENTS

Switch Panel 17
Wiper Switch 18
Wiper Delay Selector Switch 18
Washer Switch 18
Air Conditioners 19
Cooling 21
Heating 21
Dehumidifying and Heating 21
Defrosting 22
Blower Operation without Cooling or Heating 22
Ventilating the Cab 22
Indicator Light Check Switch 23
Level Check Switch 23
Buzzer Stop Switch 24
Dimmer Switch 24
Engine Speed Control Lever 25
Work Light Switch 26
Dome Light Switch 27
Engine Room Light Switch 28
Entrance Light Switch 29
Travel Speed Switch 30
Auto-Idle Switch 30
Ether Switch (Starting Aid Switch) 31
CENTRY™ Diag. Test Switch 31
Switch Panel (Right) 32
Emergency Engine Stop Switch 32
Key Switch 32
Hour Meter 33
Horn Switch 33
AM/FM Radio Operation 34
Digital Clock Setting Procedure 35
Operator's Seat Adjustment 36
Seat Belt 38
Cab Door Release Button 39
Opening Cab Left Window 39

BREAK-IN

Observe Machine Closely 40

PRE-START INSPECTION

Inspect Machine Daily Before Starting 41

OPERATING THE ENGINE

Check Instruments before Starting 42
Level Check 43
Starting the Engine 44
Starting in Cold Weather 45
Check Instruments after Starting 46
Using Booster Batteries 47
Stopping the Engine 48
Emergency Engine Stop Switch 49

DRIVING THE MACHINE

Drive Machine Carefully 50
Steering the Machine Using Pedals 51
Steering the Machine Using Levers 52
Travel Speed Switch 53
Travel Alarm 53

OPERATING THE MACHINE

Control Lever (ISO Pattern) 54
Conrol Lever (HITACHI Pattern) 56
Bucket Open-Close Pedals (Loading Shovel) 58
Pilot Control Shut-Off Lever 59
Warming Machine 60
Auto-Idle Switch 61
Traveling 62
Operating on Soft Ground 63
Raise One Track Using Boom and Arm 63
Going Up or Down Hill 64
Avoid Tipping 64
Parking and Stopping on a Slope 65
Operating in Water or Mud 65
Avoid Swinging Bucket to Move Objects 66
Precautions for Operations 67
Operate the Machine Safely 68
Backhoe Operation 69
Grading Operation 70
Avoid Abusive Operation 70
Operating Tips 71
Loading Shovel Operation 72
Prohibited Operations 72
Towing Machine a Short Distance 75
Object Handling 76
Parking the Machine 77
Lock All Compartments 77
After Finishing Work 78

MAINTENANCE

Correct Maintenance and Inspection Procedures 79
Service Your Machine at Specified Intervals 80
Check the Hour Meter Regularly 80
Use Correct Fuels and Lubricants 80
Prepare Machine for Maintenance 81
Open Access Doors for Service 82
Inspection/Maintenance Lights 83
Use a Chain to Prevent Falling Accidents 84
Construction Outline 85
Hydraulic System (Loading Shovel) 86
Hydraulic System(Backhoe Shovel) 88
Periodic Replacement of Rubber Hoses 90
Maintenance Interval Guide 92
A. Greasing 96
Loader Front Joint Pins 97
Backhoe Front Joint Pins 100

Order the manual at mid-west-tech.com >

CONTENTS

Swing Bearing 101
Swing Internal Gear 102
Center Joint 103
Operating the Lubricator 104
B. Engine 106
Engine Oil Level 107
Change Engine Oil 108
Replace Engine Oil Main and Bypass Filters 108
C. Transmission 110
Pump Transmission 111
Swing Reduction Gear 114
Travel Reduction Gear 116
Oil Cooler Fan Drive 118
D. Hydraulic System 121
Inspection and Maintenance of Hydraulic Equipment 122
Check Hydraulic Oil Level 124
Drain Hydraulic Oil Tank Sump 126
Replace Full-Flow Filter and Drain Filter ... 128
Replace Bypass Filter 130
Replace Pilot Oil Filter 132
Change Hydraulic Oil 134
Suction Filter Cleaning 134
Replace Suction Filter 137
Replace High-Pressure Strainer 138
Clean Oil Cooler Front Screen 139
Check Hoses and Lines 140
E. Fuel System 143
Refueling 143
Drain Fuel Tank Sump 145
Drain Fuel Filter Sediment 146
Replace Fuel Filter 147
Clean Fuel Tank Strainer 148
Check Fuel Hoses 149
F. Air Cleaner 151
Clean Air Cleaner Outer Element 151
Replace Air Cleaner Outer and Inner Elements 151
Clean Dust Cup 152
G. Cooling System 153
Check Coolant Level 161
Check DCA4 Concentration in Coolant 162
Replace Coolant Filter 162
Change Coolant 163
Clean Radiator Interior 163
Clean Radiator Core 164
Check Fan Belt for Wear 164
H. Air Conditioner 165
Recirculation Air Filter 165
Ventilation Air Filter 166
Check Refrigerant Quantity 167
Check Compressor Belt Tension 168
Clean Condenser Core 169
Check Tightening Torque 170
Seasonal Maintenance 171
I. Electrical System 172
Batteries 172
Replace Batteries 174
Replacing Fuses 175
Power Source Terminal 177
Slow Blow Fuse 178
Check Electrical Cables and Wire Harnesses for Short Circuits 179
Check Emergency Engine Stop Switch 181
J. Miscellaneous 182
Check and Replace Seat Belt 183
Inspect Emergency Rope and Rope Mounting Hardware 183
Auto-Lubrication System 184
Automatic Greasing 185
Manual Greasing 187
Check Bucket Teeth 188
Check and Adjust Track Sag 190
Loosen Track 190
Tighten Track 191
Check Accumulator and Track Adjuster Cylinder Circuits 192
Check Side Frame Area 192
Check Tightening Torque of Bolts and Nuts 193
Maintenance Under Special Environmental Conditions 205

STORAGE
Storing the Machine 206
Removing the Machine from Storage 206

TROUBLESHOOTING
Engine 207
Electrical System 211
Control Levers 213
Hydraulic System 214
Auto-Idle 217

SPECIFICATIONS
Specifications 218
Working Range (Loading Shovel) 219
Working Range (Backhoe) 220

MACHINE NUMBERS
Machine Type and Serial Number 221
Product Identification Number 221
Engine Type and Serial Number 221
Travel Motor Type and Serial Number 221
Swing Motor Type and Serial Number 222
Hydraulic Pump Type and Serial Number 222
Front Type and Serial Number 222
Bucket Type and Serial Number 222

INDEX 223

Order the manual at mid-west-tech.com >