PART No. EM185-5-6

OPERATOR'S MANUAL

EX3500-2

EXCAVATOR

Serial. No. 0226 and up

HITACHI

MidWestTech | Hitachi EX3500-2 Excavator Operator's Manual | Publication EM185-5-6 Order the manual at mid-west-tech.com >

CONTENTS

Safety 1

Safety Signs 25

Handling Ladder / Emergency Rope 29

Operator's Station 31
Pedals and Levers 31
Monitor Panels and Switch Panels 32
Indicator Light Check Switch, Buzzer Stop Switch
Level Check Switch 42
Operating Wiper and Washer,
Hour Meter, Light Switches, Engine Room
Cooling Fan Switch 43
Fast Filling System (Option) 45
Air Conditioner 46
Adjusting the Seat, Seat Belt 52

Break-In 55

Pre-Start Inspection 56

Operating the Engine 57
Check Instrument before Starting 57
Starting the Engine 58
Starting in cold weather 60
Using Booster Batteries 61
Check Instrument after Starting,
Stopping the Engine 62
Emergency Engine Stop Switch, Engine stop
Switches 63

Driving the Machine 64
Drive Machine Carefully, Travel Speed
Select/Pilot Control Shutt-off Lever 64
Travel Alarm, Steering the Machine Using Pedals,
Steering the Machine Using Levers 65

Operating the Machine 67
Horn, Control Lever 67
Bucket Open-Close, Arm Retraction 72
Warming Machine 73
Auto-Idle Switch 74
Power Mode Selection Switch 75
Traveling 76
Craning 81
Backhoe Operation 82
Loading Shovel Operation 85

Maintenance 89
Correct Maintenance and Inspection
Procedure 89
Periodic Replacement of Rubber Hoses 99
Maintenance Interval Guide 107
A. Greasing 111
B. Engine Oil 118
C. Gear Oil 122
D. Hydraulic System 129
E. Fuel System 146
F. Air Cleaner 150
G. Air System 152
H. Cooling System 155
I. Air Conditioner 163
J. Electrical System 168
K. Miscellaneous 177
Check Seat Belt 177
Inspect Emergency Rope and Rope
Mounting Hardware 178
Auto - Lubrication System (Option) 178
Check Bucket Teeth 182
Check Track Sag 184
Check Accumulator Gas 186
Clean Side Frame 186
Check Tightening Torque of Bolts
and Nuts 187

Maintenance Under Special Environmental
Conditions 197

Storage 198

Troubleshooting
Engine 199
Electrical System, Control Levers 204
Hydraulic System 206
Mode Selection, Auto-Idle 209

Specifications 210

Machine Numbers 214

MidWestTech | Hitachi EX3500-2 Excavator Operator's Manual | Publication EM185-... Order the manual at mid-west-tech.com >