PART No. EM185 – 6 – 2

# OPERATOR'S MANUAL

# EX3500-3

# HYDRAULIC EXCAVATOR

HITACHI

Serial No. 0301 and up

MidWestTech | Hitachi EX3500-3 Excavator Operator's Manual | Publication EM185-6-2 Order the manual at mid-west-tech.com >

# CONTENTS


## SAFETY

Recognize Safety Information ..... S1
Understand Signal Words ..... S1
Follow Safety Instructions ..... S2
Prepare for Emergencies ..... S2
Wear Protective Clothing ..... S3
Protect Against Noise ..... S3
Inspect Machine ..... S3
Use Handholds and Steps ..... S4
Adjust the Operator' s Seat ..... S4
Fasten Your Seat Belt ..... S5
Move and Operate Machine Safely ..... S5
Operate Only from Operator' s Seat ..... S6
Handle Starting Aids Safely ..... S6
Jump Starting ..... S7
Keep Riders off Machine ..... S7
Investigate Job Site Beforehand ..... S8
Protect Against Falling Stones and Debris .... S8
Provide Signals for Jobs Involving Multiple Numbers of Machines ..... S9
Confirm Direction of Machine to be Driven .... S9
Drive Machine Safely ..... S10
Avoid Injury from Rollaway Accidents ..... S11
Avoid Injury from Back-Over and Swing Accidents ..... S12
Keep Personnel Clear from Working Area .... S13
Never Position Bucket Over Anyone ..... S13
Avoid Undercutting ..... S13
Avoid Tipping ..... S14
Never Undercut a High Bank ..... S14
Dig with Caution ..... S15
Operate With Caution ..... S15
Avoid Power Lines ..... S15
Do Not Use for Craning Operation ..... S16
Protect Against Flying Debris ..... S16
Park Machine Safely ..... S16
Handle Fluids Safely-Avoid Fires ..... S17
Practice Safe Maintenance ..... S18
Warn Others of Service Work ..... S19
Support Machine Properly ..... S19
Stay Clear of Moving Parts ..... S19
Prevent Parts from Flying off ..... S20
Store Attachments Safely ..... S20
Prevent Burns ..... S21
Replace Rubber Hoses Periodically ..... S21
Avoid High-Pressure Fluids ..... S22
Prevent Fires ..... S23
Evacuating in Case of Fire ..... S24
Beware of Exhaust Fumes ..... S25
Avoid Heating Near Pressurized Fluid Lines ..... S25
Avoid Applying Heat to Lines Containing Flammable Fluids ..... S25
Remove Paint Before Welding or Heating ..... S26
Prevent Battery Explosions ..... S26
Service Air Conditioning System Safely ..... S27
Avoid Harmful Asbestos Dust ..... S27
Handle Chemical Products Safely ..... S28
Dispose of Waste Properly ..... S28

## SAFETY SIGNS ..... S29

## COMPONENTS NAME ..... 1

## HANDLING LADDER/EMERGENCY ROPE ..... 2

Using Ladder ..... 2
Operating Ladder on the Ground ..... 2
Operating Ladder on the Upperstructure ..... 3
Emergency Rope ..... 3
Emergency Exit ..... 4
Evacuating in Case of Fire ..... 5

## OPERATOR' S STATION

Pedals and Levers ..... 7
Monitor Panels and Switch Panels (Left) ..... 8
Gauges and Indicators on the Monitor Panel and Side Monitor Panel ..... 9
Engine Oil Pressure Gauge ..... 10
Coolant Temperature Gauge ..... 10
Air Pressure Gauge ..... 10
Fuel Gauge ..... 11
Engine Oil Level Indicator ..... 11
Pump Transmission Oil Level Indicator .... 11
Swing Device Oil Level Indicator ..... 11
Coolant Level Indicator ..... 12
Hydraulic Oil Level Indicator ..... 12
Engine Oil Pressure Indicator ..... 12
Coolant Temperature (Overheat) Indicator ..... 12
Hydraulic Oil Temperature Indicator ..... 13
Pump Transmission Oil Pressure Indicator ..... 13
Side Monitor Indicator ..... 13
Hydraulic Oil Level Indicator ..... 13
Pump Contamination Indicator ..... 14
Fuel Level Indicator ..... 14
Alternator Indicator ..... 14
Hydraulic Filter Contamination Indicator ..... 14
Pilot Filter Contamination Indicator ..... 15
Air Filter Restriction Indicator ..... 15
Engine Stop Indicator ..... 15
Ladder Position Indicator ..... 15
Auto-Lubrication Indicator (Optional) ..... 16
Stop Valve Indicator ..... 16
Fast Filling System Indicator (Optional) .... 16
Engine Controller Indicator ..... 16



Order the manual at mid-west-tech.com >

# CONTENTS


CENTRY™ Engine System Indicator ..... 17
Prelub Indicator ..... 17
Indicator Light Check Switch ..... 18
Buzzer Stop Switch ..... 18
Level Check Switch ..... 18
CENTRY™ Diag. Test Switch ..... 19
Operating Wiper and Washer ..... 20
Hour Meter ..... 20
Light Switches ..... 21
Fast-Filling System (Optional) ..... 22
Air Conditioner ..... 23
Using Air Conditioner ..... 26
Cooling ..... 26
Dehumidifying and Heating ..... 26
Heating ..... 27
Defrosting ..... 27
Caution on Using Air Conditioner ..... 28
FM/AM Radio Operation ..... 29
Adjusting the Seat ..... 32
Seat Belt ..... 33

**BREAK-IN**

Observe Machine Closely ..... 34
Every 10 Hours or Each Shift ..... 34
After the First 50 Hours ..... 34

**PRE-START INSPECTION**

Inspect Excavator Every 10 Hours or Each Shift Before Starting ..... 35

**OPERATING THE ENGINE**

Check Instruments before Starting ..... 36
Level Check ..... 37
Starting the Engine ..... 38
Starting in Cold Weather ..... 40
Using Booster Batteries ..... 41
Check Instruments after Starting ..... 42
Stopping the Engine ..... 42
Emergency Engine Stop Switch ..... 43
Engine Stop Switches ..... 43

**DRIVING THE MACHINE**

Drive the Machine Carefully ..... 44
Travel Speed Select/Pilot Control Shut-Off Lever ..... 44
Travel Alarm ..... 45
Steering the Machine Using Pedals ..... 45
Steering the Machine Using Levers ..... 46

**OPERATING THE MACHINE**

Horn ..... 47
Control Lever (ISO Pattern) ..... 48
Control Lever (HITACHI Pattern) ..... 50
Bucket Open-Close Pedals (Loading Shovel) ..... 52
Arm Retraction Switches (Loading Shovel) ..... 52
Warming Machine ..... 53
Auto-Idle Switch ..... 54
Power Mode Selection Switch ..... 55
Traveling ..... 56
Going Up or Down Hill ..... 57
Avoid Tipping ..... 57
Parking and Stopping on a Slope ..... 58
Operating in Water or Mud ..... 58
Raise One Track Using Boom and Arm ..... 59
Operating on Soft Ground ..... 59
Towing Machine a Short Distance ..... 59
Avoid Swinging Bucket to Move Objects ..... 60
Cautions when Operating ..... 60
Position the Machine Safely ..... 60
Backhoe Operation ..... 61
Grading Operation ..... 62
Avoid Abusive Operation ..... 62
Operating Tips ..... 63
Loading Shovel Operation ..... 64
Arm-Retract Operations ..... 64
Prohibited Operations ..... 65
After Finishing Work ..... 68
Parking the Machine ..... 69

**MAINTENANCE**

Correct Maintenance and Inspection Procedures ..... 70
Service Your Machine at Specified Intervals ..... 70
Check Hour Meter Regularly ..... 71
Prepare Machine for Maintenance ..... 71
Backhoe Front Attachment ..... 72
Loader Front Attachment ..... 72
Open Cab Door for Service ..... 73
Open Access Doors for Service ..... 73
Hydraulic System (Loading Shovel) ..... 74
Hydraulic System (Backhoe) ..... 76
Air System ..... 78
Periodic Replacement of Rubber Hoses ..... 80
Maintenance Interval Guide ..... 86
A. Greasing ..... 90
Front Joint Pins ..... 91
Loading Shovel Front ..... 91
Backhoe Front ..... 94
Swing Bearing ..... 95
Swing Gear ..... 95
Center Joint ..... 96
Operating the Lubricator ..... 97
Fan Drive for Auxiliary Oil Cooler ..... 99
B. Engine ..... 100
Engine Oil ..... 102
Check Engine Oil Level ..... 102
Change Engine Oil ..... 102
Replace Engine Oil Filter ..... 103


MidWestTech | Hitachi EX3500-3 Excavator Operator's Manual | Publication EM185-6-2 Order the manual at mid-west-tech.com >

# CONTENTS


Replace Engine Oil Bypass Filter ..... 104
Pump Transmission Oil ..... 105
C. Transmission ..... 108
Swing Gear Oil ..... 109
Travel Gear Oil ..... 110
D. Hydraulic System ..... 112
Inspection and Maintenance of Hydraulic Equipment ..... 113
Check Hydraulic Oil Level ..... 115
Drain Hydraulic Tank Sump ..... 116
Replace Full-Flow Filter ..... 117
Replace Bypass Filter ..... 118
Replace Drain Filter ..... 119
Replace Pilot Filter ..... 120
Change Hydraulic Oil ..... 121
Clean Suction Strainer ..... 123
Replace Suction Strainer ..... 123
Replace High-Pressure Strainer ..... 124
Clean Auxiliary Oil Cooler Core ..... 125
Check Hoses and Lines ..... 126
E. Fuel System ..... 129
Drain Fuel Tank Sump ..... 130
Drain Fuel Filter Sediment ..... 130
Replace Fuel Filter ..... 131
Clean Fuel Tank Strainer ..... 132
Check Fuel Hoses ..... 132
F. Air Cleaner ..... 134
Clean Air Cleaner Outer Element ..... 134
Replace Air Cleaner Outer and Inner Elements ..... 134
G. Air System ..... 136
Drain Air Filter ..... 137
Clean Air Filter Element (Strainer) ..... 137
Replace Air Governor Filter Element ..... 138
Check and Replace Air Dryer ..... 139
Check and Replace Oil Mist Separator ..... 139
H. Cooling System ..... 140
Check Coolant Level ..... 148
Check DCA4 Concentration in Coolant ..... 149
Replace Coolant Filter ..... 149
Change Coolant ..... 150
Clean Radiator Core ..... 151
Check Fan Belt Tension ..... 152
I. Air Conditioner ..... 153
Clean Air Conditioner Inner Filter ..... 153
Clean Cooling Unit Inner Filter ..... 154
Air Conditioner Outer Filter ..... 154
Check Refrigerant Quantity ..... 155
Check Compressor Belt Tension ..... 156
Clean Condenser Core ..... 156
Check Tightening Torque ..... 157
Seasonal Maintenance ..... 158
J. Electrical System ..... 159
Batteries ..... 159
Replacing Fuses ..... 161
Power Terminal ..... 162
Slow Blow Fuses ..... 162
Check Electrical Cables and Wire Harnesses for Short ..... 163
Check Emergency Engine Stop Switch ..... 165
K. Miscellaneous ..... 166
Check and Replace Seat Belt ..... 166
Inspect Emergency Rope and Rope Mounting Hardware ..... 167
Auto-Lubrication System (Optional) ..... 168
Checking Indicator Pins ..... 168
Check Grease Level ..... 169
Automatic Greasing ..... 169
Manual Greasing ..... 171
Fast-Filling System (Optional) ..... 172
Check Bucket Teeth ..... 173
Check and Adjust Track Sag ..... 175
Check Accumulator and Track Adjuster Cylinder Circuit ..... 177
Check Side Frame Area ..... 177
Check Tightening Torque of Bolts and Nuts ..... 178
Maintenance Under Special Environmental Conditions ..... 188

**STORAGE**
Storing the Machine ..... 189
Removing the Machine from Storage ..... 189

**TROUBLESHOOTING**
Engine ..... 190
Electrical System ..... 194
Control Levers ..... 196
Hydraulic System ..... 197
Mode Selection, Auto-Idle ..... 200

**SPECIFICATIONS**
Specification ..... 201
Working Range ..... 202
Loading Shovel ..... 202
Backhoe ..... 203

**MACHINE NUMBERS**
Machine Type and Serial Number ..... 204
Product Identification Number ..... 204
Engine Type and Serial Number ..... 204
Travel Motor Type and Serial Number, ..... 204
Swing Motor Type and Serial Number ..... 205
Hydraulic Pump Type and Serial Number ..... 205
Front Type and Serial Number ..... 205
Bucket Type and Serial Number ..... 205

**INDEX** ..... 206


MidWestTech | Hitachi EX3500-3 Excavator Operator's Manual | Publication EM185-6-2 Order the manual at mid-west-tech.com >