PART No. EM186 – 1 – 1

OPERATOR'S MANUAL

EX2500-5

HYDRAULIC EXCAVATOR

Serial No. 000501 and up

HITACHI

MidWestTech | Hitachi EX2500-5 Excavator Operator's Manual | Publication EM186-1-1 Order the manual at mid-west-tech.com >

CONTENTS

MACHINE NUMBERS

SAFETY

Recognize Safety Information S-1
Understand Signal Words S-1
Follow Safety Instructions S-2
Prepare for Emergencies S-2
Wear Protective Clothing S-3
Protect Against Noise S-3
Inspect Machine S-3
General Precautions for CAB S-4
Use Handholds and Steps S-5
Adjust the Operator's Seat S-5
Fasten Your Seat Belt S-6
Move and Operate Machine Safely S-6
Handle Starting Aids Safely S-6
Operate Only from Operator's Seat S-7
Jump Starting S-7
Keep Riders Off Machine S-7
Investigate Job Site Beforehand S-8
Protect Against Falling Stones and Debris S-8
Provide Signals for Jobs Involving Multiple Numbers of Machines S-9
Confirm Direction of Machine to be Driven S-9
Drive Machine Safely S-10
Avoid Injury from Rollaway Accidents S-11
Avoid Injury from Back-Over and Swing Accidents S-12
Keep Person Clear from Working Area S-13
Never Position Bucket Over Anyone S-13
Avoid Undercutting S-13
Avoid Tipping S-14
Never Undercut a High Bank S-14
Dig with Caution S-15
Operate with Caution S-15
Avoid Power Lines S-15
Object Handling S-16
Protect Against Flying Debris S-16
Park Machine Safely S-17
Handle Fluids Safely – Avoid Fires S-17
Practice Safe Maintenance S-18
Warn Others of Service Work S-19
Support Machine Properly S-19
Stay Clear of Moving Parts S-19
Prevent Parts from Flying S-20
Store Attachments Safely S-20
Prevent Burns S-21
Replace Rubber Hoses Periodically S-21
Avoid High-Pressure Fluids S-22
Prevent Fires S-23
Evacuating in Case of Fire S-24
Beware of Exhaust Fumes S-24
Precautions for Welding and Grinding S-25
Avoid Heating Near Pressurized Fluid Lines S-26
Avoid Applying Heat to Lines Containing Flammable Fluids S-26
Remove Paint Before Welding or Heating S-26
Prevent Battery Explosions S-27
Service Air Conditioning System Safely S-27
Handle Chemical Products Safely S-28
Dispose of Waste Properly S-28

SAFETY SIGNS S-29

COMPONENTS NAME 1-1

HANDLING LADDER/EMERGENCY ROPE

Using Ladder 1-2
Operating Ladder on the Ground 1-3
Operating Ladder on the Upperstructure 1-3
Emergency Escape 1-4
Emergency Exit 1-5
Evacuating in Case of Fire 1-5

OPERATOR'S STATION

Cab Features 1-7
Monitor Panel and Switch Panels (Left) 1-8
Monitor Panel 1-9
Fuel Gauge 1-10
Hydraulic Oil Temperature Gauge 1-10
Coolant Temperature Gauge 1-10
Tachometer 1-10
Hydraulic Oil Level Indicator(Warning) 1-11
Fuel Level Indicator 1-11
Engine Oil Level Indicator 1-11
Download Indicator 1-11
Coolant Level Indicator 1-12
Hydraulic Oil Level Indicator 1-12
Travel Mode Indicator (Slow Speed) 1-12
Auto Idle Indicator 1-12
Engine Room Light Indicator 1-13
Entrance Light Indicator 1-13
Prelub Indicator 1-13
Travel Mode Indicator (Fast Speed) 1-13
Coolant Level Indicator (Warning) 1-14
Auto-Lubrication Indicator 1-14
Engine Stop Indicator (Warning) 1-14
Engine Warning Indicator 1-14
Air Cleaner Restriction Indicator(Warning) 1-15
Pump Contamination Indicator(Warning) 1-15
Fast-Filling System Indicator 1-15
Stop Valve Indicator (Warning) 1-15
Emergency Engine Stop Indicator 1-16
Ladder Position Indicator 1-16
Switch Panel 1-17
Wiper Switch 1-18
Wiper Delay Selector Switch 1-18

Order the manual at mid-west-tech.com >

CONTENTS

Washer Switch 1-18
Air Conditioners 1-19
Cooling 1-21
Heating 1-21
Dehumidifying and Heating 1-22
Defrosting 1-23
Blower Operation without Cooling or Heating 1-24
Ventilation the Cab 1-24
Indicator Light Check Switch 1-25
Level Check Switch 1-26
Buzzer Stop Switch 1-27
Dimmer Switch 1-28
Engine Speed Control Lever 1-28
Work Light Switch 1-29
Dome Light Switch 1-30
Engine Room Light Switch 1-31
Entrance Light Switch 1-32
Travel Speed Switch 1-33
Auto-Idle Switch 1-33
Fast-Filling System Switch 1-34
Switch Panel (Right) 1-35
Emergency Engine Stop Switch 1-35
Key Switch 1-35
Engine Troubleshooting Switch 1-36
Hour Meter 1-37
Horn Switch 1-38
FM/AM Radio Operation 1-39
Digital Clock Setting Procedure 1-40
Operator's Seat Adjustment 1-41
Seat Belt 1-43
Cab Door Release Button 1-44
Opening Cab Left Window 1-44

BREAK-IN

Observe Machine Closely 2-1
Every 10 Hours or Each Shift 2-1
After the First 50 Hours 2-1

OPERATING THE ENGINE

Inspect Machine Daily Before Starting 3-1
Check Instruments Before Starting 3-2
Level Check 3-3
Starting the Engine 3-4
Starting in Cold Weather 3-5
Check Instruments After Starting 3-6
Using Booster Batteries 3-7
Stopping the Engine 3-9
Emergency Engine Stop Switch 3-10
Engine Stoop Switches 3-11

DRIVING THE MACHINE

Drive the Machine Carefully 4-1
Steering the Machine Using Pedals 4-2
Steering the Machine Using Levers 4-3
Travel Speed Switch 4-4
Travel Alarm 4-5
Traveling 4-6
Operating on Soft Ground 4-7
Raise One Track Using Boom and Arm 4-7
Towing Machine a Short Distance 4-8
Operating in Water or Mud 4-9
Precautions for Traveling on Slopes 4-10
Parking the Machine on Slopes 4-11
Parking the Machine 4-11

OPERATING THE MACHINE

Control Lever (HITACHI Pattern Backhoe) 5-1
Control Lever (ISO Pattern Backhoe) 5-2
Control Lever (HITACHI Pattern Loading Shovel) 5-3
Control Lever (ISO Pattern Loading Shovel) 5-4
Bucket Open-Close Pedals (Loading Shovel) 5-5
Pilot Control Shut-Off Lever 5-6
Warming-Up Operation 5-7
Warming-Up the Motor and the Cylinders 5-8
Auto-Idle 5-9
Engine Speed Control 5-10
Precautions for Operations 5-11
Operate the Machine Safely 5-12
Operating Backhoe 5-13
Grading Operation 5-13
Avoid Abusive Operation 5-14
Operating Tips 5-15
Avoid Swinging Bucket to Move Objects 5-15
Loading Shovel Operation 5-16
Prohibited Operation 5-16
Object Handling — If Equipped 5-19
Overnight Storage Instructions 5-20

MAINTENANCE

Correct Maintenance and Inspection Procedures 7-1
Service Your Machine at Specified Intervals 7-2
Check the Hour Meter Regularly 7-2
Use Correct Fuels and Lubricants 7-2
Prepare Machine for Maintenance 7-3
Open Access Doors for Service 7-5
Inspection/Maintenance Lights 7-6
Use a Chain to Prevent Falling Accidents 7-7
Construction Outline 7-9
Hydraulic System 7-10
Periodic Replacement of Rubber Hoses 7-14
Maintenance Interval Guide 7-18
A. Greasing 7-22
Loading Shovel Front Joint Pins 7-23
Backhoe Front Joint Pins 7-26
Swing Bearing 7-28
Swing Internal Gear 7-29
Center Joint 7-30

Order the manual at mid-west-tech.com >

CONTENTS

Operating the Lubricator 7-31
B. Engine 7-33
Engine Oil Level 7-34
Change Engine Oil 7-35
Replace Engine Oil Filters 7-35
C. Transmission 7-37
Pump Transmission 7-38
Swing Reduction Gear 7-41
Travel Reduction Gear 7-43
D. Hydraulic System 7-45
Inspection and Maintenance of Hydraulic Equipment 7-46
Check Hydraulic Oil Level 7-48
Drain Hydraulic Oil Tank Sump 7-49
Replace Full-Flow Filter and Drain Filter 7-50
Replace Bypass Filter 7-52
Replace Pilot Oil Filter 7-54
Change Hydraulic Oil 7-56
Suction Filter Cleaning 7-56
Replace Suction Filter 7-60
Replace High-Pressure Strainer 7-62
Clean Oil Cooler Front Screen 7-63
Check Hoses and Lines 7-64
Service Recommendations for Hydraulic Fittings 7-67
E. Fuel System 7-69
Refueling 7-69
Drain Fuel Tank Sump 7-71
Drain Fuel Filter Sediment 7-71
Replace Fuel Filter 7-72
Check Fuel Hoses 7-73
Clean Fuel Cooler Core 7-75
F. Air Cleaner 7-76
Clean Air Cleaner Outer Element 7-76
Replace Air Cleaner Outer and Inner Elements 7-76
G. Cooling System 7-78
Check Coolant Level 7-80
Check DCA4 Concentration in Coolant 7-81
Replace Coolant Filter 7-89
Change Coolant 7-90
Clean Radiator Interior 7-90
Clean Radiator Core 7-92
Check Fan Belt for Wear 7-92
H. Air Conditioner 7-93
Recirculation Air Filter 7-93
Ventilation Air Filter 7-94
Check Refrigerant Quantity 7-95
Check Compressor Belt Tension 7-96
Clean Condenser Core 7-97
Check Tightening Torque 7-98
Seasonal Maintenance 7-99
I. Electrical System 7-100
Batteries 7-100
Replace Batteries 7-104
Replacing Fuses 7-105
Power Source Terminal 7-107
Slow Blow Fuse 7-108
Check Electrical Cables and Wire Harnesses for Short Circuits 7-109
Check Emergency Engine Stop Switch 7-111
J. Miscellaneous 7-112
Check Bucket Teeth 7-113
Inspect Emergency Evacuation Equipment and Hanger 7-115
Auto-Lubrication System 7-116
Check and Replace Seat Belt 7-120
Check Windshield Washer Fluid Lever 7-120
Check and Adjust Track Sag 7-121
Check Accumulator and Track Adjuster Cylinder Circuit 7-123
Check Side Frame Area 7-123
Check Tightening Torque of Bolts and Nuts 7-124

MAINTENANCE UNDER SPECIAL ENVIRONMENTAL CONDITIONS

Maintenance Under Special Environmental Conditions 9-1

STORAGE

Storing the Machine 10-1
Removing the Machine from Storage 10-2

TROUBLESHOOTING

Engine 11-1
Electrical System 11-5
Control Levers 11-8
Hydraulic System 11-8
Auto-Idle 11-11

SPECIFICATIONS

Specifications 12-1
Working Range (Loading Shovel) 12-2
Working Range (Backhoe) 12-3

INDEX 14-1

MidWestTech | Hitachi EX2500-5 Excavator Operator's Manual | Publication EM186-1-1 Order the manual at mid-west-tech.com >