PART No. EM187 – 1 – 2

OPERATOR'S MANUAL

EX1800-3

HYDRAULIC EXCAVATOR

Serial No. 00501 and up

HITACHI

MidWestTech | Hitachi EX1800-3 Excavator Operator's Manual | Publication EM187-1-2 Order the manual at mid-west-tech.com >

CONTENTS

SAFETY

Recognize Safety Information S1
Understand Signal Words S1
Follow Safety Instructions S2
Prepare for Emergencies S2
Wear Protective Clothing S3
Protect Against Noise S3
Inspect Machine S3
Use Handholds and Steps S4
Adjust the Operator's Seat S4
Fasten Your Seat Belt S5
Move and Operate Machine Safely S5
Operate only from Operator's Seat S6
Handle Starting Aids Safely S6
Jump Starting S7
Keep Riders Off Machine S7
Investigate Job Site Beforehand S8
Protect Against Falling Stones and Debris S8
Provide Signals for Jobs Involving Multiple Numbers of Machines S9
Confirm Direction of Machine to be Driven S9
Drive Machine Safely S10
Avoid Injury from Rollaway Accidents S11
Avoid Injury from Back-Over and Swing Accidents S12
Keep Personnel Clear from Working Area S13
Never Position Bucket Over Anyone S13
Avoid Undercutting S13
Avoid Tipping S14
Never Undercut a High Bank S14
Dig with Caution S15
Operate with Caution S15
Avoid Power Lines S15
Object Handling S16
Protect Against Flying Debris S16
Park Machine Safely S17
Handle Fluids Safely-Avoid Fires S17
Practice Safe Maintenance S18
Warn Others of Service Work S19
Support Machine Properly S19
Stay Clear of Moving Parts S19
Prevent Parts from Flying Off S20
Store Attachments Safely S20
Prevent Burns S21
Replace Rubber Hoses Periodically S21
Avoid High-Pressure Fluids S22
Prevent Fires S23
Evacuating in Case of Fire S24
Beware of Exhaust Fumes S25
Avoid Heating Near Pressurized Fluid Lines S25
Avoid Applying Heat to Lines Containing Flammable Fluids S25
Remove Paint before Welding or Heating S26
Prevent Battery Explosions S26
Service Air Conditioning System Safely S27
Avoid Harmful Asbestos Dust S27
Handle Chemical Products Safely S28
Dispose of Waste Properly S28

SAFETY SIGNS S29

COMPONENTS NAME 1

HANDLING LADDER/EMERGENCY ROPE

Using Ladder 2
Operating Ladder on the Ground 3
Operating Ladder on the Upperstructure 3
Emergency Rope 4
Emergency Exit 4
Evacuating in Case of Fire 5

OPERATOR'S STATION

Cab Features 7
Monitor Panel and Switch Panels (Left) 8
Monitor Panel 9
Engine Oil Level Indicator 10
Coolant Level Indicator 10
Hydraulic Oil Level Indicator 10
Travel Mode Indicator (Slow Speed) 10
Auto Idle Indicator 11
Engine Room Light Indicator 11
Entrance Light Indicator 11
Travel Mode Indicator (Fast Speed) 11
Coolant Temperature Gauge 12
Hydraulic Oil Temperature Gauge 12
Tachometer 12
Fuel Gauge 12
Alternator Indicator 13
Pump Transmission Oil Pressure Indicator 13
Hydraulic Oil Level Indicator (Warning) 13
Fuel Level Indicator 13
Auto-Lubrication Indicator (Optional) 14
Engine Stop Indicator 14
Engine Warning Indicator 14
Engine Protection Indicator 15
Air Cleaner Restriction Indicator 15
Pump Contamination Indicator 16
Emergency Engine Stop Indicator 16
Ladder Position Indicator 16
Switch Panel 17
Wiper Switch 18
Wiper Delay Selector Switch 18

Order the manual at mid-west-tech.com >

CONTENTS

Washer Switch 18
Air Conditioners 19
Cooling 21
Heating 21
Dehumidifying and Heating 21
Defrosting 22
Blower Operation without Cooling or Heating 22
Ventilation the Cab 22
Indicator Light Check Switch 23
Level Check Switch 23
Buzzer Stop Switch 24
Dimmer Switch 25
Engine Speed Control Lever 25
Work Light Switch 26
Dome Light Switch 27
Engine Room Light Switch 28
Entrance Light Switch 29
Travel Speed Switch 30
Auto-Idle Switch 30
Ether Switch (Starting Aid Switch) 31
Switch Panel (Right) 32
Emergency Engine Stop Switch 32
Key Switch 32
Engine Diagnostic Switch 33
Hour Meter 34
Horn Switch 35
FM/AM Radio Operation 36
Digital Clock Setting Procedure 37
Operator's Seat Adjustment 38
Seat Belt 40
Cab Door Release Button 41
Opening Cab Left Window 41

BREAK-IN
Observe Machine Closely 42

PRE-START INSPECTION 43

OPERATING THE ENGINE
Check Instruments before Starting 44
Level Check 45
Starting the Engine 46
Starting in Cold Weather 47
Check Instruments after Starting 48
Using Booster Batteries 49
Stopping the Engine 50
Emergency Engine Stop Switch 51
Engine Stop Switches 52

DRIVING THE MACHINE
Drive Machine Carefully 53
Steering the Machine Using Pedals 54
Steering the Machine Using Levers 55
Travel Speed Switch 56
Travel Alarm 57

OPERATING THE MACHINE
Conrol Lever (ISO Pattern) 58
Conrol Lever (HITACHI Pattern) 60
Bucket Open-Close Pedals (Loading Shovel) 62
Pilot Control Shut-Off Lever 63
Warming Machine 64
Auto-Idle Switch 65
Traveling 66
Operating on Soft Ground 67
Raise One Track Using Boom and Arm 67
Going Up or Down Hill 68
Avoid Tipping 68
Parking and Stopping on a Slope 69
Operating in Water or Mud 69
Avoid Swinging Bucket to Move Objects 70
Precautions for Operations 71
Operate the Machine Safely 72
Backhoe Operation 73
Grading Operation 74
Avoid Abusive Operation 74
Operating Tips 75
Loading Shovel Operation 76
Prohibited Operation 76
Towing Machine a Short Distance 79
Object Handling — If Equipped 80
Parking the Machine 81
Lock All Compartments 81
After Finishing Work 82

MAINTENANCE
Correct Maintenance and Inspection Procedure 83
Service Your Machine at Specified Intervals 84
Check the Hour Meter Regularly 84
Use Correct Fuels and Lubricants 84
Prepare Machine for Maintenance 85
Open Access Doors for Service 86
Inspection/Maintenance Lights 87
Use a Chain to Prevent Falling Accidents 88
Construction Outline 89
Hydraulic System (Loading Shovel) 90
Hydraulic System (Backhoe Shovel) 92
Periodic Replacement of Rubber Hoses 94
Maintenance Interval Guide 98
A. Greasing 102
Loading Shovel Front Joint Pins 103
Backhoe Front Joint Pins 106

MidWestTech | Hitachi EX1800-3 Excavator Operator's Manual | Publication EM187-1-2 Order the manual at mid-west-tech.com >

CONTENTS

Swing Bearing 107
Swing Internal Gear 108
Center Joint 109
Operating the Lubricator 110
B. Engine 112
Engine Oil Level 114
Change Engine Oil 115
Replace Engine Oil Filter 115
Pump Transmission 117
C. Transmission 120
Swing Reduction Gear 121
Travel Reduction Gear 123
D. Hydraulic System 125
Inspection and Maintenance of Hydraulic Equipment 126
Check Hydraulic Oil Level 128
Drain Hydraulic Oil Tank Sump 129
Replace Full-Flow Filter Element 130
Replace Drain Filter Element 132
Replace Pilot Oil Filter 134
Change Hydraulic Oil 136
Suction Strainer 139
Replace High-Pressure Strainer 140
Check Hoses and Lines 142
E. Fuel System 145
Refueling 145
Drain Fuel Tank Sump 147
Drain Fuel Filter Sediment 147
Replace Fuel Filter 148
Replace Fuel Tank Strainer 149
Drain Fuel Cooler Sump 150
Check Fuel Hoses 151
F. Air Cleaner 153
Clean Air Cleaner Outer Element 153
Replace Air Cleaner Outer and Inner Elements 153
G. Cooling System 155
Check Coolant Level 163
Check DCA4 Concentration in Coolant 164
Replace Coolant Filter 164
Change Coolant 165
Clean Radiator Interior 165
Clean Radiator Core 167
Check Fan Belt for Wear 167
H. Air Conditioner 168
Recirculation Air Filter 168
Ventilation Air Filter 169
Check Refrigerant Quantity 170
Check Compressor Belt Tension 171
Clean Condenser Core 172
Check Tightening Torque 173
Seasonal Maintenance 174
I. Electrical System 175
Batteries 175
Replace Batteries 177
Replacing Fuses 178
Power Source Terminal 180
Slow Blow Fuse 181
Check Electrical Cables and Wire Harnesses for Short Circuits 182
Check Emergency Engine Stop Switch 184
J. Miscellaneous 185
Check and Replace Seat Belt 186
Inspect Emergency Rope and Rope Mounting Hardware 186
Auto-Lubrication System (Optional) 187
Check Bucket Teeth 191
Check and Adjust Track Sag 193
Loosen Track 193
Tighten Track 194
Check Accumulator and Track Adjustment Cylinder Circuits 195
Check Side Frame Area 195
Check Windshield Washer Fluid Level 196
Check Tightening Torque of Bolts and Nuts 197
Maintenance Under Special Environmental Conditions 209

STORAGE
Storing the Machine 210
Removing the Machine from Storage 210

TROUBLESHOOTING
Engine 211
Electrical System 215
Control Levers 217
Hydraulic System 218
Auto-Idle 221

SPECIFICATIONS
Specification 222
Working Range (Loading Shovel) 223
Working Range (Backhoe) 224

MACHINE NUMBERS
Machine Type and Serial Number 225
Product Identification Number 225
Engine Type and Serial Number 225
Travel Motor Type and Serial Number 225
Swing Motor Type and Serial Number 226
Hydraulic Pump Type and Serial Number 226
Front Type and Serial Number 226
Bucket Type and Serial Number 226

INDEX 227

MidWestTech | Hitachi EX1800-3 Excavator Operator's Manual | Publication EM187-1-2 Order the manual at mid-west-tech.com >