EX200-5 EX200 LC-5
EX210 H-5
EX210 LCH-5
EQUIPMENT
COMPONENTS PARTS

HITACHI

PARTS CATALOG

EX200-5 EX200 LC-5 EX210 H-5 EX210
LCH-5 EQUIPMENT COMPONENTS PARTS

PART NO. EP14M-E1-4

SERIAL NO. 050001-

PART NO. EP14M-E1-4

MidWestTech | Hitachi EX200-5, EX200 LC-5, EX210 H-5, EX210 LCH-5 Excavator Parts C... Order the manual at mid-west-tech.com >

部品番号 PART NO.	コード CODE	部品名	PART NAME	適用号機 SERIAL NO.	頁 PAGE
ポンプ			PUMP		
9150726	9150726A	ポンプ装置	PUMP DEVICE		001
+++++++	9150727	・ポンプ;ユニット	-PUMP;UNIT		003
9150728	9150728	・・レギュレータ	--REGULATOR		005
4276918	04509008	・ポンプ;ギヤ	-PUMP;GEAR		007
4278696	0451400A	ポンプ;ギヤ	PUMP;GEAR		009
モータ；オイル			MOTOR；OIL		
4330222	0667600A	モータ;オイル（旋回）	MOTOR;OIL (SWING)		011
9146471	9146471	モータ;オイル（走行）	MOTOR;OIL (TRAVEL)		013
9145186	9145186	・バルブ;ブレーキ	-VALVE;BRAKE		015
9134147	9134147A	・・バルブ;リリーフ	--VALVE;RELIEF		017
9130524	9130524	・ピストン;サーボ	-PISTON;SERVO		019
バルブ			VALVE		
4366959	-------	バルブ;コントロール	VALVE;CONTROL		---
+++++++	06728008	・バルブ;コントロール（1/5）	-VALVE;CONTROL (1/5)		021
+++++++	0672900A	・バルブ;コントロール（2/5）	-VALVE;CONTROL (2/5)		023
+++++++	06730008	・バルブ;コントロール（3/5）	-VALVE;CONTROL (3/5)		025
+++++++	0673100A	・バルブ;コントロール（4/5）	-VALVE;CONTROL (4/5)		027
+++++++	0673200A	・バルブ;コントロール（5/5）	-VALVE;CONTROL (5/5)		029
9149232	9149232A	バルブ;パイロット（フロント，旋回）	VALVE;PILOT (FRONT & SWING)	050001-050095	031
9156581	9156581A	バルブ;パイロット（フロント，旋回）	VALVE;PILOT (FRONT & SWING)	050096-	033
9149233	9149233	バルブ;パイロット（走行）	VALVE;PILOT (TRAVEL)	200,LC：050001-083346 210H,LCH：050001-083344	035
9151777	9151777	バルブ;パイロット（走行）	VALVE;PILOT (TRAVEL)	200,LC：083347- 210H,LCH：083345-	037
9137384	9137384	バルブ;パイロット	VALVE;PILOT		039
4367132	0672400A	バルブ;フロウコントロール	VALVE;FC		041
4350150	0661800	バルブ;ソレノイド	VALVE;SOLENOID		043
4351142	0670500	バルブ;リリーフ	VALVE;RELIEF		045
9075046	90750468	バルブ;スローリターン	VALVE;SLOW-RETURN		047

MidWestTech | Hitachi EX200-5, EX200 LC-5, EX210 H-5, EX210 LCH-5 Excavator Parts C... Order the manual at mid-west-tech.com >

部品番号 PART NO.	コード CODE	部 品 名	PART NAME	適用号機 SERIAL NO.	頁 PAGE
4372037	0671400	バルブ;スローリターン	VALVE;SLOW-RETURN		049
4334827	0668300	バルブ;ロック	VALVE;LOCK		051
4311303	0644400	バルブ;ホールディング	VALVE;HOLDING		053
シリンダ			CYLINDER		
4317393	0667200	シリンダ;ブーム（右）[STD] [AUS]	CYL.;BOOM (R) [STD] [AUS]		055
4372912	0679400	シリンダ;ブーム（右）[USA]	CYL.;BOOM (R) [USA]		057
4317394	0667300	シリンダ;ブーム（左）[STD] [ASU]	CYL.;BOOM (L) [STD] [AUS]		059
4372913	0679500	シリンダ;ブーム（左）[USA]	CYL.;BOOM (L) [USA]		061
4316930	0667400	シリンダ;アーム [STD] [AUS]	CYL.;ARM [STD] [AUS]		063
4372914	0679600	シリンダ;アーム [USA]	CYL.;ARM [USA]		065
4318327	0667500	シリンダ;バケット [STD] [AUS]	CYL.;BUCKET [STD] [AUS]		067
4372915	0679700	シリンダ;バケット [USA]	CYL.;BUCKET [USA]		069
4371061	0671500A	シリンダ;バケット（スーパーロング）	CYL.;BUCKET (RIVER MAINTENANCE)		071
4288743	0496700A	シリンダ;クラムシェル	CYL.;CLAMSHELL		073
索 引			PARTS INDEX		075

MidWestTech | Hitachi EX200-5, EX200 LC-5, EX210 H-5, EX210 LCH-5 Excavator Parts C... Order the manual at mid-west-tech.com >

·Q'TY Q'ty shows the quantity used for a particular single hydraulic unit, however quantity of components shows the quantity for one assembly part.

·SERVICE CODE Abbreviations in the column of service code have their own meaning as shown below.

W: The part with this abbreviation shows that the part requires some work on it before installing in the machine.

D: The part with this abbreviation is a component of an assembly and is not available independently. The assembly part containing this part should be ordered.

K: This means that the part is contained in the service parts kit.

M: The part with this abbreviation shows that the quantity of the part is changed depending upon the machine, such as an adjusting shim etceteras.

S: This part is specially provided as a service part, which was not provided in the machine before from shipping the factory.

OP: Optional parts

OS: Over-sized parts

US: Under-sized parts

(NOTE: Part with abbreviation "OS" or "US" is described on the line below the standard-sized part.)

#: The part with this mark is newly added on that page of the equipment.

·SERIAL No. The machine serial number is printed just above the SERIAL No. column on all parts list pages.

[The serial number corresponds to the figures following the letter P in the PIN (Product Identification Number) on the name-plate.]

This serial number indicates the machine serial number applicable to the group unit (or component) described on this page.

When parts are modified, both the old and new parts are shown in the parts catalog with the applicable machine serial numbers in the SERIAL No. column.

Be sure to check that the your machine serial number is included in the range of the serial numbers shown above or in the SERIAL No. column when selecting parts.

Descriptions starting with letter D indicate the date when the part was replaced. (Example: "D96/01-" means that this part was replaced January '96.)

Descriptions starting with letter H indicate the component manufacturing No. stamped on the component manufacturing No. plate.

Description stating with letter F indicate the Front attachment manufacturing No. stamped on the front attachment manufacturing No. plate.

The letter H or F is used to identify the component or front attachment manufacturing No. from the machine serial number.

·ICA ICA shows the interchangeability between the original and the improved parts. Abbreviations used in this column are as follows.

I: Part No. in the column of "Replaceable part" can be used instead of this part but not vice versa.

MidWestTech | Hitachi EX200-5, EX200 LC-5, EX210 H-5, EX210 LCH-5 Excavator Parts C... Order the manual at mid-west-tech.com >

PARTS INDEX

079

PART NO.	PAGE	ITEM
4312894	018	07
4314064	018	09
4314065	018	10
4316930	064A	
4317393	056A	
4317394	060A	
4317633	002A	34
4318327	068A	
4319299	038	01
4323936	074	1
4323937	074	3
4323938	074	100
4324747	054B	42
4330222	012A	
4333170	004A	12
4334827	052	
4334891	002B	63F
4334892	002B	63D
4334894	002B	63E
4334899	002B	63B
4335047	038	06B
4337035	004A	21
4337154	018	18
4337419	004A	06
4337483	004A	08
4337812	004A	44
4338053	004A	43
4338060	004A	47
4338061	004A	51
4338110	018	19
4338907	004A	10
4340855	002A	37
4340960	002B	63A
4342840	004B	59
4342841	006	15
4342843	006	14
4342846	006	41
4343074	004B	73
4343339	040	02
4346521	006	28
4346522	006	27
4347107	006	24
4348182	004A	07
4348665	004B	74
* 4350150	044	
4350928	006	49
4350938	006	48
4351142	046	
4352398	056A	1B
	056A	2B
	060A	1B
	060A	2B
	068A	2B
4352399	064A	1B
	064A	2B
4352400	068A	1B
4352707	036	11E
4354415	016	23
4355012	004B	64
4355083	004A	50
4355085	004A	46
4357063	038	23
4358413	014B	56
4358914	026B	95
	028B	95
4364104	014A	41
4364914	072B	100
4364915	056B	100
	058B	100
	060B	100
4364915	062B	100
4364916	064B	100
	066B	100
4364917	068B	100
	070B	100
4364970	038	04
4365007	016	15
4365448	072A	2B
4365826	004B	64A
4365897	072A	1B
4366959	022	
	024A	
	026A	
	028A	
	030	
4367132	042	
4367385	006	05
4367500	006	06
4368619	006	13
4368629	038	03
4368630	038	05
4369148	002B	50
4371061	072A	
4372034	022	24
	024A	24
4372035	028B	61
4372037	050	
4372038	026B	50
4372039	026B	51
	028B	51
4372204	026B	62
4372912	058A	
4372913	062A	
4372914	066A	
4372915	070A	
4379022	034	04
4379209	002A	34
4379582	002A	36
4384540	026A	34
4386065	012A	051
* 4396017	014A	33
447068	048	06
4506320	026B	84
	028B	84
	030	84
4506406	022	83
	024A	53A
	024B	83
	026B	83
	028B	83
4506407	054A	21
4506408	014B	64A
	016	35A
	022	55C
	022	63A
	024A	63A
	026B	62B
	028B	61C
	030	63A
	042	20
4506412	012A	489
	012B	882
	018	03
4506415	014A	34
	018	14
4506416	026B	90
4506418	002B	53A
	014B	63A
	024A	53C
	026B	91
4506418	030	66A
4506420	022	82
	024A	82
	026B	82
	030	82
	054A	24
4506424	016	12
	016	17A
	022	55A
	024A	04A
	046	13
4506428	012A	488
4506429	054A	25
4506430	056A	30
	058A	31
	060A	30
	062A	31
	068A	29
	070A	29
4508160	074	15
4509180	002A	43A
	004B	80A
	016	25A
	022	55B
	024A	03A
	026B	65A
	026B	85
	030	26A
	030	65A
	030	85
	042	22
	046	12
	054A	23
4509181	072A	27
4509493	016	29
* 4510188	022	24B
	024A	24B
4510494	072A	5
4514388	004A	56
	006	38
4515041	004B	72
7018460	040	00
7024389	036	00
7030762	016	01
7031409	032	00
	034	00
8050658	014A	17
8058352	002A	23
8059452	004A	19
8063718	038	00
9075046	048	
9086168	040	24
9089484	016	35
9089485	016	33
9089486	016	25
9089488	016	17
* 9101513	032	11
	034	11
9101522	036	24
9102507	036	16
9107447	032	11
	034	11
9108066	032	12
	034	12
9130524	014B	53
	020	
9134018	036	11
9134109	014B	64
9134110	002B	54
	004B	67

MidWestTech | Hitachi EX200-5, EX200 LC-5, EX210 H-5, EX210 LCH-5 Excavator Parts C... Order the manual at mid-west-tech.com >