Chassis
1482 Combine

Service Manual

GSS1496

CASE IH AGRICULTURE

MidWestTech | Case Chassis 1482 Combine Service Manual | Publication GSS-1496

Order the manual at mid-west-tech.com >

Section 1

SEPARATOR DRIVE UNITS

Contents

	Page
Specifications	1-2
Main Drive Line	1-3
Power Drive Shaft	1-3
Knuckle Service	1-5
Main Drive Gear Box	1-7
Removal	1-7
Disassembly	1-10
Output Shaft	1-10
Input Shaft	1-11
Cross Shaft	1-12
Inspection and Repair	1-13
Reassembly	1-14
Cross Shaft	1-14
Input Shaft	1-17
Output Shaft	1-18
Main Drive Gear Box Assembly	1-20
General Information	1-21
Secondary Drive Case	1-21
Primary Drive Case	1-22
Installation of Input and Output Shaft Assemblies	1-24
Installation	1-25

MidWestTech | Case Chassis 1482 Combine Service Manual | Publication GSS-1496 Order the manual at mid-west-tech.com >