D-70 & SD70 Backhoe

Parts Catalog

H15487

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

Serial Number Location

When ordering parts or requesting information from your authorized Davis dealer by personal contact or correspondence, specify the model and serial number of the machine and backhoe in question. The bakchoe serial number plates for the D-70 and SD-70 are located on the backhoe control console.

Alphabetical Index

A

Angle Cylinder - Blade ---------- 8,48
Anti-Cavitation Valve ---------- 28,30,38

B

Backfill Blade ---------- 8
Backfill Blade Control Valve ---------- 16,36
Backfill Blade Controls ---------- 16
Backhoe Boom Cylinder ---------- 12,40
Backhoe Bucket ---------- 18
Backhoe Bucket Cylinder ---------- 12,42
Backhoe Control Valve ---------- 14,16,36
Backhoe Crowd Cylinder ---------- 12,42
Backhoe Dipper Cylinder ---------- 12,42
Backhoe Stabilizer Cylinder ---------- 6,46
Backhoe Swing Cylinder ---------- 10,44
Blade Angle Cylinder ---------- 8,48
Blade Lift Cylinder ---------- 8,48
Blade - Backfill ---------- 8
Boom Cylinder - Backhoe ---------- 12,40
Boom - Backhoe ---------- 12
Bucket Cylinder - Backhoe ---------- 12,42
Bucket - Backhoe ---------- 18

C

Control Valve - Backfill Blade ---------- 16,36
Control Valve - Backhoe ---------- 14,16,36
Controls - Backfill Blade ---------- 16
Controls - Backhoe ---------- 14,16
Crowd Cylinder - Backhoe ---------- 12,42
Cylinder - Backhoe Boom ---------- 12,40
Cylinder - Backhoe Bucket ---------- 12,42
Cylinder - Backhoe Crowd ---------- 12,42
Cylinder - Backhoe Dipper ---------- 12,42
Cylinder - Backhoe Stabilizer ---------- 6,46
Cylinder - Backhoe Swing ---------- 10,44
Cylinder - Blade Angle ---------- 8,48
Cylinder - Blade Lift ---------- 8,48

D

Decals ---------- 50
Dipper Cylinder - Backhoe ---------- 12,42
Dipper Stick - Backhoe ---------- 12

E

F

Frame - Backfill Blade ---------- 8
Frame - Backhoe ---------- 2,4

MidWestTech | Case D-70, SD70 Backhoe Parts Catalog | Publication H15487

Order the manual at mid-west-tech.com >

Alphabetical Index (cont.)

G

H

Hydraulic System - Backfill Blade ---------- 26
Hydraulic System - Backhoe ---------- 20-24,28-34

I

J

K

Kingpost - Backhoe ---------- 10

L

Lift Cylinder - Blade ---------- 8,48
Link - Transport ---------- 12

M

Mainframe - Backhoe ---------- 2,4

N

O

P

Q

R

Relief Valve ---------- 38

S

Stabilizer ---------- 6
Stabilizer Cylinder - Backhoe ---------- 6,46
Subframe - Backhoe ---------- 4
Swing Cylinder - Backhoe ---------- 10,44
Swing Tower - Backhoe ---------- 10

T

Tower - Backhoe Swing ---------- 10
Transport Link ---------- 12

U

V

Valve - Anti-Cavitation ---------- 38
Valve - Backfill Blade Control ---------- 16,36
Valve - Backhoe Control ---------- 14,16,36
Valve - Relief ---------- 38

W

X

Y

Z

MidWestTech | Case D-70, SD70 Backhoe Parts Catalog | Publication H15487

Order the manual at mid-west-tech.com >

GENERAL INFORMATION

Indexes

This parts catalog is arranged for easy identification of parts. The Alphabetical Index at the front of the catalog gives location of major groups and assemblies. The Numerical Index at the rear of the catalog gives part numbers and the page on which they are listed.

Orders

Orders should specify correct part number, full description, quantity required, backhoe serial number, method of shipment and shipping address.

Illustrations

All parts are illustrated and numbered in "exploded" views. Each part is shown in its normal relationship with the other parts in the illustration. The circled numbers correspond to numbers under REF. on the following page.

Changes

When changes are made to the machine, revised pages for this catalog will be issued. These pages must be inserted into your catalog as soon as they are received. Failure to keep your catalog up to date will result in confusion and may cause you to order wrong parts.

Part Numbers, Description and Quantity

All part numbers are listed under PART NO. The abbreviation NSS indicates that the item is not serviced separately. All parts are briefly described under DESCRIPTION. The symbol @ in the description column designates attaching parts for the preceding component. The Quantity used is listed under NO. REQ'D. Notice in the example below that the description of some items is moved in (indented) from the left-hand margin. An indented item is part of the item under which it is indented. The example shows that six track roller assemblies are used on the machine. Each track roller contains two nuts, two washers, two block and retainers, two "O" rings, and two face seal assemblies (indented items 1 thru 5). The face seal assemblies are further divided to show individual parts (items 6, 7 and 8).

Ref. No.	Part No.	Description	No. Req.
	R27948	ROLLER ASSEMBLY - Track, Single Flange	6
1	131-737	NUT - Hex, Lock (3/4" - 10 NC)	2
2	R29429	WASHER - Special	2
3	R27951	BLOCK AND RETAINER - Seal	2
4	A7156	SEAL - "O" Ring	2
5	D35267	SEAL - Face	2
6	NSS	BODY - Seal, Split	1
	D36826	KIT - Repair	1
7	NSS	SEAL - Rubber	2
8	NSS	RETAINER - Plastic	1

THIS CATALOG IS INTENDED TO PROVIDE PARTS ORDERING INFORMATION ONLY, AND SHOULD NOT BE USED AS A GUIDELINE FOR DISASSEMBLY OR REASSEMBLY OF THE MACHINE OR COMPONENTS. Parts are included in this catalog as a convenience to the owner. All parts must be ordered through an authorized Davis dealer.

Right-Hand and Left-Hand Sides

Right-hand and left-hand sides (abbreviated to R.H. and L.H.) of this machine and mounted equipment are determined by sitting in the operator's seat and facing the controls.

MidWestTech | Case D-70, SD70 Backhoe Parts Catalog | Publication H15487

Order the manual at mid-west-tech.com >