MOTOR GRADER

SERVICE MANUAL

HG190

HYUNDAI

MidWestTech | Hyundai HG190 Grader Service Manual | Publication HG190

Order the manual at mid-west-tech.com >

Installation and Maintenance Manual

Foreword ---------- 20-2

Safety Notes ---------- 20-4

Description of Hanging Up ---------- 20-6

Tightening Torque ---------- 20-8

Engine

Specification and Maintenance ---------- 20-9

Transmission System

1. Structure and Function ---------- 20-19

2. Maintenance Standard ---------- 20-49

Steering System

1. Structure and Function ---------- 20-52

2. Test and Adjustment ---------- 20-68

3. Maintenance Standard ---------- 20-74

Braking System

1. Structure and Function ---------- 20-78

2. Test and Adjustment ---------- 20-86

3. Maintenance Standard ---------- 20-92

Hydraulic System

1. Structure and Function ---------- 20-95

2. Test and Adjustment ---------- 20-115

3. Maintenance Standard ---------- 20-118

Work Equipment

1. Structure and Function ---------- 20-120

2. Test and Adjustment ---------- 20-128

3. Maintenance Standard ---------- 20-138

Electric System ---------- 20-145

MidWestTech | Hyundai HG190 Grader Service Manual | Publication HG190 Order the manual at mid-west-tech.com >

Dimensions of tire and spoke

Tire's Dimensions


The dimensions of tire include the tire width (in inch), inner diameter (in inch), tire layers indicating with dimensions and the three values connecting together by using of "-" symbol.

e.g.

13.00 – 24 – 12PR (Narrow Base Tire)

Width Inner Diameter Layers

17.5 – 25 – 12PR (Normal Tire)



Dimensions of Spokes

The dimensions include the spoke diameter indicated in inch and spoke's type and the spoke width indicated in inch.

e.g.

8.50V×24

Spoke Width
Spoke's Type
Spoke's Diameter


MidWestTech | Hyundai HG190 Grader Service Manual | Publication HG190 Order the manual at mid-west-tech.com >

Troubleshooting (Turning Motor)

Fault	Cause	Troubleshooting
Motor doesn't run	1. Dust or the oil is too dirty, radial load of shaft and shaft sleeve is too large and motor is clogged. 2. No pressure. 3. Motor internal leak.	1. Turn the motor and test the oil pressure. 2. Check the pumps and valves in the entire circuit. 3. Exchange the motor
The rotation speed of motor is different with the setting value	1. The oil of motor is not enough. 2. The axle temperature increases and hydraulic oil leaks and the viscidity reduce.	1. Check the flow rate of pump and motor, check the output volum in idling condition and check the drain flow of valves. 2. Use the oil with normal viscidity or use the normal oil temperature to drive.
The rotation speed of motor is deviated	1. Pipeline is wrong. 2. Speed adjusting is wrong.	1. Adjust pipeline 2. Change speed adjusting (means the re-installed items)
Shaft seal leaks	1. Sealing elements were worn or damaged	1. Change sealing elements.
Leak between flange and flange surface	1. The flange connection is too loose. 2. The O ring between flange and flange surface is damaged or the flange is damaged. 3. The connection seal leaks oil.	1. Re-tight (tightening torque: 26-32 N·m) 2. Check O-ring for scratch or bur and check the working surface of O-ring on the flange surface. 3. Change O-ring.
Leak from rear cover	1. The bolt of bottom cover has loosened. 2. The O-ring is worn or damaged. 3. Contacting area has dirt. 4. Contacting area has concave slot or crack.	1. Tight 7 bolts (Tightening torque: 32-35 N·m); 2. Replace O-ring; 3. Clean and reassemble it. 4. Grind the contacting area with 6# sand paper to smooth it.
The installed flange have crack (4 bolted flanges)	1. Result from the installation method	1. Change flange or use the normal bolt to tight.
Holes leak	1. Improper connection 2. Screw is damaged 3. Flange surface has crack	1. Re-connect 2. Change flange surface.
Abnormal sound	1. The axle is installed wrongly; 2. Air in the pipeline or motor; 3. Pump has clearance 4. Motor has clearance 5. Air in the oil inlet pipe	1. Reinstall 2. Exhaust 3. Exchange pump 4. Exchange motor 5. Exhaust
Abnormal temperature raise	1. Cooling system is abnormal; 2. The capacity of oil tank is not enough 3. The pressure is too high 4. Using swing mechanism frequently	1. Check and repair cooler; 2. Increase capacity or cooler 3. Adjust the overflow valve to normal pressure.

MidWestTech | Hyundai HG190 Grader Service Manual | Publication HG190 Order the manual at mid-west-tech.com >

The principle of hydraulic system



1.Hydraulic oil tank
2.Hydraulic and steering pump
3.Hydraulic oil filter
4.Hydraulic pump (gearbox)
5.Brake booster
6.Steering gear
7.Turning cylinder
8.Distributing valve
9.Left Control Valve
9A.Overflow valve
9B.Rear scarifier control valve (optional)
9C.Lifting cylinder (left) control valve
9D.Scraper plate side moving control valve
9E.Power incline control valve
9F.Turning control valve
10.Right control valve
10A.Overflow valve
10B.Hinge control valve
10C.Traction frame side swing control valve
10D.Incline control valve
10E.Scraper plate lifting cylinder control valve (right)
10F.Scarifier control valve (left)
11.Hydraulic-control check valve (with safety valve)
12.Hydraulic-control check valve
13.Scarifier cylinder (optional)
14.Lifting cylinder (left)
15.Scraper plate side moving oil cylinder
16.Power incline oil cylinder
17.Turning motor
18.Hinge oil cylinder
19.Traction frame side swing oil cylinder
20.Front wheel incline oil cylinder
21.Scraper plate lifting oil cylinder (right)
22.Scarifier oil cylinder (optional)

MidWestTech | Hyundai HG190 Grader Service Manual | Publication HG190

Order the manual at mid-west-tech.com >