VIBRATORY COMPACTOR BCA12S

Bobcat®

Parts Manual

Ingersoll-Rand S/N 169074 & Above
Bobcat S/N 491611050 & Above

NOTE: Serial Numbers listed within this manual are Ingersoll-Rand Serial Numbers.



An Ingersoll-Rand business
Printed in U.S.A.

CPN IR13226618 (12-02)

®Bobcat Company 2002

MidWestTech | Bobcat BCA12S Vibratory Compactor Parts Manual | Publication IR13226618 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS
BCA12S

TITLE **PAGE**

Table of Contents ..... A
Abbreviations Used In This Manual ..... D
Recommended Service Parts ..... E

FRAME

A

Frame Assembly A.1.2
Swivel Link Assembly A.2.2
Arch ROPS Installation A.3.2
Bent ROPS Installation - Optional A.4.2
Foldable ROPS Installation - Optional A.5.2
Hood and Trim Installation A.6.2
Front Bumper Installation - Optional A.7.2

For Internal Breakdowns - See Section I.

DRUM

B

Drum Installation B.1.2
Front Drum Assembly B.2.2
Rear Drum Assembly B.3.2

For Internal Breakdowns - See Section I.

ENGINE

C

Engine Installation C.1.2
Engine Assembly C.2.2
Propulsion Pump Assembly C.3.2
Vibration/Steering Pump Assembly C.4.2
Fuel Tank Installation C.5.2

For Internal Breakdowns - See Section I.

CONSOLE

D

Operators Platform Installation D.1.2
Pedestal Assembly D.2.2
Pedestal Assembly For Pressurized Water Installation - Optional D.3.2
Standard Seat Assembly D.4.2
Suspension Seat Assembly - Optional D.5.2
Instrument Panel Assembly D.6.2
Console Assembly For Pressurized Water Installation - Optional D.7.2
Steering Knob Installation - Optional D.8.2

For Internal Breakdowns - See Section I.

MidWestTech | Bobcat BCA12S Vibratory Compactor Parts Manual | Publication IR13226618 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS
BCA12S

TITLE PAGE

ELECTRICAL

E
Wire Harness Installation E.1.2
Main Wiring Harness Assembly E.2.2
Battery and Horn Installation E.3.2
Backup Alarm Installation - Optional E.4.2
Beacon Lamp Installation - Bent ROPS - Optional E.5.2
ROPS Beacon Lamp Installation - Arch ROPS - Optional E.6.2

For Internal Breakdowns - See Section I.

WATER SYSTEM

F
Water System Installation F.1.2
Scraper Assembly F.2.2
Pressurized Water System Installation - Optional F.3.2
Scraper Assembly - Optional F.4.2
Spray Tube Assembly - Optional F.5.2
Water Strainer Installation - Optional F.6.2

For Internal Breakdowns - See Section I.

DECALS AND PAINT

G
Decal Installation G.1.2

HYDRAULICS

H
Hydraulic Hose And Tube Installation H.1.2
Hydraulic Filter and Valve Installation H.2.2
Brake Valve Assembly H.3.2
Hydraulic Filter Assembly H.4.2
Vibration Valve Assembly H.5.2
Inside Scraper Installation - Optional H.6.2
Rear Inside Scraper Assembly - Optional H.7.2
Front Inside Scraper Assembly - Optional H.8.2

For Internal Breakdowns - See Section I.

INTERNAL BREAKDOWNS

MidWestTech | Bobcat BCA12S Vibratory Compactor Parts Manual | Publication IR13226618 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS
BCA12S

TITLE **PAGE**

I

Drive Motor (54596648) I.1.2
Propulsion Pump (54747449) I.2.2
Fuel Tank (13166244) I.3.2
Water Tank (13183645) I.4.2
F-Stop-R Control (59257790) I.5.2
Suspension Seat (13197926) I.6.2
Water Pump (13209978) I.7.2

MAINTENANCE INTERVAL KITS

M

Maintenance Interval Kits
- 250-Hour M.1.2

PUBLICATIONS AND TRAINING

P

Manuals P.1.2

WORD INDEX

W

Word Index W.1.2

NUMERIC INDEX

X

Numeric Index X.1.2

MidWestTech | Bobcat BCA12S Vibratory Compactor Parts Manual | Publication IR13226618 Order the manual at mid-west-tech.com >