Operation & Maintenance Manual

KEAM003400



D41E,P-6

BULLDOZER

SERIAL NUMBERS D41E-B30001 and up
D41P-B30001

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu D41E-6, D41P-6 Bulldozer Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >

PRECAUTIONS FOR OPERATIONS ---- 2- 16
BEFORE STARTING ENGINE ---- 2- 16
Checks before starting engine ---- 2- 16
Precautions when starting ---- 2- 16
Precautions in cold areas ---- 2- 17
AFTER STARTING ENGINE ---- 2- 18
Checks after starting engine ---- 2- 18
Precautions for moving machine forward or in reverse ---- 2- 18
Precautions when traveling ---- 2- 18
Traveling on slopes ---- 2- 19
Using brake ---- 2- 19
Operate carefully on snow ---- 2- 20
Parking machine ---- 2- 20
TRANSPORTATION ---- 2- 21
Loading and unloading ---- 2- 21
Shipping ---- 2- 21
BATTERY ---- 2- 22
Battery hazard prevention ---- 2- 22
Starting with booster cable ---- 2- 23
TOWING ---- 2- 24
When towing ---- 2- 24

PRECAUTIONS FOR MAINTENANCE ---- 2- 25
Warning tag ---- 2- 25
Keep work place clean and tidy ---- 2- 25
Appoint leader when working with others ---- 2- 25
Stop engine before carriying out inspection and maintenance ---- 2- 25
Two workers for maintenance when engine is running ---- 2- 26
Proper tools ---- 2- 27
Personnal ---- 2- 27
Attachments ---- 2- 27
Precautions for work under machine and work equippment ---- 2- 27
Work on top of machine ---- 2- 27
Noise ---- 2- 27
Precautions when using hammer ---- 2- 28
Repair welding ---- 2- 28
Removing battery terminal ---- 2- 28
Precautions when Using high-pressure grease to adjust track tension ---- 2- 28
Do not disassemble recoil spring ---- 2- 28
Precaution with high-pressure oil ---- 2- 29
Handling high-pressure hoses ---- 2- 29
Waste material ---- 2- 29
Maintenance for air conditioner ---- 2- 29
Use of lighting ---- 2- 30
Precautions when carrying out maintenance at high temperature ---- 2- 30
Checks after inspection and maintenance ---- 2- 30
Compressed air ---- 2- 31
Periodic replacement of safety critical parts ---- 2- 31

MidWestTech | Komatsu D41E-6, D41P-6 Bulldozer Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >

OPERATION

⚠ WARNING

Please read and make sure that you understand the safety volume before reading this section.

MidWestTech | Komatsu D41E-6, D41P-6 Bulldozer Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >