ILLUSTRATED PARTS LIST

KUBOTA

KX121-2

EXCAVATOR



Kubota

MidWestTech | Kubota KX121-2 Excavator Parts Manual | Publication KX121-2 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RD101-19110	BEARING SWIVEL	1	<=10429			44.8	98.56
010	RD101-19113	BEARING SWIVEL	1	>=10430	≠		40	88
020	01138-61645	BOLT	35	<=10608			0.101	0.2222
020	01138-51645	BOLT	35	>=10609	↔		0.1	0.22
030	99999-99999	BLANK	0				0	0
040	RD101-19210	TUBE GREASE	1	<=10429			0.016	0.0352
040	RD108-19210	TUBE GREASE	1	>=10430	≠		0.05	0.11
050	69241-19220	TUBE GREASE	1	<=10429			0	0
050	RC108-19220	TUBE GREASE	1	>=10430	≠		0.03	0.066
060	68241-67470	CONNECTOR	4	<=10429			0.013	0.0286
060	68721-67480	CONNECTOR	4	>=10430	≠		0.02	0.044
070	68241-67480	BODY CONNECTOR	4	<=10429			0.01	0.022
080	68331-41350	NUT	4	<=10429			0.002	0.0044
090	68331-41340	SLEEVE	4	<=10429			0.001	0.0022
100	06611-15010	NIPPLE GREASE	2				0.01	0.022

MidWestTech | Kubota KX121-2 Excavator Parts Manual | Publication KX121-2 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	68651-42910	SPONGE	2				0.013	0.0286
020	RC401-42690	SPONGE HOUSING	1				0.002	0.0044
030	99999-99999	BLANK	0				0	0
040	RD101-42740	SPONGE	1				0.048	0.1056
050	RD101-42770	SPONGE	1				0.03	0.066
060	RD101-42920	SPONGE	1				0.001	0.0022
070	99999-99999	BLANK	0				0	0
080	RD101-42790	SPONGE	1				0.015	0.033
090	RD101-43604	KIT SPONGE	1	<=10243			1.332	2.9304
090	RD108-43600	KIT SPONGE	1	>=10244	≠		0	0
090	RD108-43602	KIT SPONGE	1	>=10430	←		0.81	1.782
100	RD101-43610	SPONGE	1				0.15	0.33
110	RD101-43620	SPONGE	1	<=10429			0.15	0.33
110	RD108-43620	SPONGE	1	>=10430	←		0.065	0.143
120	RD101-43630	SPONGE	1	<=10429			0.3	0.66
120	RD108-43630	SPONGE	1	>=10430	←		0.145	0.319
130	RD101-43660	SPONGE	1	<=10243			0.22	0.484
130	RD108-43660	SPONGE	1	>=10244	≠		0	0
130	RD108-43662	SPONGE	1	>=10430	←		0.05	0.11
132	RD108-43640	SPONGE	1	>=10244			0.03	0.066
132	RD108-43640	SPONGE	1	<=10429			0.03	0.066
134	RD108-43650	SPONGE	1	>=10244			0.05	0.11
134	RD108-43650	SPONGE	1	<=10429			0.05	0.11
140	RD101-43670	SPONGE	1				0.2	0.44
150	RD101-43690	SPONGE	1				0.04	0.088
160	RD101-43710	SPONGE	1				0.05	0.11
170	RD101-43720	NOISE ABSORBER	1				0.002	0.0044
180	RD101-43730	NOISE ABSORBER	1				0.002	0.0044
190	RC301-51310	PLATE PARTITION TANK	1				0.03	0.066
200	RC301-62510	NOISE ABSORBER	1				0.02	0.044
210	RC301-62520	PLATE PARTITION	1				0.2	0.44
220	RD101-62530	SPONGE TANK REAR	1				0.025	0.055
230	RD101-62540	SPONGE TANK LOWER	1				0.02	0.044

MidWestTech | Kubota KX121-2 Excavator Parts Manual | Publication KX121-2 Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
010	RC101-53500	ASSY HEATER	1				4	8.8
020	68311-53510	HEATER	1				3.9	8.58
030	90038-11120	VALVE	1				0.2	0.44
040	68311-72810	CLAMP HOSE	4				0.02	0.044
050	68311-53540	ASSY SWITCH HEATER	1				0.1	0.22
060	01135-61020	BOLT	4				0.015	0.033
070	90407-11210	GROMMET	2				0.006	0.0132
080	55311-41260	BAND CORD	7				0.007	0.0154
090	68591-68190	ADAPTER	1				0.09	0.198
100	RD101-53520	HOSE	1				0.25	0.55
110	RD101-53530	HOSE	1				0.2	0.44
120	90038-11180	CLAMP	1				0.02	0.044
130	01133-61016	BOLT	1				0.018	0.0396
140	04015-60100	WASHER PLAIN	1				0.015	0.033
150	90038-11250	PIPE WATER	1				0.05	0.11
160	RD101-46850	JOINT WATER HOSE	1				0.165	0.363
170	RD101-46862	HOSE LOWER HEATER	1				0.177	0.3894
180	15108-72870	BAND	2				0.027	0.0594
190	RC108-46980	COVER HEATER	1				1.25	2.75
200	03614-50410	SCREW TAPPING	4				0.002	0.0044
210	15000-36550	CAP	1				0.045	0.099

MidWestTech | Kubota KX121-2 Excavator Parts Manual | Publication KX121-2 Order the manual at mid-west-tech.com >