ILLUSTRATED PARTS LIST

KUBOTA

L235

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	35260-35100	ASSY TANK,FUEL	1				6.9	15.18
002	99999-99999	BLANK	1			ORDER BY REF.No.001	0	0
003	38240-35200	ASSY CAP	1				0.06	0.132
004	99999-99999	BLANK	1			ORDER BY REF.No.003	0	0
005	99999-99999	BLANK	1			ORDER BY REF.No.003	0	0
006	99999-99999	BLANK	1			ORDER BY REF.No.003	0	0
007	34150-35470	GAUGE,FUEL	1				0	0
008	10013-41770	CLIP,PIPE	2				0.005	0.011
009	37300-35550	BUSH,FUEL	1				0.014	0.0308
010	35260-35270	SUPPORT,FUEL TANK	1				0.8	1.76
011	35260-35280	STAY,FUEL TANK RH	1				0.845	1.859
012	01152-50835	BOLT	1				0.015	0.033
013	01152-50830	BOLT	1				0.014	0.0308
014	02112-50080	NUT	2				0.003	0.0066
015	99999-99999	BLANK	0				0	0
016	37150-35290	STAY,FUEL TANK LH	1				0.38	0.836
017	01202-50816	BOLT	10				0.012	0.0264

MidWestTech | Kubota L235 Tractor Parts Manual | Publication L235 Order the manual at mid-west-tech.com >

DIFFERENTIAL CASE [4WD]

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	38440-43310	CASE, DIFFERENTIAL	1				2.1	4.62
002	37650-43320	PIN,SNAP	1				0.01	0.022
003	37650-43330	SHAFT,DIFF PINION	1				0.3	0.66
004	31220-26300	PINION, DIFFERENTIAL	2				0.155	0.341
005	31220-26360	BUSH	2				0.015	0.033
006	31220-26390	WASHER,DIFF PINION	2				0	0
007	38440-44980	GEAR,DIFF SIDE RH	2				0	0
008	31220-26480	WASHER	2				0.015	0.033
008	31220-26490	WASHER	2				0.02	0.044
008	37150-26480	WASHER	2				0.016	0.0352
009	99999-99999	BLANK	1			ORDER BY REF.No.026 ON FIG.No.093,REF.No	0	0
010	37650-43360	BUSH	1				0.039	0.0858
011	08101-06011	BEARING,BALL	1				0.376	0.8272
012	08101-06010	BEARING,BALL	1				0.262	0.5764
013	37800-43870	BOLT	6				0.026	0.0572
014	38440-43880	PIN,STRAIGHT	2				0	0
015	06331-35012	PLUG	1				0.022	0.0484
016	04717-01200	WASHER,SEAL	1				0.002	0.0044
017	37650-43130	SHIM 0.2	4				0.005	0.011
017	37650-43160	SHIM 0.1	4				0.002	0.0044
018	37650-43140	SHIM 0.2	2				0.005	0.011
018	37650-43170	SHIM 0.1	2				0.004	0.0088

MidWestTech | Kubota L235 Tractor Parts Manual | Publication L235 Order the manual at mid-west-tech.com >

TOP LINK HOLDER

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	35212-41400	ASSY HOLDER,TOP LINK	1				6.8	14.96
002	99999-99999	BLANK	1			ORDER BY REF.No.001	0	0
003	99999-99999	BLANK	1			ORDER BY REF.No.001	0	0
004	99999-99999	BLANK	1			ORDER BY REF.No.001	0	0
005	37300-41450	BUSH	3				0.03	0.066
006	37300-41440	PIN,STRAIGHT	2				0.055	0.121
007	06613-10010	NIPPLE,GREASE	3				0.006	0.0132
008	01173-51230	BOLT	4				0.037	0.0814
009	04512-50120	WASHER,SPRING	4				0	0
010	35260-41310	ROD,DRAFT CONTROL	1				0.105	0.231
011	35260-41320	ROD,DRAFT CONTROL	1				0.03	0.066
012	02112-50080	NUT	2				0.003	0.0066
013	05122-50814	PIN,JOINT	1				0.005	0.011
014	05122-50818	PIN,JOINT	1				0.008	0.0176
015	04012-50080	WASHER,PLAIN	2				0.001	0.0022
016	05511-50218	PIN,SPLIT	2				0.001	0.0022
017	35114-25340	COLLAR	2				0.02	0.044
018	01173-51235	BOLT	4				0.04	0.088
019	04512-50120	WASHER,SPRING	4				0	0

MidWestTech | Kubota L235 Tractor Parts Manual | Publication L235 Order the manual at mid-west-tech.com >