ILLUSTRATED PARTS LIST

KUBOTA

L305DT

TRACTOR



Kubota

Order the manual at mid-west-tech.com >

MAIN BEARING CASE

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15521-04040	ASSY CASE MAIN BEARI	1				0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
004	15521-04540	BOLT 1	6				0	0
005	15521-94010	WASHER	6				0.001	0.0022
006	15221-04360	GASKET	1				0	0
007	15221-04810	COVER BEARING	1				0.3	0.66
008	15221-04820	GASKET COVER	1				0	0
009	01123-50825	BOLT	8				0.013	0.0286
010	01123-50828	BOLT	8				0.014	0.0308
011	15221-04460	SEAL OIL	1				0.06	0.132
012	15521-04050	ASSY CASE BEARING 1	1				0	0
013	99999-99999	BLANK	0			ORDER BY REF.No.012	0	0
014	99999-99999	BLANK	0			ORDER BY REF.No.012	0	0
015	15521-04060	ASSY CASE MAIN BEARI	1				0	0
016	99999-99999	BLANK	0			ORDER BY REF.No.015	0	0
017	99999-99999	BLANK	0			ORDER BY REF.No.015	0	0
018	15291-04560	BOLT 2	2				0.06	0.132
019	15521-94020	WASHER	2				0.004	0.0088

MidWestTech | Kubota L305DT Tractor Parts Manual | Publication L305DT Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	15301-54020	ASSY APPARATUS FUEL	1				0	0
002	15301-54030	ASSY APPARATUS FUEL	1				0.037	0.0814
003	99999-99999	BLANK	0			ORDER BY REF.No.002	0	0
004	99999-99999	BLANK	0			ORDER BY REF.No.002	0	0
005	15261-54230	SPRING	1				0.001	0.0022
006	99999-99999	BLANK	0			ORDER BY REF.No.002	0	0
007	14301-54430	SCREW SET	1				0.001	0.0022
008	14301-54250	NUT LOCK	1				0.005	0.011
009	15221-54150	GASKET	2				0.001	0.0022
010	14301-54220	NUT CAP	1				0.015	0.033
011	14301-54420	CAP	1				0.005	0.011
012	15521-54090	ASSY APPARATUSE IDLE	1				0.045	0.099
013	15521-54100	ASSY BOLT ADJUSTING	1				0.015	0.033
014	99999-99999	BLANK	0			ORDER BY REF.No.013	0	0
015	15521-54260	SPRING	1				0.001	0.0022
016	15401-92010	NUT	1				0.01	0.022
017	15521-92330	NUT CAP	1				0.02	0.044
018	15021-33660	GASKET	2				0.001	0.0022
019	15521-54270	CAP	1				0.003	0.0066
020	99999-99999	BLANK	0				0	0
021	15221-57150	LEVER SPEED CONTROL	1				0.07	0.154
022	05712-00408	KEY FEATHER	1				0.001	0.0022
023	04811-00120	O RING	1				0.001	0.0022
024	04013-50080	WASHER PLAIN	1				0	0
025	02112-50080	NUT	2				0.003	0.0066
026	17011-57380	PLATE FRICTION	1				0	0
027	15221-57110	PLATE SPEED CONTROL	1				0	0
028	15221-57210	GASKET CONT.PLATE	1				0	0
029	15221-88210	STUD	2				0.005	0.011
030	02056-50060	NUT	2				0.002	0.0044
031	04512-50060	WASHER SPRING	2				0	0
032	99999-99999	BLANK	0			NON SALE	0	0
033	99999-99999	BLANK	0			NON SALE	0	0
034	99999-99999	BLANK	0			NON SALE	0	0
035	99999-99999	BLANK	0			NON SALE	0	0
036	99999-99999	BLANK	0			NON SALE	0	0

MidWestTech | Kubota L305DT Tractor Parts Manual | Publication L305DT Order the manual at mid-west-tech.com >

↔ Interchangeable; ≠ not interchangeable; ← new for old; → old for new

REF.No	Part No.	Description	Q'ty	S.No.	I/C	REMARKS	Weight (kgf)	Weight (lb)
001	35110-85010	ASSY SEAT	1				0	0
002	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
003	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
004	99999-99999	BLANK	0			ORDER BY REF.No.001	0	0
005	35110-18400	ASSY SUSPENSION SEAT	1				4.3	9.46
006	99999-99999	BLANK	0			ORDER BY REF.No.005	0	0
007	99999-99999	BLANK	0			ORDER BY REF.No.005	0	0
008	35258-18430	ARM 1	1				0.67	1.474
009	99999-99999	BLANK	0			ORDER BY REF.No.005	0	0
010	34119-18450	SPRING SEAT	2				0.117	0.2574
011	35258-18460	BOLT ADJUSTING	1				0.08	0.176
012	34269-18490	PIN	4				0.06	0.132
013	02118-50100	NUT	1				0.005	0.011
014	02116-50100	NUT	1				0.004	0.0088
015	04013-50100	WASHER PLAIN	8				0	0
016	05511-50220	PIN SPLIT	8				0.001	0.0022
017	32160-18440	CUSHION	1				0.013	0.0286
018	35258-18480	ROLLER	2				0.005	0.011
019	32160-18440	CUSHION	2				0.013	0.0286
020	01130-51020	BOLT	6				0	0
021	01130-51038	BOLT	2				0	0
022	35300-18460	SEAT SPACER FRONT	1				0.37	0.814
023	35300-18470	SEAT SPACER REAR	1				0.53	1.166
024	35110-18470	BOLT	2				0.012	0.0264
025	02114-50080	NUT	2				0.005	0.011
026	35340-18510	ASSY BOX TOOLS	1				3.05	6.71
027	35340-18520	BOX TOOLS	1				1.5	3.3
028	66571-54520	CAP SID	1				0.085	0.187
029	01053-50614	BOLT	2				0.005	0.011
030	04512-50060	WASHER SPRING	2				0	0
031	01173-51225	BOLT	2				0.033	0.0726
032	04512-50120	WASHER SPRING	2				0	0

MidWestTech | Kubota L305DT Tractor Parts Manual | Publication L305DT Order the manual at mid-west-tech.com >