KOBELCO®

PARTS CATALOG

SK295-9
Acera Mark 9 Excavator
Tier IV

LB91Z00005P1
Issued 3/2011

MidWestTech | Kobelco SK295-9 Acera Mark 9 Tier IV Excavator Parts Catalog | Publication LB91Z00005P1

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
AIR CLEANER & INTAKE PARTS	01-005	01
AIR CONDITIONER INSTALL	01-068	01
AIR CONDITIONER INSTALL	01-068	02
AIR CONDITIONER INSTALL	01-068	03
ALTERNATOR (4892317 - 504328894)	09-039	00
ARM - ASSY	03-009	00
ARM - GROUP	03-011	00
ARM - LINE	03-012	03
ARM - LINE	03-012	02
ARM - LINE	03-012	00
ARM - MOUNTING	03-010	00
ARM HYD LINES (N&B)	03-013	02
ARMREST	01-034	00
AUXILIARY HYDRAULIC - LINE (N&B)	03-013	01
BATTERY ASSY	01-067	00
BOOM - ASSY	03-001	02
BOOM - ASSY	03-001	00
BOOM - GROUP	03-002	02
BOOM - GROUP	03-002	00
BOOM - LINE	03-005	02
BOOM - LINE	03-005	00
BOOM - MOUNTING	03-003	00
CAB - DOOR ASSY	01-054	08
CAB - DOOR WINDOW	01-054	09
CAB - HARNESS ASSY	01-054	12
CAB - HARNESS ASSY	01-054	05
CAB - LIGHT INSTAL	01-054	13
CAB - RADIO	01-054	11
CAB - SEAL ASSY	01-054	06
CAB - WINDOW ASSY, FR	01-054	14
CAB - WINDOW ASSY, FR	01-054	15
CAB - WINDOW, ROOF	01-054	07
CAB - WIPER INSTAL	01-054	10
CAB ASSY	01-054	01
CAB ASSY	01-054	02
CAB ASSY	01-054	03
CAB ASSY, GLASS	01-054	04
CAB GUARD ASSY	01-056	01
CAB GUARD ASSY	01-056	02
CAB GUARD ASSY	01-056	03
CAB INSTAL	01-052	00
CAMSHAFT - TIMING CONTROL (504345141)	09-017	00
CLAMP ASSY	01-035	00
CONDITIONER, AIR	01-069	02
CONDITIONER, AIR	01-069	01
CONTROL BOX ASSY	01-039	00
CONTROL LINES, (MULTI)	01-021	00
CONTROL LINES, BLOCK	01-022	00
CONTROL LINES, MAIN	01-016	00
CONTROL LINES, MULTI	01-033	00
CONTROL LINES, PROPEL	01-020	00
CONTROL LINES, PUMP	01-031	00
CONTROL LINES, REMOTE (N&B HAND)	01-029	00
CONTROL LINES, REMOTE (NIBBLER & BREAKER - FOOT)	01-030	00
CONTROL LINES, REMOTE (SENSOR)	01-019	00
CONTROL LINES, REMOTE (SINGLE PEDAL TRAVEL)	01-032	00

Order the manual at mid-west-tech.com >

CONTROL LINES, VALVE	01-026	02
CONTROL LINES, VALVE	01-026	01
CONTROL LINES, VALVE (N&B W/ ROTATION)	01-028	01
CONTROL LINES, VALVE (N&B W/ROTATION)	01-028	02
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-027	00
CONTROLLER INSTAL	01-044	00
CONTROLS, OPERATORS	01-040	02
CONTROLS, OPERATORS	01-040	01
COUNTERWEIGHT	01-002	00
COVER ASSEBMLY, UNDER	01-063	00
COVER ASSEMBLY, UNDER (YN24CU0002F1)	02-012	00
CRANKCASE COVERS (4894734)	09-009	00
CRANKCASE COVERS (504038705)	09-010	00
CRANKCASE COVERS (504350260)	09-011	00
CYLINDER - LINE (ARM)	03-008	00
CYLINDER - LINE (BOOM)	03-006	00
CYLINDER - MOUNTING	03-007	00
CYLINDER - MOUNTING	03-004	00
CYLINDER ASSEMBLY, ARM	08-003	00
CYLINDER ASSEMBLY, BOOM	08-004	00
CYLINDER ASSEMBLY, BUCKET	08-005	00
CYLINDER HEAD (504115961)	09-005	00
CYLINDER HEAD COVERS (504327543)	09-006	00
ELECTRICAL ASSY, UPPER	01-066	00
ELECTRONIC INJECTION (504092213)	09-040	00
ENGINE ASSY (LB02P00019P1)	09-002	00
ENGINE BREATHERS (504331902)	09-007	00
ENGINE MOUNTING	01-003	00
ENGINE OIL SUMP (504010891)	09-008	00
EXHAUST MANIFOLD (504088265)	09-028	00
FAN DRIVE (504243628 - 504226781 - 504243503)	09-036	00
FLYWHEEL - ENGINE (504229874)	09-013	00
FRAME - LOWER	02-001	01
FRAME - LOWER (HIGH&WIDE)	02-001	03
FRAME - UPPER	01-001	01
FRAME - UPPER	01-001	02
FRAME - UPPER INSULATION	01-001	04
FRAME - UPPER INSULATION	01-001	03
FUEL FILTER (504135694)	09-020	00
FUEL LINES	01-007	02
FUEL LINES	01-007	01
FUEL TANK INSTALLATION	01-008	01
GUARD ASSY, CAB	01-053	00
GUARD INSTALLATION, (HOOD)	01-059	00
GUARD INSTALLATION, (INSIDE)	01-061	00
GUARD INSTALLATION, (PARTITION)	01-062	00
GUARD INSTALLATION, (SIDE PANEL)	01-060	00
HARNESS ASSY, FLASHER AND ALARM	01-075	01
HARNESS ASSY, FLASHER AND ALARM	01-075	02
HARNESS ASSY, UPPER	01-073	02
HARNESS ASSY, UPPER	01-073	01
HARNESS ASSY, UPPER	01-073	03
HARNESS ASSY, UPPER (FLOOR PLATE)	01-074	01
HARNESS ASSY, UPPER (FLOOR PLATE)	01-074	02
HEAT EXCHANGER - ENGINE (504096820 - 500396329)	09-035	00
HOOKS - ENGINE (504121114)	09-004	00
HYD LINES, ARM (ROTATION)	03-014	01
HYD LINES, PUMP (ROTATION)	01-014	01

Order the manual at mid-west-tech.com >

HYD LINES, RETURN	01-025	01
HYD LINES, RETURN	01-025	02
HYD LINES, UPPER (NIBBLER & BREAKER)	01-023	00
HYDRAULIC LINE - DRIVE	02-009	01
HYDRAULIC LINE - DRIVE (H&W)	02-009	02
HYDRAULIC LINE - LOWER	02-008	01
HYDRAULIC LINE - LOWER (H&W)	02-008	02
HYDRAULIC LINES UPPER (BASE)	01-017	00
HYDRAULIC LINES UPPER (STANDARD)	01-018	00
HYDRAULIC LINES, PUMP	01-014	00
HYDRAULIC LINES, SWIVEL	01-015	00
HYDRAULIC LINES, UPPER (ROTATION)	01-024	00
HYDRAULIC TANK ASSEMBLY	01-010	00
IDLER	02-006	01
IDLER - ASSY	02-005	01
IDLER - ASSY (H&W)	02-005	02
IDLER (H&W)	02-006	02
INJECTION EQUIPMENT - INJECTOR (504129392)	09-022	00
INJECTION EQUIPMENT - PIPING (504324976)	09-021	01
INJECTION PUMP (504041280)	09-023	00
INSULATION INSTAL	01-055	00
INTAKE MANIFOLD - ENGINE AIR INTAKE (504114394 - 504165154)	09-026	00
INTAKE MANIFOLD - HEATER (504116855)	09-027	00
ISL LIST A	00-001	00
ISL LIST B	00-002	00
JOINT ASSEMBLY, SWIVEL	08-001	00
JOINT INSTALLATION, SWIVEL	01-012	00
LEVER ASSY, PROPEL	01-037	00
LIGHT INSTAL, BOOM	01-072	00
LIGHT INSTAL, UPPER	01-070	00
MIRROR INSTALLATION (FRONT)	01-050	00
MIRROR INSTALLATION, CAB	01-051	00
MOTOR ASSEMBLY, PROPELLING	08-017	02
MOTOR ASSEMBLY, PROPELLING	08-017	03
MOTOR ASSEMBLY, PROPELLING	08-017	04
MOTOR ASSEMBLY, PROPELLING	08-017	01
MOTOR ELECTRIC INSTALLATION (504369519)	09-037	00
MUFFLER ASSEMBLY	01-006	00
NAME PLATE INSTALLATION, (CAB WARNING) LABEL	06-003	01
NAME PLATE INSTALLATION, (CAB WARNING) LOCATION	06-003	00
NAME PLATE INSTALLATION, (NIBBLER & BREAKER) LABEL	06-005	01
NAME PLATE INSTALLATION, (NIBBLER & BREAKER) LOCATION	06-005	00
NAME PLATE INSTALLATION, (PATTERN CHANGER CAB)	06-004	01
NAME PLATE INSTALLATION, (PATTERN CHANGER CAB) LOCATION	06-004	00
NAME PLATE INSTALLATION, BOOM	06-007	00
NAME PLATE INSTALLATION, LOCATION	06-006	00
NAMEPLATE INSTAL (LIFT CHARTS)	06-001	00
NAMEPLATE INSTALL, LIFT CHARTS (H&W)	06-002	00
OIL LEVEL CHECK (504310590 - 504088054)	09-029	00
OIL PUMP - ENGINE (504099881)	09-030	00
PANEL ASSY, INSTRUMENT	01-064	01
PANEL ASSY, INSTRUMENT	01-064	02
PANEL ASSY, INSTRUMENT	01-064	03
PEDAL, ASSY (3 BUTTON AND PEDAL, N+B AND PEDAL)	01-042	00
PEDAL, ASSY (STD, NO BOOST, 3 BUTTON)	01-041	00
PICTORIAL INDEX - ENGINE	09-001	01
PICTORIAL INDEX - ENGINE	09-001	02

Order the manual at mid-west-tech.com >