KOBELCO®

PARTS CATALOG

SK350-9 Acera Mark 9
Excavator Tier IV

APPLICABLE
ASN YC12U2401

LC91Z00021P1
Issued 5/2011

Copyright © 2009 Kobelco Construction Machinery America, LLC. All Rights Reserved

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
AIR CLEANER ASSY	01-010	00
AIR CONDITIONER	01-080	05
AIR CONDITIONER	01-080	04
AIR CONDITIONER	01-080	02
AIR CONDITIONER	01-080	03
AIR CONDITIONER	01-080	01
AIR INTAKE AND EXHAUST SYSTEM	08-009	03
AIR INTAKE AND EXHAUST SYSTEM	08-009	01
AIR INTAKE AND EXHAUST SYSTEM	08-009	02
ALARM ASSY	01-090	00
ARM 3.3M	03-023	00
ARM GROUP 3.3M	03-024	02
ARM GROUP 3.3M	03-024	01
ARM INSTALL	03-022	00
ARM REST	01-049	04
BATTERY ASSY	01-079	00
BOOM GROUP 6.5M	03-003	00
BOOM INSTALL	03-001	00
BOOM, HOE	03-002	00
BUCKET INSTALL	03-025	00
CAB INSTALL	01-062	11
CAB INSTALL	01-062	01
CAB INSTALL	01-062	10
CAB INSTALL	01-062	14
CAB INSTALL	01-062	12
CAB INSTALL	01-062	13
CAB INSTALL	01-062	09
CAB INSTALL	01-062	07
CAB INSTALL	01-062	08
CAB INSTALL	01-062	05
CAB INSTALL	01-062	06
CAB INSTALL	01-062	04
CAB INSTALL	01-062	03
CAB INSTALL	01-062	02
CAMSHAFT AND IDLE GEAR	08-016	00
CLAMP ASSY	01-049	03
CONNECTOR ASSY (NIBBLER & BREAKER)	03-012	00
CONTROL LINES, BLOCK	01-040	01
CONTROL LINES, BLOCK	01-040	02
CONTROL LINES, BLOCK (1PEDAL)	01-042	00
CONTROL LINES, BLOCK (HAND CONTROL)	01-041	02
CONTROL LINES, BLOCK (HAND CONTROL)	01-041	01
CONTROL LINES, MAIN	01-027	02
CONTROL LINES, MAIN	01-027	01
CONTROL LINES, MAIN (TANK PLUG LESS)	01-028	02
CONTROL LINES, MAIN (TANK PLUG LESS)	01-028	01
CONTROL LINES, MULTI	01-039	02
CONTROL LINES, MULTI	01-039	03
CONTROL LINES, MULTI	01-039	01
CONTROL LINES, PROPEL	01-038	01
CONTROL LINES, PUMP	01-037	00
CONTROL LINES, REMOTE	01-034	01
CONTROL LINES, REMOTE (NIBBLER & BRAKER, HAND CONTROL)	01-036	01
CONTROL LINES, REMOTE (NIBBLER & BRAKER, HAND CONTROL)	01-036	02
CONTROL LINES, REMOTE (NIBBLER & BREAKER)	01-035	01
CONTROL LINES, VALVE (BOOM ARM SAFETY)	01-030	00

MidWestTech | Kobelco SK350-9 Acera Mark 9 Tier IV Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

CONTROL LINES, VALVE (BOOM SAFETY)	01-033	00
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	02
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	01
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-031	03
CONTROL LINES, VALVE (ROTARY NIBBLER & BREAKER, HAND CONTROL)	01-032	04
CONTROL LINES, VALVE (ROTARY NIBBLER & BREAKER, HAND CONTROL)	01-032	05
CONTROL LINES, VALVE (ROTARY NIBBLER & BREAKER, HAND CONTROL)	01-032	06
CONTROL LINES, VALVE (ROTARY NIBBLER & BREAKER, HAND CONTROL)	01-032	01
CONTROL LINES, VALVE (ROTARY NIBBLER & BREAKER, HAND CONTROL)	01-032	02
CONTROL LINES, VALVE (ROTARY NIBBLER & BREAKER, HAND CONTROL)	01-032	03
CONTROL LINES, VALVE (ROTARY, HAND CONTROL)	01-029	06
CONTROL LINES, VALVE (ROTARY, HAND CONTROL)	01-029	05
CONTROL LINES, VALVE (ROTARY, HAND CONTROL)	01-029	02
CONTROL LINES, VALVE (ROTARY, HAND CONTROL)	01-029	01
CONTROL VALVE	07-006	06
CONTROL VALVE	07-006	05
CONTROL VALVE	07-006	02
CONTROL VALVE	07-006	03
CONTROL VALVE	07-006	04
CONTROL VALVE	07-006	01
CONTROLLER INSTALL	01-055	01
CONTROLLER INSTALL	01-055	02
CONTROLLER INSTALL (STD, HAND CONTROL)	01-056	01
CONTROLLER INSTALL (STD, HAND CONTROL)	01-056	02
CONTROLS, OPERATORS (1PEDAL, N&B)	01-049	02
CONTROLS, OPERATORS (1PEDAL, N&B)	01-049	01
CONTROLS, OPERATORS [0PEDAL, N&B(HC)]	01-051	05
CONTROLS, OPERATORS [0PEDAL, N&B(HC)]	01-051	02
CONTROLS, OPERATORS [0PEDAL, N&B(HC)]	01-051	03
CONTROLS, OPERATORS [0PEDAL, N&B(HC)]	01-051	04
CONTROLS, OPERATORS [0PEDAL, ROTARY(HC) & N&B(HC)]	01-052	04
CONTROLS, OPERATORS [0PEDAL, ROTARY(HC) & N&B(HC)]	01-052	05
CONTROLS, OPERATORS [0PEDAL, ROTARY(HC) & N&B(HC)]	01-052	02
CONTROLS, OPERATORS [0PEDAL, ROTARY(HC) & N&B(HC)]	01-052	03
CONTROLS, OPERATORS [0PEDAL, ROTARY(HC)]	01-050	03
CONTROLS, OPERATORS [0PEDAL, ROTARY(HC)]	01-050	04
CONTROLS, OPERATORS [0PEDAL, ROTARY(HC)]	01-050	02
CONTROLS, OPERATORS [1PEDAL(N&B), ROTARY(HC)]	01-053	05
CONTROLS, OPERATORS [1PEDAL(N&B), ROTARY(HC)]	01-053	04
CONTROLS, OPERATORS [1PEDAL(N&B), ROTARY(HC)]	01-053	02
CONTROLS, OPERATORS [1PEDAL(N&B), ROTARY(HC)]	01-053	03
CONTROLS, OPERATORS [2PEDAL(RN&B)]	01-054	03
CONTROLS, OPERATORS [2PEDAL(RN&B)]	01-054	04
CONTROLS, OPERATORS [2PEDAL(RN&B)]	01-054	05
CONTROLS, OPERATORS [2PEDAL(RN&B)]	01-054	02
COOLING SYSTEM	08-030	00
COUNTERWEIGHT INSTALL	01-003	00
COVER ASSY, UNDER	01-073	00
CYLINDER BLOCK	08-001	02
CYLINDER BLOCK	08-001	01
CYLINDER HEAD	08-006	01
CYLINDER HEAD	08-006	03

Order the manual at mid-west-tech.com >

CYLINDER HEAD	08-006	04
CYLINDER HEAD	08-006	02
CYLINDER INSTALL (ARM)	03-030	02
CYLINDER INSTALL (ARM)	03-030	01
CYLINDER INSTALL (BOOM)	03-029	02
CYLINDER INSTALL (BOOM)	03-029	01
CYLINDER INSTALL (BUCKET)	03-031	02
CYLINDER INSTALL (BUCKET)	03-031	01
ELECTRICAL ASSY, UPPER	01-078	02
ELECTRICAL ASSY, UPPER	01-078	01
ELECTRICAL PARTS (ENGINE)	08-012	06
ELECTRICAL PARTS (ENGINE)	08-012	02
ELECTRICAL PARTS (ENGINE)	08-012	03
ELECTRICAL PARTS (ENGINE)	08-012	01
ELECTRICAL PARTS (ENGINE)	08-012	04
ELECTRICAL PARTS (ENGINE)	08-012	05
ENGINE ACCESSORY PARTS	08-008	05
ENGINE ACCESSORY PARTS	08-008	03
ENGINE ACCESSORY PARTS	08-008	01
ENGINE ACCESSORY PARTS	08-008	04
ENGINE ACCESSORY PARTS	08-008	06
ENGINE ACCESSORY PARTS	08-008	02
ENGINE CONTROL SYSTEM	08-010	00
ENGINE INSTALL	01-005	01
ENGINE INSTALL	01-005	02
FILTER LIST	00-001	00
FRAME ASSY, LOW	02-002	00
FRAME GROUP, UPPER	01-002	00
FRAME, UPPER	01-001	00
FUEL LINES	01-012	00
FUEL SYSTEM	08-017	02
FUEL SYSTEM	08-017	01
FUEL SYSTEM	08-017	04
FUEL SYSTEM	08-017	03
FUEL TANK INSTALL	01-013	02
FUEL TANK INSTALL	01-013	01
GASKET KIT (ENGINE OVERHAUL)	08-007	00
GEAR PUMP	07-003	00
GUARD INSTALL	01-069	01
GUARD INSTALL	01-069	02
GUARD INSTALL	01-069	10
GUARD INSTALL	01-069	09
GUARD INSTALL	01-069	08
GUARD INSTALL	01-069	07
GUARD INSTALL	01-069	06
GUARD INSTALL	01-069	05
GUARD INSTALL	01-069	04
GUARD INSTALL	01-069	03
HARNESS ASSY, BOOM	03-004	00
HARNESS ASSY, CAB	01-088	00
HARNESS ASSY, CAB (HAND CONTROL)	01-089	01
HARNESS ASSY, CAB (HAND CONTROL)	01-089	02
HARNESS ASSY, CAB (HAND CONTROL)	01-089	03
HARNESS ASSY, UPPER	01-082	02
HARNESS ASSY, UPPER	01-082	01
HARNESS ASSY, UPPER	01-084	02
HARNESS ASSY, UPPER	01-084	03
HARNESS ASSY, UPPER	01-084	01

Order the manual at mid-west-tech.com >