KOBELCO®

PARTS CATALOG

SK260-9 Acera Mark 9
Excavator Tier IV

APPLICABLE
ASN LL14U1700

LQ91Z00016P1
Issued 4/2011

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
AIR CLEANER & INTAKE PARTS	01-005	01
AIR CONDITIONER INSTALL	01-068	01
AIR CONDITIONER INSTALL	01-068	02
AIR CONDITIONER INSTALL	01-068	03
ALTERNATOR (4892317 - 504328894)	09-038	00
ARM (LONG REACH)	03-010	02
ARM ASSEBMLY	03-010	01
ARM GROUP	03-009	01
ARM GROUP (LONG REACH)	03-009	03
ARM GROUP (SHORT)	03-009	02
ARM INST (STD)	03-008	00
ARM INST'L (LONG REACH)	03-008	02
ARMREST	01-034	00
BATTERY ASSY	01-067	00
BOOM - ASSY	03-001	00
BOOM - ASSY	03-001	02
BOOM - GROUP	03-002	00
BOOM - MOUNTING	03-003	00
BOTTOM ROLLER ASSEMBLY, H&W, H.D	02-003	02
BUCKET - INSTALLATION	03-014	01
BUCKET INSTAL (LONG REACH)	03-014	02
CAB - DOOR ASSY	01-054	08
CAB - DOOR WINDOW	01-054	09
CAB - HARNESS ASSY	01-054	05
CAB - HARNESS ASSY	01-054	12
CAB - LIGHT INSTAL	01-054	13
CAB - RADIO	01-054	11
CAB - SEAL ASSY	01-054	06
CAB - WINDOW ASSY, FR	01-054	14
CAB - WINDOW ASSY, FR	01-054	15
CAB - WINDOW, ROOF	01-054	07
CAB - WIPER INSTAL	01-054	10
CAB ASSY	01-054	01
CAB ASSY	01-054	02
CAB ASSY	01-054	03
CAB ASSY, GLASS	01-054	04
CAB GUARD ASSY	01-056	01
CAB GUARD ASSY	01-056	02
CAB GUARD ASSY	01-056	03
CAB INSTAL	01-052	00
CAMSHAFT - TIMING CONTROL (504345141)	09-016	00
CLAMP ASSY	01-035	00
CONDITIONER, AIR	01-069	01
CONDITIONER, AIR	01-069	02
CONTROL BOX ASSY	01-039	00
CONTROL LINES, (MULTI)	01-021	00
CONTROL LINES, BLOCK	01-022	00
CONTROL LINES, MAIN	01-016	00
CONTROL LINES, MULTI	01-033	00
CONTROL LINES, PROPEL	01-020	00
CONTROL LINES, PUMP	01-031	00
CONTROL LINES, REMOTE (N&B HAND)	01-029	00
CONTROL LINES, REMOTE (NIBBLER & BREAKER - FOOT)	01-030	00
CONTROL LINES, REMOTE (SENSOR)	01-019	00
CONTROL LINES, REMOTE (SINGLE PEDAL TRAVEL)	01-032	00
CONTROL LINES, VALVE	01-026	01

MidWestTech | Kobelco SK260-9 Acera Mark 9 Tier IV Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

CONTROL LINES, VALVE	01-026	02
CONTROL LINES, VALVE (N&B W/ ROTATION)	01-028	01
CONTROL LINES, VALVE (N&B W/ROTATION)	01-028	02
CONTROL LINES, VALVE (NIBBLER & BREAKER)	01-027	00
CONTROLLER INSTAL	01-044	00
CONTROLS, OPERATORS	01-040	01
CONTROLS, OPERATORS	01-040	02
COUNTERWEIGHT INSTALLATION	01-002	00
COVER ASSEBMLY, UNDER	01-063	00
COVER ASSEMBLY, UNDER (YN24CU0002F1)	02-012	00
CRANKCASE COVERS (4894734)	09-008	00
CRANKCASE COVERS (504038705)	09-009	00
CRANKCASE COVERS (504350260)	09-010	00
CYLINDER - MOUNTING	03-004	00
CYLINDER ASSY, ARM	08-004	00
CYLINDER ASSY, BOOM	08-003	00
CYLINDER ASSY, BUCKET	08-005	00
CYLINDER ASSY, BUCKET (LONG REACH)	08-005	01
CYLINDER HEAD (504115961)	09-004	00
CYLINDER HEAD COVERS (504327543)	09-005	00
CYLINDER INSTAL, BUCKET (LONG REACH)	03-012	02
CYLINDER, INSTAL (BUCKET)	03-012	01
ELECTRICAL ASSY, UPPER	01-066	00
ELECTRONIC INJECTION (504092213)	09-039	00
ENGINE ASSY (504386129)	09-001	00
ENGINE BREATHERS (504331902)	09-006	00
ENGINE OIL SUMP (504010891)	09-007	00
EXHAUST MANIFOLD (504088265)	09-027	00
FAN DRIVE (504243628 - 504226781 - 504243503)	09-035	00
FLYWHEEL - ENGINE (504229874)	09-012	00
FRAME - LOWER	02-001	01
FRAME - LOWER (HIGH&WIDE)	02-001	03
FRAME - UPPER INSULATION	01-001	03
FRAME - UPPER INSULATION	01-001	04
FRAME GROUP, UPPER	01-001	00
FUEL FILTER (504135694)	09-019	00
FUEL LINES	01-007	01
FUEL LINES	01-007	02
FUEL TANK INSTALLATION	01-008	01
GUARD ASSY, CAB	01-053	00
GUARD INSTALLATION, (HOOD)	01-059	00
GUARD INSTALLATION, (INSIDE)	01-061	00
GUARD INSTALLATION, (PARTITION)	01-062	00
GUARD INSTALLATION, (SIDE PANEL)	01-060	00
HARNESS ASSY, FLASHER AND ALARM	01-075	01
HARNESS ASSY, FLASHER AND ALARM	01-075	02
HARNESS ASSY, UPPER	01-073	01
HARNESS ASSY, UPPER	01-073	02
HARNESS ASSY, UPPER	01-073	03
HARNESS ASSY, UPPER (FLOOR PLATE)	01-074	01
HARNESS ASSY, UPPER (FLOOR PLATE)	01-074	02
HEAT EXCHANGER - ENGINE (504096820 - 500396329)	09-034	00
HOOKS - ENGINE (504121114)	09-003	00
HYD LINES, RETURN	01-025	01
HYD LINES, RETURN	01-025	02
HYD LINES, UPPER (NIBBLER & BREAKER)	01-023	00
HYDRAULIC LINE - DRIVE STD & H&W	02-009	01
HYDRAULIC LINE - LOWER	02-008	01

Order the manual at mid-west-tech.com >

HYDRAULIC LINE - LOWER (H&W)	02-008	02
HYDRAULIC LINES - SHORT ARM	03-011	03
HYDRAULIC LINES UPPER (BASE)	01-017	00
HYDRAULIC LINES UPPER (STANDARD)	01-018	00
HYDRAULIC LINES, ARM	03-011	01
HYDRAULIC LINES, ARM (2 WAY)	03-015	00
HYDRAULIC LINES, ARM (LONG REACH)	03-011	04
HYDRAULIC LINES, ARM (STD W/ROT + N&B)	03-016	02
HYDRAULIC LINES, ARM (STD W/ROT + N&B)	03-016	01
HYDRAULIC LINES, BOOM	03-005	00
HYDRAULIC LINES, BOOM (LONG REACH)	03-007	00
HYDRAULIC LINES, CYLINDER (BUCKET)	03-013	01
HYDRAULIC LINES, CYLINDER (BUCKET) LONG REACH	03-013	03
HYDRAULIC LINES, CYLINDER (BUCKET) SHORT ARM	03-013	02
HYDRAULIC LINES, PUMP	01-014	00
HYDRAULIC LINES, SWIVEL	01-015	00
HYDRAULIC LINES, UPPER (ROTATION)	01-024	00
HYDRAULIC LINES,BOOM (ROT)	03-006	00
HYDRAULIC TANK ASSEMBLY	01-010	00
IDLER	02-006	01
IDLER - ASSY	02-005	02
IDLER - ASSY H&W	02-005	01
IDLER H&W	02-006	02
INJECTION EQUIPMENT - INJECTOR (504129392)	09-021	00
INJECTION EQUIPMENT - PIPING (504324976)	09-020	01
INJECTION PUMP (504041280)	09-022	00
INSULATION INSTAL	01-055	00
INTAKE MANIFOLD - ENGINE AIR INTAKE (504114394 - 504165154)	09-025	00
INTAKE MANIFOLD - HEATER (504116855)	09-026	00
ISL LIST A	00-001	00
ISL LIST B	00-002	00
JOINT ASSEMBLY, SWIVEL	08-001	00
LEVER ASSY, PROPEL	01-037	00
LIGHT INSTAL, BOOM	01-072	00
LIGHT INSTAL, UPPER	01-070	00
MIRROR INSTALLATION, CAB	01-051	00
MOTOR ASSEMBLY, PROPELLING	08-017	02
MOTOR ASSEMBLY, PROPELLING	08-017	03
MOTOR ASSEMBLY, PROPELLING	08-017	04
MOTOR ASSEMBLY, PROPELLING	08-017	01
MOTOR ELECTRIC INSTALLATION (504369519)	09-036	00
MUFFLER ASSEMBLY	01-006	00
NAME PLATE INSTALLATION, (CAB WARNING) LABEL	06-003	01
NAME PLATE INSTALLATION, (CAB WARNING) LOCATION	06-003	00
NAME PLATE INSTALLATION, (EXTERIOR) LABEL	06-008	00
NAME PLATE INSTALLATION, (EXTERIOR) LOCATION,	06-009	02
NAME PLATE INSTALLATION, (EXTERIOR) LOCATION,	06-009	01
NAME PLATE INSTALLATION, (NIBBLER & BREAKER) LABEL	06-005	01
NAME PLATE INSTALLATION, (NIBBLER & BREAKER) LOCATION	06-005	00
NAME PLATE INSTALLATION, (PATTERN CHANGER CAB)	06-004	01
NAME PLATE INSTALLATION, (PATTERN CHANGER CAB) LOCATION	06-004	00
NAME PLATE INSTALLATION, BOOM	06-007	00
NAME PLATE INSTALLATION, LOCATION	06-006	00
NAMEPLATE INSTAL (LIFT CHARTS)	06-001	00
NAMEPLATE INSTALL, LIFT CHARTS (H&W)	06-002	00
OIL LEVEL CHECK (504310590 - 504088054)	09-028	00
OIL PUMP - ENGINE (504099881)	09-029	00
PANEL ASSY, INSTRUMENT	01-064	01

Order the manual at mid-west-tech.com >