TEREX
LIGHT CONSTRUCTION

SERIES LT7000
LIGHT TOWER
OPERATION/SERVICE & PARTS MANUAL

amida
Bartell
Benford
COLEMAN Engineering
morrison
MULLER

PO Box 3147 • Rock Hill, SC 29732 USA Phone 803-324-3011
Toll Free 800-433-3026 Parts Department Fax 800-633-5534

MidWestTech | Terex LT7000 Light Tower Parts Manual | Publication LT7
Order the manual at mid-west-tech.com >

TABLE OF CONTENTS



WARNING!!! READ OPERATING,TROUBLESHOOTING,AND

CAUTION!!!! MAINTENANCE INSTRUCTIONS CAREFULLY BEFORE OPERATING THIS PIECE OF EQUIPMENT.

OPERATING INSTRUCTIONS AND MAINTENACE

Safety Precautions	Page 5-6
Initial Set Up	Page 7
Model Coding System	Page 8
Operating Instructions	Page 9-13
Oil & Fuel Specifications	Page 14-15
Engine (See manufacturer's handbook)	
Generator (See manufacturer's handbook)	

PARTS DRAWINGS AND LISTS

9055	Axle w/wheels	Page 17
9109B	Air Chamber - For unit with Lister Engine	Page 18-19
9366	Air Chamber - For unit with LPA3	Page 20-21
9062A	Crossarm w/wiring 4 lights	Page 22-23
9063A	Crossarm w/wiring 6 lights	Page 24-25
9065C	Engine & Generator - Lister TS2 - Leroy Somer 8 KW	Page 26-27
9365	Engine & Generator - Lister LAP3 - Leroy Somer 7.5 KW	Page 28
N/A	Engine & Generator - Kubota 1105- Leroy Somer 8 KW	Page 29
9069	Trailer Frame and Parts	Page 30-31
9070B	Generator Enclosure	Page 32-33
9071	Tower and Base Assembly	Page 34-35
9072	Pivot Cylinder	Page 36-37
9073	Telescoping Cylinder	Page 38-39
9074A	Hydraulic Piping	Page 40-41
9123A	Electrical	Page 42-43
9075	CDC Control Box - For unit with Lister Engine	Page 44-45
9076	CDC Control Box - For unit with Kubota or Lister	Page 46-47
9528	CDC Control Box - For unit with Lister/Alpha	Page 48-49
9089	Hitches for trailers	Page 50
N/A	Ballast	Page 51
	Fixture Assembly	Page 52

MidWestTech | Terex LT7000 Light Tower Parts Manual | Publication LT7 Order the manual at mid-west-tech.com >

DRAWING# 9070B - LT7000 GENERATOR ENCLOSURE

ITEM #	PART #	DESCRIPTION
-001	123460	AS-CABINET FRONT 7000, 2347A
-002	184060	FP-CABINET SIDE, CURB-5 ROAD-7, 2329H, LT5&7000
-003	1232475	AS-CABINET REAR, LTS&7 TS2?,.KUBOTA, INSUL MUFF
-004	184050	FP-CABINET SIDE, ROAD-5 CUR B-7, 3043E, LT5&7000
-005	123990	AS-CABINET TOP, 5&7LTB W/INS, MUFFLER, 2995
-006	123480	AS-CABINET DOOR LT5&7000, 123490
-007	123490	AS-FENDERW/SKIRTLT5&7
-009	794860	HINGE, PIANG, 1.5X55.5
-010	794935	DOOR LATCH, RECESSED, ZP W/HASP,3-5900-P (25)
-011	794820	HINGE, PIANO, 1. 5X14. S 5/51 2434, LTS&7000
-012	184161	FP-DOOR FOR CONTROL BOX, 2357- LT5&7000
-013	184170	FP-RUBBER DOOR SEAL FLAP,2358, LT5&7000
-014	794845	LOCK,CAM FOR ELEC.BOX DOOR, AUTOHARDWARE#DL20
-015	184210	FP-ACOUSTIC FOAM, REAR, CURBSIDE, LTS&7000
-016	184200	FP-ACOUSTIC FOAM, REAR ROADSIDE, LT5&7000
-017	184190	FP-ACOUSTIC FOAM, FRONT RD. SIDE, LT5&7000, 2360C
-018	184180	FP-ACOUSTIC FOAM, DOOR LT5&7000
-019	186265	FP-ACOUSTIC FOAM CS/7 FRT,RS/S REAR, 2759
-020	186220	FP-ACOUSTIC FOAM RS/7 FRT,CS/S REAR, 2759
-021	176370	FP-LITERATURE RACK FOR CABINET,DWG# 1003, 5000
-022	684030	LIGHT,DOME,WITH SWITCH EA FOR GEN.ENCL.P/N 3905
-023	720430	WEATHERSTRIP,DOOR FT FLANGE, AU-VE-.CD#4675
-024	184195	FP-ACOUSTIC FOAM FRONT CB. SIDE,LT5/7000,2360C
-025	186270	FP-ACOUSTIC FOAM RS/7 REAR,CS/5 FRT,2760
-026	186275	FP-ACOUSTIC FOAM CS/7 REAR,RS/5 FRT,2760
-027	184205	FP-ACOUST I C FOAM REAR CENTER SECTION,LT5-700
-028	186350	FP-COVER PLATE, LT7000 EA FRONT PANEL, 2804
-029	186280	FP-PLATE,COIL CORD CAB MDUNT,2770,4000C
-030	186820	FP-PLATE,ELECTRICAL BOX COVER, 2989B, LT5--7

MidWestTech | Terex LT7000 Light Tower Parts Manual | Publication LT7 Order the manual at mid-west-tech.com >

DRAWING # 9123A ELECTRICAL, LT7000B

ITEM #	PART #	DESCRIPTION
-001	115930	EA-ELEC.BDX W/C-CORD 4MH,GF1,NBC,30A,7LTA
-002	115290	EA-ELEC.BOX W/C-CORD, 4MH, GFI I ND DC I 30A, 7LTA
-003	112555	EA-JUNCTION BOX,TOP OF TWF\,4MH/HPS.JOY
-004	186751	FP-CONTROL BOX FACE. 4MH,HPS W/GFI.3744.7B
-005	185390	FP-CONTROL BOX TOP 2501
-006	185370	FP-CONTROL BOX BOTTOM. 2499
-007	186790	FP-CONTROL BOX SIDE, FRONT,2970,7000B
-008	186801	FP-CONTROL BOX SIDE, REAR W/O HR.MTR ,3745
-009	186730	FP-CONTROL BOX REAR , 2964.7000B
-010	683680	BREAKER, 2P 30A 240V CS AA2-B0-26-630-2D1-C
-012	683870	BREAKER lP 15A 277VAC CS AA1-BO-24-615-2D1-C
-013	683870	BREAKER MINI lP 20A W/HEX PAL NUT
-014	684640	RECEPTACLE, 20A, 120V, DUPLEX W/GFI
-015	684450	RECEPTACLE, 30A, 240V T-LOCK,L6-30R,HUB 2620
-017	663890	CORD SET,FEMALE,6FT,5P 16AW G,JOY-5000111-4
-020	121620	AS-BOX WITH MOUNT BARS, W/7 1/2",HUBS.3b26
-021	663870	CONNECTOR,3P,FEMALE RECEPT,JOY-5000109-9
-022	663880	CAP FOR RECEPTICLE, W/CHAIN,JOY-3316582-1
-023	680080	GRIP,STRAIN RELIEF 1/2", KELLUM CQ410
-024	660287	CORD RETRACT/14/7,SOWA 66" COIL, 10&54" TAIL, STD
-025	683830	BREAKER 2P 15A 240V
-026	680240	SWITCH PB IP 800 TAIDI, CSAAPPROVED

MidWestTech | Terex LT7000 Light Tower Parts Manual | Publication LT7 Order the manual at mid-west-tech.com >

DRAWING # 9528 LT7000 CONTROL BOX W/ALPHA

ITEM #	PART #	DESCRIPTION
-001	114368	EA-ELECT. CDC BOX.4MHI HPS.ALPHA.NO DC.7LTA
-002	123-03	AS-EL. BOX.LT7000 WI ALPHA LPA3.4MH.4255
-003	114660	EA-RECEPTACLE.7-POLE W/18.'WIRES. CONT. BOX. LT
-004	684235	GASKET FOR RECEPTACLE 7 POLE.10-404-0-20
-005	663890	CORD SET.FEMALE.6FT.SP 16AW G.JOY-5000111-4
-006	685550	FREQUENCY METER 15PH-56. LT5&7000
-007	260360	HOURMETER 12V DC HOBBS 80048
-008	440140	AMMETER. 12V.-30 0 +30. DATCON
-009	684450	RECEPTACLE.30A.240V T-LOCK.L6-30R.HUB 2620
-010	683820	RECEPTACLE.30A.120V T-LOCK 3-WIRE HUB 2610
-011	683970	BREAKER MINI 1P 20A W/HEX PAL NUT
-012	684640	RECEPTACLE.20A.120V DUPLEX W/GFI
-013	440180	OIL PRES. EL. GAUGE 100P 12V. 06341-01 BLACK
-014	682715	LIGHT, INDICATOR 12V RED
-015	680240	SWITCH PB 1P 800 TAIDI CSAAPPVD
-016	184460	FP-EA. BOX, BACK PANEL 14X18,2333.LT5&7000
-017	683830	BREAKER 2P 15 240VCS AA2-BO-24-61S-2D1-C
-018	114700	EA-INDICATOR LIGHT.BALLAST OUT.440V.LT
-019	114690	EA-INDICATOR LIGHT, BALLAST INPUT LT5&7000
-020	683870	BREAKER 1P 15A 277VAC CS AA1-BO-24-615-2D1-C
-021	683680	BREAKER 2P 30-A 240VAC CS AA2 BO-26-630-2DI-C
-022	684680	SWITCH, IGNITION, LEVER OPERATED, P/N 31-607
-023	R660010	SWITCH, PUSH-BUTTON, W/BOOT, POLLACK 24-360

MidWestTech | Terex LT7000 Light Tower Parts Manual | Publication LT7 Order the manual at mid-west-tech.com >