OMPC30006194

Operation & Maintenance Manual

PC3000-1

HYDRAULIC MINING SHOVEL

SERIAL NUMBERS PC3000-1 6194

July 2006

KOMATSU®

MidWestTech | Komatsu PC3000-1 Hydraulic Mining Shovel Operation & Maintenance Manu... Order the manual at mid-west-tech.com >

SECTION	SUBJECT	PAGE
A	Explanation of Abbreviations	1
1.0	Foreword	1
2.0	Construction of the Excavator	1-6
2.1	Catwalk in front of the Operator's Cab	1
3.0	Safety Instructions	1-18
3.1	Ladder, Walkways and Access Doors	1
3.3	Emergency Engine Shutdown from Ground Man	1
3.4	Operator's Cab	1
3.5	Operator's Seat	1
4.0	Operator's Cab, Controls	1-5
5.0	Electronic Text and Monitoring System ETM	1-32
5.1	Power House Controls	1-2
5.2	Main Switch Board in Cab Base	1
5.3	Preheating Systems	1-5
5.5	Generator Set	1-5
6.1	Before starting the Engine	1-2
6.2	Starting the Engine	1-5
6.3	Stopping the Engine	1-2
6.4	Moving the Excavator	1-4
6.5	Slewing and Braking the Superstructure	1-2
6.6	Working with the Attachment	1-5
6.7	Combined Operation Cycles	1
6.8	Operating the Heater and Air Conditioning	1-2
6.11	Operating the Lubrication Systems	1-4
6.13	Fire Detection and Suppression System	1-4
7.0	Working Instructions	1-3
8.0	Parking the Excavator	1
9.0	Central Refilling System	1-5
9.1	Service Crane for Grease Barrels	1-3
10.0	Exchange of Attachment and/or Components	1
11.0	Transportation and Lifting of Excavator Main Components	1
12.0	Retrieval Procedure	1

MidWestTech | Komatsu PC3000-1 Hydraulic Mining Shovel Operation & Maintenance Manu... Order the manual at mid-west-tech.com >