OMPC30006202

Operation & Maintenance Manual

PC3000-1

HYDRAULIC MINING EXCAVATOR

SERIAL NUMBERS PC3000-1 6202

July 2006

KOMATSU®

MidWestTech | Komatsu PC3000-1 Hydraulic Mining Excavator Operation & Maintenance M... Order the manual at mid-west-tech.com >

SECTION	SUBJECT	PAGE
A	Explanation of Abbreviations	1
1.0	Foreword	1
2.0	Construction of the Excavator	1-4
3.0	Safety Instructions	1-18
3.1	Ladder, Walkways and Access Doors	1-2
3.2	Transport of the Excavator	1
3.3	Operator's Seat	1
4.0	Operator's Cab, Controls and Monitors	1-4
5.0	Operator's Cab, Electronic Text Monitoring System ETM	1-31
5.1	Power House Controls	1-2
5.2	Electrical Equipment in the Cab Base	1-3
5.3	Preheating System for Hydraulic Oil	1
5.4	Engine Oil Management System	1-5
5.5	Operator's Cab, Arrangement of Components	1
6.1	Checks before starting the Engine	1-2
6.2	Starting the Engine	1-5
6.3	Stopping the Engine	1
6.4	Pontoon Operation	1-3
6.5	Slewing and Braking the Superstructure	1-2
6.6	Working with the Attachment	1-2
6.7	Combined Operation Cycles	1
6.8	Operating the Heater and Air Conditioning	1-2
6.9	Not used	--
6.10	Not used	--
6.11	Operating the Lubrication Systems	1-2
6.12	Not used	--
6.13	Fire Detection, Actuation and Suppression System	1-4
6.14	Not used	--
6.15	Transfer Pump for hydraulic oil reservoir	1-3
7.0	Working Instructions	1-3
7.1	Emergency Operation	1
8.0	Not used	--
9.0	Refueling the Excavator	1
10.0	Exchange of Attachment and / or Components	1

MidWestTech | Komatsu PC3000-1 Hydraulic Mining Excavator Operation & Maintenan... Order the manual at mid-west-tech.com >