Model No. _____

Serial No. _____

RM/RMD 6000S Series

Service & Parts Manual



Crown 2001 PF17911 Rev. 1/11

Re-Printed in U.S.A.

MidWestTech | Crown RM, RMD 6000S Series High Reah Forklift Service Manual & Parts C... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

SAFETY	PAGE
General Maintenance Instructions	3
Cleaning of Material Handling Equipment	5
Cleaning Procedures	5
Control of Hazardous Energy	7
Lockout/Tagout	7
Battery	7
Safety Procedures	7
Battery Maintenance	7
Battery Charging	8
Battery Removal	8
Battery Installation	8
Lockout/Tagout Procedures	8
Lockout/tagout procedures for the truck	8
To do maintenance on the truck (with the battery in the truck)	9
To do maintenance on the truck (with the battery out of the truck)	9
Capacitance	9
Discharge the capacitors	9
Hydraulic	10
Releasing the Brakes	11
Access 123 UTILITIES Menu Brake Release Procedure	11
Brake Release Service Tool Procedure	11
Connect the brake release service tool	11
Release the brakes	11
Apply the brakes	11
Disconnect the brake release service tool	12
Mechanical Brake Release Procedure	12
Towing Truck	12
Towing by Pulling in Power Unit First Direction	12
Prepare Truck for Towing:	13
Towing Device Requirements:	13
Towing Guidelines:	13
Towing by Pulling in the Forks First Direction	13
Towing by Lifting Truck and Pulling in Power Unit First Direction	13
Prepare Truck for Towing:	13
Towing Device Requirements:	13
Towing Guidelines:	13
Towing by Lifting Truck and Pulling in the Forks First Direction	14
Lifting and Blocking	14
Mast and Fork Carriage	15
Blocking Masts	15
Reach Mechanism	17
Tilt	17
Mast Removal	18

MidWestTech | Crown RM, RMD 6000S Series High Reah Forklift Service Manual & Pa... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

INTRODUCTION	PAGE
Introduction	**21**
Operator Instructions	21
Operator Training	21
Service Training	21
Replacement Parts	21

INSPECTION AND LUBRICATION	PAGE
Operator's Daily Checklist	**27**
Lubricants, Aerosols & Service Supplies	**29**
Planned Maintenance	**35**
Overview	35
Component Access	36
Power Unit Console	37
Knee Pad and Upper Pedal Assembly	37
Seat Covers and Floorboard	37
Floorboard	37
Upper Foot Rest	37
Power Unit Traction Motor Compartment Door	37
Front Left Hand Power Unit Compartment	37
Front Right Hand Power Unit Compartment	38
Lubrication	38
Metric Torque Values	**55**
Grade	55
SAE Torque Values	**59**
Grade	59

COMPONENTRY	PAGE
Componentry	**63**
Audible Indicators	**64**
ALM1	64
ALM2	64
HN	64
Contactors	**66**
ED1	66
ED2	66
Encoders	**66**
ECR1	66
ECR2	66
ECR4	68
ECR5	68
ECR6	70
ECR8	70
Fans	**70**
FAN1	70
FAN3	70
FAN5	72
FAN7	72
Fuses	**74**
FU1	74
FU2	74
FU3	74
FU4	74

MidWestTech | Crown RM, RMD 6000S Series High Reah Forklift Service Manual & Pa... Order the manual at mid-west-tech.com >