KOBELCO

PARTS CATALOG

EXCAVATOR

SK60-IV

S3LEJ0001 NA

Issued 01Mar07

APPLICABLE:
SK60-IV . . . . . LEJ0201~

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001		FILTER LIST
00-002		NUT AND SLEEVE
00-003		FRAME ASSY, UPPER 24100J14505F1
00-004		COUNTER-WEIGHT ASSY 24100N6395F3 & F4
00-005		MOTOR ASSY, SWING 24100J11943F2
00-006		TANK ASSY 24100J14508F1
00-007		TANK ASSY 24100J14508F2
00-008		TANK ASSY (FOR KAI) 24100J14508F3
01-001		INSTALL, CAB 24100N7404F2
01-002		INSTALL, CAB (FOR SOUTHEAST ASIA) 24100N7404F10
01-003		INSTALL, CAB (FOR SOUTHEAST ASIA) 24100N7404F19
01-004		INSTALL, CAB (FOR NORTH EUROPE) 24100N7404F4
01-005		INSTALL, CAB (FOR KAI) 24100N7463F2
01-006		INSTALL, CAB (FOR EUROPE) 24100N7753F2
01-007	01	CAB ASSY 24100J14396F1
01-008	01	CAB ASSY (FOR SOUTHEAST ASIA) 24100J14396F5
01-008	02	CAB ASSY (FOR SOUTHEAST ASIA) 24100J14396F5
01-009	01	CAB ASSY (FOR SOUTHEAST ASIA) 24100J14396F19
01-009	02	CAB ASSY (FOR SOUTHEAST ASIA) 24100J14396F19
01-010	01	CAB ASSY (FOR NORTH EUROPE) 24100J14396F2
01-010	02	CAB ASSY (FOR NORTH EUROPE) 24100J14396F2
01-011	01	CAB ASSY (FOR KAI) 24100J14396F9
01-011	02	CAB ASSY (FOR KAI) 24100J14396F9
01-012	01	CAB ASSY (FOR EUROPE) 24100J14396F15
01-012	02	CAB ASSY (FOR EUROPE) 24100J14396F15
01-013		INSTALL, MIRROR (FOR NORTH EUROPE) 24100P4126
01-014		PLATE ASSY, FLOOR 24100J14323F1
01-015		PLATE ASSY, FLOOR (FOR EXPORT) 24100J14655F2
01-016		SEAT ASSY 24100N7360F1
01-017		SEAT ASSY 24100N7703F2
01-018		SEAT ASSY (FOR KAI) 24100N7703F1
01-019		SEAT ASSY 2448U251F1
01-020		SEAT ASSY (FOR NORTH EUROPE) 2448U167F1
01-021	01	GUARD ASSY 24100J14314F1
01-021	02	GUARD ASSY 24100J14314F1
01-022	01	GUARD ASSY (FOR NORTH EUROPE) 24100J14314F2 & F5
01-022	02	GUARD ASSY (FOR NORTH EUROPE) 24100J14314F2 & F5
01-023	01	GUARD ASSY (FOR EXTREME HEAT) 24100J14314F3
01-023	02	GUARD ASSY (FOR EXTREME HEAT) 24100J14314F3
01-024		COVER ASSY, UNDER
01-025		COVER ASSY, UNDER (FOR NORTH EUROPE) 24100J12927F1
02-008		LEVER ASSY, CONTROL 24100N7446F1
02-001	01	CONTROL ASSY 24100J14309F1
02-001	02	CONTROL ASSY 24100J14309F1
02-002	01	CONTROL ASSY (WRIST) (FOR EXPORT) 24100J14656F1
02-002	02	CONTROL ASSY (WRIST) (FOR EXPORT) 24100J14656F1
02-003	01	REMOTE-CONTROL ASSY 24100J14317F2
02-003	02	REMOTE-CONTROL ASSY 24100J14317F2
02-003	03	REMOTE-CONTROL ASSY 24100J14317F2
02-004	01	REMOTE-CONTROL ASSY (FOR SOUTHEAST ASIA) 24100J14317F3
02-004	02	REMOTE-CONTROL ASSY (FOR SOUTHEAST ASIA) 24100J14317F3

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-004	03	REMOTE-CONTROL ASSY (FOR SOUTHEAST ASIA) 24100J14317F3
02-005	01	REMOTE-CONTROL ASSY (WRIST) (FOR EXPORT) 24100J14384F1
02-005	02	REMOTE-CONTROL ASSY (WRIST) (FOR EXPORT) 24100J14384F1
02-005	03	REMOTE-CONTROL ASSY (WRIST) (FOR EXPORT) 24100J14384F1
02-006		REMOTE-CONTROL ASSY (FOR KAI) 24100J14384F2
02-007		REWORK, CONTROL ASSY (SWING LOCK) (FOR SWEDEN) 24100J14750F1
02-009	01	REMOTE-CONTROL ASSY (MULTI) 24100J14317F1
02-010		LEVER ASSY, CONTROL (FOR EXPORT) 24100N7501F1
03-001	01	HYDR LINES, UPPER 24100J14931F1
03-001	02	HYDR LINES, UPPER 24100J14931F1
03-002	01	HYDR LINES, UPPER (FOR EXPORT) 24100J14931F2
03-002	02	HYDR LINES, UPPER (FOR EXPORT) 24100J14931F2
04-001		POWER-PLANT ASSY 24100J14455F1
04-002		POWER-PLANT ASSY (FOR SOUTHEAST ASIA) 24100J14455F2, F3
04-003		ENGINE ASSY 2451U340F1
04-004		RADIATOR ASSY 2452U424F1
04-005		PUMP ASSY, CONNECT 24100N6332F3
04-006		NET, WIRE (FOR NORTH EUROPE) 2427U1395F1
04-007		CONTROL ASSY, ENGINE 24100J14528F1
04-008	01	PANEL ASSY, INST (FOR EXPORT) 24100J14583F1
04-008	02	PANEL ASSY, INST (FOR EXPORT) 24100J14583F1
04-008	03	PANEL ASSY, INST (FOR EXPORT) 24100J14583F1
04-009	01	PANEL ASSY, INST (FOR SOUTHEAST ASIA) 24100J14524F3
04-009	02	PANEL ASSY, INST (FOR SOUTHEAST ASIA) 24100J14524F3
04-009	03	PANEL ASSY, INST (FOR SOUTHEAST ASIA) 24100J14524F3
04-010	01	PANEL ASSY, INST (FOR EXPORT) 24100J14524F2
04-010	02	PANEL ASSY, INST (FOR EXPORT) 24100J14524F2
04-010	03	PANEL ASSY, INST (FOR EXPORT) 24100J14524F2
04-011	01	PANEL ASSY, INST (FOR NORTH EUROPE) 24100J14616F1
04-011	02	PANEL ASSY, INST (FOR NORTH EUROPE) 24100J14616F1
04-011	03	PANEL ASSY, INST (FOR NORTH EUROPE) 24100J14616F1
04-013	01	PANEL, ASSY, INST (FOR KAI) 24100J15209F1
04-013	02	PANEL, ASSY, INST (FOR KAI) 24100J15209F1
04-013	03	PANEL, ASSY, INST (FOR KAI) 24100J15209F1
04-014		CLUSTER, GAUGE 2489U276F1 APPLICABLE: LE14101-15864 & F3 15865 & UP
04-015		HEATER ASSY (FOR NEAR MIDDLE EAST) 24100N7430F2
04-016		HEATER ASSY (FOR CENTRAL SOUTH AMERICA) 24100N7764F1
04-017		CONDITIONER GROUP, AIR 24100J14390F1
04-018		CONDITIONER ASSY, AIR 24100U1415F2
04-019		PARTS KIT 24100Z146F2
04-020		UNIT, AIR-CONDITIONER 24100U1188F2
04-021		CASE ASSY 24100U1189F1
04-022		HEATER AND DEFROSTER (FOR EXPORT) 24100J14552F1
04-023		HEATER ASSY (FOR EXPORT) 24100J625F3
04-024		BOX ASSY 24100N7377F1 & F2
04-025		BOX ASSY (FOR EXPORT) 24100N6782F2
05-001		WIRING ASSY, ELEC 24100J14516F1
05-002		WIRING ASSY, ELEC (FOR NORTH EUROPE) 24100J14516F2
05-003		WIRING ASSY, ELEC (FOR KAI) 24100J14516F4
05-004		WIRING ASSY, ELEC (FOR EUROPE) 24100J14516F3
05-007		BATTERY ASSY 24100P1124F3,F4,F5

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05-008		LAMP ASSY 2456U106F5 (R.H.), F6 (L.H.)
05-009		LAMP ASSY 24100P3615F1,F2,F3
05-010		LIGHT ASSY, WORKING 2456U116F1,F2
05-011		LAMP ASSY 2456U103F1,F2
05-012		LIGHT ASSY, WORKING 2456U74F2,F3
06-001		INSTALL, LOW 24100J11969F3
06-002		INSTALL, LOW (FOR RUBBER CRAWLER) 24100J12583F2
06-003		IDLER ASSY (FOR RUBBER CRAWLER) 24100N6398F1
06-004		IDLER ASSY 24100N6296F1
06-005		ROLLER ASSY (LOWER) (FOR RUBBER CRAWLER) 24100N6734F1
06-006		ROLLER ASSY (LOWER) 24100N6398F1
06-007		ROLLER ASSY (UPPER) 24100N6291F1
06-008		ROLLER ASSY (LOWER) (FOR RUBBER CRAWLER) 24100N7775F1
06-009		SPRING ASSY, TRACK 24100N6295F2
06-010		ROLLER ASSY (UPPER) (FOR RUBBER CRAWLER) 24100N6510F1
06-011		SPRING ASSY, TRACK (FOR RUBBER CRAWLER) 24100N7447F1
06-012		HYDR LINES, LOW 24100J14382F1
06-013		INSTALL, CRAWLER TRACK 24100J11947F7
06-014		RUBBER, CRAWLER (FOR RUBBER CRAWLER) 24100P3561F1
07-001		BOOM ASSY, 3.7M 24100J14483F1
07-002		BOOM ASSY, 3.7M (FOR NORTH EUROPE) 24100J14483F2
07-003		BOOM ASSY, 3.7M (FOR NORTH EUROPE) 24100J14567F1 & F2
07-004	01	BOOM ASSY, 3.7M (FOR EUROPE) 24100J15309F1
07-004	02	BOOM ASSY, 3.7M (FOR EUROPE) 24100J15309F1
07-005		ARM ASSY, 1.73M 24100J14504F1
07-006		ARM ASSY, 1.73M (FOR NORTH EUROPE) 24100J14504F3
07-007		ARM ASSY, 1.73M (FOR KAI) 24100J14504F4
07-008		BUCKET ASSY, 0.25M{3} (FOR EXPORT) 24100N7424F3
05-005		INSTALL, VALVE (FOR EXPORT) 24100P3319F1
05-006		PUMP ASSY, FUEL 24100J13308F2
08-001		HEATER ASSY (FOR EXPORT) 24100N7430F3
08-002		GUARD ASSY, CAB (FOR KAI) 24100J13658F2
08-003		BELT ASSY, SEAT 24100N7338F1
08-004		REMOTE-CONTROL ASSY (FOR EUROPE) 24100N7780F1
08-005		REWORK, HYDR LINES (FOR NORTH EUROPE) 24100J13277F2
08-006		SWITCH ASSY, PRESSURE (FOR NORTH EUROPE) 24100P1818F1
08-007		REWORK, AIR CLEANER (FOR EXPORT) 2446U279F1
08-008		FAN ASSY, AUTOMOBILE (FOR EXTREME HEAT) 24100P3237F1
08-009		LIGHT, BOOM (FOR EXPORT) 24100P1655F4
08-010		KIT, CONVERTER (FOR KAI) 24053P1F1
08-011		ALARM ASSY (FOR KAI) 24100N7245F2
08-012		REWORK, LOW FRAME 2422N1554
08-013		REWORK, LOW FRAME (FOR NORTH EUROPE) 2422J3391
08-014		REWORK, LOW FRAME 2422P1294
793-32		LIGHT ASSY (FOR NORTH EUROPE) 24100P3290F1
09-001	01	BOOM ASSY, SEPARATE 24100J13226F1
09-001	02	BOOM ASSY, SEPARATE 24100J13226F1
09-002		ARM ASSY, 2.15M 24100J14580F1
09-003		ARM ASSY, 2.15M (FOR NORTH EUROPE) 24100J14580F3
09-004		ARM ASSY, 2.15M (FOR KAI) 24100J14580F4
09-005		ARM ASSY, EXTENSION 24100J13160F1

Order the manual at mid-west-tech.com >

CAB ASSY (FOR SOUTHEAST ASIA) 24100J14396F5

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
150		24100J11965S150		3	WASHER
158		2418R506D4		1	SEAL, RUBBER
164		2405R68		2	BUSHING
167		2414R445		1	COVER
168		2406R498		1	LEVER
169		2420R606D3		1	TUBE, RIGID
170		2429R237		1	GUIDE
171		2429R238		1	GUIDE
175		24100J14396S175		1	SPRING
176		2414R447		1	COVER
177		2432T6138		1	LABEL, APPLICABLE: LE17596-
179		{2445R390}		1	SEAL
180		{2418R614}		1	PLATE
181		{24100J14396S181}		2	SCREW
182		2405R306		1	BUSHING
183		24100J14396S183		2	CLAMP
188		24100J14396S188		2	SCREW
189		24100J14396S189		2	WASHER
304		{2427U1479D4}		1	CAB
304-15		2427U1347		1	DOOR
304-15C		2420Z1253		2	HINGE
304-15D		ZW16X10000		6	WASHER
304-15E		ZW26X10000		6	WASHER, LOCK
304-15F		ZS18C10025		6	SCREW
304-18		ZW16X10000		6	WASHER
304-19		ZW26X10000		6	WASHER, LOCK
304-20		ZN17C10008		6	NUT
		24100R169F1		1	CABIN DOOR

MidWestTech | Kobelco SK60-IV Excavator Parts Catalog | Publication S3LEJ0001 Order the manual at mid-west-tech.com >

CAB ASSY (FOR KAI) 24100J14396F9

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
72		24100J6107S14		2	NUT
73		24100J6107S15		2	WASHER
75		2420R578		1	GROMMET
76		2427U1191		1	HANDLE
77		24100J6284S75		4	CAPSCREW
78		2420U194D1		4	NUT
79		2418R506D3		2	SEAL, RUBBER
80		2418R277		11	SPACER
81		2418R604		3	SPACER
84		24100R271		1	WIRE
86		2416R279		2	HOLDER
87		24100J11965S87		4	SET SCREW
88		2418U415		1	SEAL, RUBBER
89		2418U415D2		1	SEAL, RUBBER
90		2416R462		2	HOLDER
91		24100J11965S167		4	SETSCREW
93		2427R1139		2	HANDLE
94		24100J11965S94		4	SCREW
95		2417U169D2		2	SPRING, GAS
96		24100J14396S96		4	RING
97		2416Z464		2	STOP
98		ZN18F10008		2	NUT
99		ZW16X10000		2	WASHER
100		2416U310		1	HOLDER
101		24100J6512S159		1	GLASS-RUN
102		24100J11965S102		4	SETSCREW
103		24100J11965S103		2	CHANNEL
106		24100J6512S143		1	SWITCH
107		24100J11965S168		2	SCREW, TAPPING
108		24100J11965S108		2	GASKET
109		24100J6512S115		2	SEAL
110		24100J6512S70		1	SEAL, RUBBER
112		2418R548D2		1	SEAL, RUBBER
113		2427R1133		2	RUBBER SLEEVE
114		2427U1188		2	STOPPER, RUBBER

MidWestTech | Kobelco SK60-IV Excavator Parts Catalog | Publication S3LEJ0001 Order the manual at mid-west-tech.com >

GUARD ASSY (FOR NORTH EUROPE) 24100J14314F2 & F5

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
28		2420T6788		6	SEMS-BOLT
29		ZS18C08025		4	SCREW
30		ZW26X10000		8	WASHER, LOCK
31		ZW26X08000		8	WASHER
32		2418T12346		8	WASHER
33		ZW16X10000		2	WASHER
34		ZW16H08000		4	WASHER
35		ZN18C10008		8	NUT
36		ZP16K02025		2	PIN, SPLIT (COTTER), PIN, SPLIT
37		ZW16X08000		4	WASHER
38		{2414N4913}		1	GUARD, APPLICABLE: LE14101-17595 F2 ONLY
39		{24100P3587F2}		1	COVER ASSY, APPLICABLE: LE14101-17595 F2 ONLY
39-1		2414N4908		1	COVER
39-1B		2420T4450		2	HINGE
39-2		2421T222		1	LOCK
39-5		{2479Z2702}		1	INSULATOR
39-6		2416Z650D1		1	RUBBER SLEEVE
40		24100P3588F2		1	COVER, COVER ASSY, APPLICABLE: LE14101-17595 F2 ONLY
40-1		2414N4911		1	COVER
40-1B		2420T4450		2	HINGE
40-2		2421T222		1	LOCK
40-5		{2479Z2704}		1	INSULATOR
40-6		{2416Z1099D10}		1	RUBBER, CUSHION
41		2427P3479		1	HANDRAIL, APPLICABLE: LE14101-17595 F5 ONLY
45		ZS18C08020		4	SCREW
46		2416Z631D12		1	RUBBER, CUSHION, APPLICABLE: LE17563-
47		{2416Z1156}		1	RUBBER, CUSHION, APPLICABLE: LE17563-
50		2427P4210		1	HANDLE, APPLICABLE: LE17624-
51		{24100P3268F3}		1	GUARD ASSY, APPLICABLE: LE17596-
52		{2414N5676}		1	GUARD, APPLICABLE: LE17596-

MidWestTech | Kobelco SK60-IV Excavator Parts Catalog | Publication S3LEJ0001 Order the manual at mid-west-tech.com >