KOBELCO®

PARTS CATALOG

SK80CS-2
Center Swing Excavator

APPLICABLE
ASN LF06-04501

S3LF00012ZE02
Issued 8/2012

Printed in U.S.A. Book
Copyright © 2012 Kobelco Construction Machinery America, LLC. All Rights Reserved

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
AIR CLEANER ASSEMBLY	01-010	00
AIR CONDITIONING	01-080	08
AIR CONDITIONING	01-080	02
AIR CONDITIONING	01-080	01
AIR CONDITIONING	01-080	03
AIR CONDITIONING	01-080	04
AIR CONDITIONING	01-080	05
AIR CONDITIONING	01-080	06
AIR CONDITIONING	01-080	07
ALARM ASSEMBLY	01-088	00
ARM 1.87M	03-010	00
ARM CYLINDER INSTALLATION	03-015	02
ARM CYLINDER INSTALLATION	03-015	01
ARM GROUP	03-023	01
ARM GROUP	03-023	02
ARM INSTALLATION	03-022	02
ARM INSTALLATION	03-022	01
ARM, LONG 2.13M	03-024	00
BATTERY ASSEMBLY	01-079	00
BOOM CYLINDER INSTALLATION	03-011	02
BOOM CYLINDER INSTALLATION	03-011	01
BOOM GROUP	03-004	00
BOOM INSTALLATION	03-001	00
BOOM, HOE 3.67M	03-002	00
BUCKET CYLINDER INSTALLATION	03-031	02
BUCKET CYLINDER INSTALLATION	03-031	01
BUCKET INSTALLATION	03-025	00
CAB INSTALLATION	01-062	11
CAB INSTALLATION	01-062	12
CAB INSTALLATION	01-062	10
CAB INSTALLATION	01-062	13
CAB INSTALLATION	01-062	01
CAB INSTALLATION	01-062	02
CAB INSTALLATION	01-062	03
CAB INSTALLATION	01-062	04
CAB INSTALLATION	01-062	05
CAB INSTALLATION	01-062	06
CAB INSTALLATION	01-062	07
CAB INSTALLATION	01-062	08
CAB INSTALLATION	01-062	14
CAB INSTALLATION	01-062	09
CAMSHAFT AND VALVE	08-004	01
CAMSHAFT AND VALVE	08-004	02
CAP ASSEMBLY	03-009	00
CAP ASSEMBLY	03-005	00
CAP ASSEMBLY	02-005	00
CONNECTOR ASSEMBLY	03-006	00
CONTROL ASSEMBLY, DOZER	01-018	00
CONTROL ASSEMBLY, ENGINE	01-006	00
CONTROL LINES, BLOCK (1 OPTION)	01-042	00
CONTROL LINES, BLOCK (2 OPTION)	01-043	00
CONTROL LINES, BLOCK (SENSOR BLOCK)	01-041	00
CONTROL LINES, MAIN (DOZER)	01-026	01
CONTROL LINES, MAIN (DOZER)	01-026	02
CONTROL LINES, MAIN (DOZER)	01-026	03
CONTROL LINES, MAIN (DOZER)	01-026	04

MidWestTech | Kobelco SK80CS-2 Center Swing Excavator Parts Catalog | Publication S3... Order the manual at mid-west-tech.com >

CONTROL LINES, MAIN (DOZER)	01-026	05
CONTROL LINES, MAIN (NIBBLER & BREAKER + DOZER)	01-027	01
CONTROL LINES, MAIN (NIBBLER & BREAKER + DOZER)	01-027	03
CONTROL LINES, MAIN (NIBBLER & BREAKER + DOZER)	01-027	02
CONTROL LINES, MAIN (NIBBLER & BREAKER + DOZER)	01-027	04
CONTROL LINES, MULTI	01-039	02
CONTROL LINES, MULTI	01-039	03
CONTROL LINES, MULTI	01-039	01
CONTROL LINES, PROPEL	01-038	02
CONTROL LINES, PROPEL	01-038	01
CONTROL LINES, PUMP	01-037	00
CONTROL LINES, REMOTE	01-040	01
CONTROL LINES, REMOTE	01-040	02
CONTROL LINES, REMOTE	01-033	02
CONTROL LINES, REMOTE	01-033	03
CONTROL LINES, REMOTE	01-033	01
CONTROL LINES, REMOTE (BLOCK)	01-035	01
CONTROL LINES, REMOTE (BLOCK)	01-035	02
CONTROL LINES, REMOTE (BLOCK)	01-035	03
CONTROL LINES, REMOTE (DOZER)	01-036	00
CONTROL LINES, REMOTE (NIBBLER & BREAKER + AUGER)	01-034	01
CONTROL LINES, REMOTE (NIBBLER & BREAKER + AUGER)	01-034	02
CONTROL LINES, VALVE	01-029	03
CONTROL LINES, VALVE	01-029	02
CONTROL LINES, VALVE	01-029	01
CONTROL LINES, VALVE	01-029	04
CONTROLLER INSTALLATION	01-054	02
CONTROLLER INSTALLATION	01-054	01
CONTROLLER INSTALLATION	01-054	03
CONTROLS, OPERATORS (1 PEDAL, DOZER)	01-050	04
CONTROLS, OPERATORS (1 PEDAL, DOZER)	01-050	03
CONTROLS, OPERATORS (1 PEDAL, DOZER)	01-050	01
CONTROLS, OPERATORS (1 PEDAL, DOZER)	01-050	07
CONTROLS, OPERATORS (1 PEDAL, DOZER)	01-050	08
CONTROLS, OPERATORS (1 PEDAL, DOZER)	01-050	02
CONTROLS, OPERATORS (1 PEDAL, DOZER)	01-050	05
CONTROLS, OPERATORS (1 PEDAL, DOZER)	01-050	06
CONTROLS, OPERATORS (2 PEDAL, DOZER)	01-051	04
CONTROLS, OPERATORS (2 PEDAL, DOZER)	01-051	03
CONTROLS, OPERATORS (2 PEDAL, DOZER)	01-051	01
CONTROLS, OPERATORS (2 PEDAL, DOZER)	01-051	06
CONTROLS, OPERATORS (2 PEDAL, DOZER)	01-051	07
CONTROLS, OPERATORS (2 PEDAL, DOZER)	01-051	08
CONTROLS, OPERATORS (2 PEDAL, DOZER)	01-051	02
CONTROLS, OPERATORS (2 PEDAL, DOZER)	01-051	05
COUNTERWEIGHT INSTALLATION	01-003	00
COVER ASSEMBLY, UNDER	01-073	00
CRANKSHAFT, PISTON AND FLYWHEEL	08-011	00
CYLINDER BLOCK	08-002	01
CYLINDER BLOCK	08-002	02
CYLINDER HEAD	08-006	00
CYLINDER HEAD COVER	08-007	00
CYLINDER INSTALLATION	01-004	02
CYLINDER INSTALLATION	01-004	03
CYLINDER INSTALLATION	02-010	02
CYLINDER INSTALLATION	02-010	01
CYLINDER INSTALLATION	01-004	01
DOZER ASSEMBLY	02-013	00

Order the manual at mid-west-tech.com >

DOZER ASSEMBLY	02-020	00
DOZER GROUP	02-017	00
DOZER INSTALLATION	02-018	00
ELECTRICAL ASSEMBLY, UPPER	01-078	00
ELECTRICAL CONTROL AND OTHER PARTS	08-018	00
ELEMENT KIT	04-002	00
EMISSION PIPING	08-012	00
ENGINE ELECTRICAL CONTROL PARTS	08-013	02
ENGINE ELECTRICAL CONTROL PARTS	08-013	01
ENGINE GASKET KIT	08-001	00
ENGINE INSTALLATION	01-005	01
ENGINE INSTALLATION	01-005	02
EXHAUST MANIFOLD	08-010	00
FAN AND FAN BELT	08-032	00
FILTERS & CAPACITIES	00-001	00
FRAME ASSEMBLY, LOW	02-001	00
FRAME GROUP, UPPER	01-002	01
FRAME GROUP, UPPER	01-002	02
FRAME GROUP, UPPER	01-001	00
FUEL FILTER AND BRACKET	08-019	00
FUEL INJECTION SYSTEM	08-020	02
FUEL INJECTION SYSTEM	08-020	03
FUEL INJECTION SYSTEM	08-020	01
FUEL LINES	01-012	00
FUEL TANK INSTALLATION	01-013	00
GENERATOR	08-015	00
GUARD INSTALLATION	01-069	02
GUARD INSTALLATION	01-069	05
GUARD INSTALLATION	01-069	06
GUARD INSTALLATION	01-069	07
GUARD INSTALLATION	01-069	01
GUARD INSTALLATION	01-069	10
GUARD INSTALLATION	01-069	08
GUARD INSTALLATION	01-069	09
GUARD INSTALLATION	01-069	04
GUARD INSTALLATION	01-069	03
GUARD INSTALLATION	01-069	11
HARNESS ASSEMBLY, BOOM	03-003	00
HARNESS ASSEMBLY, CAB	01-087	01
HARNESS ASSEMBLY, CAB	01-087	02
HARNESS ASSEMBLY, UPPER	01-083	01
HARNESS ASSEMBLY, UPPER	01-088	03
HARNESS ASSEMBLY, UPPER	01-088	01
HARNESS ASSEMBLY, UPPER	01-083	02
HARNESS ASSEMBLY, UPPER	01-088	04
HARNESS ASSEMBLY, UPPER	01-088	02
HARNESS ASSEMBLY, UPPER	01-083	03
HARNESS ASSEMBLY, UPPER	01-083	04
HARNESS ASSEMBLY, UPPER	01-083	05
HARNESS ASSEMBLY, UPPER	01-083	06
HARNESS ASSEMBLY, UPPER	01-083	07
HARNESS ASSEMBLY, UPPER	01-083	08
HARNESS ASSEMBLY, UPPER (FLOOR)	01-086	03
HARNESS ASSEMBLY, UPPER (FLOOR)	01-086	01
HARNESS ASSEMBLY, UPPER (FLOOR)	01-086	02
HYDRAULIC LINES, ARM	03-029	00
HYDRAULIC LINES, ARM (NIBBLER & BREAKER)	03-032	00
HYDRAULIC LINES, ARM 2.13M	03-030	00

Order the manual at mid-west-tech.com >

VALVE INSTALLATION

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		YT30V00039S068		8	GUIDE
2		YT30V00039S069		4	SPRING
3		YT30V00039S070		8	SPACER
4		YT30V00039S071		8	CAP
5		YT30V00039S072		8	SPACER
6		NSS		1	NOT SERVICED SEPARATELY, Swing Spool
7		NSS		2	NOT SERVICED SEPARATELY, Track Spool
8		NSS		1	NOT SERVICED SEPARATELY, Boom Spool
9		NSS		1	NOT SERVICED SEPARATELY, Bucket Spool
10		NSS		1	NOT SERVICED SEPARATELY, N & B Spool
11		PY30V00001S028		4	SPRING
12		NSS		1	NOT SERVICED SEPARATELY, Arm Spool
13		NSS		1	NOT SERVICED SEPARATELY, Dozer Spool
		YT30V00039R100		1	SPOOL, Swing Spool Repair Kit, Consists Of Item: 1(1), 2(1), 3(1), 4(1), 5(1), 6(1)
		YT30V00039R200		2	SPOOL, Track Spool Repair Kit, Consists Of Item: 1(1), 3(1), 4(1), 5(1), 7(1), 11(1)
		YT30V00039R400		1	SPOOL, Boom Spool Repair Kit, Consists Of Item: 1(1), 2(1), 3(1), 4(1), 5(1), 8(1)
		YT30V00039R500		1	SPOOL, Bucket Spool Repair Kit, Consists Of Item: 1(1), 2(1), 3(1), 4(1), 5(1), 9(1)
		YT30V00039R700		1	SPOOL, N & B Spool Repair Kit, Consists Of Item: 1(1), 3(1), 4(1), 5(1), 10(1), 11(1)
		YT30V00047R100		1	SPOOL, Arm Spool Repair Kit, Consists Of Item: 1(1), 2(1), 3(1), 4(1), 5(1), 12(1)
		YT30V00047R200		1	SPOOL, Dozer Spool Repair Kit, Consists Of Item: 1(1), 3(1), 4(1), 5(1),11(1), 13(1)

MidWestTech | Kobelco SK80CS-2 Center Swing Excavator Parts Catalog | Publication S3... Order the manual at mid-west-tech.com >

BOOM CYLINDER INSTALLATION

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		NSS		1	NOT SERVICED SEPARATELY, Tube Assy.
2		NSS		1	NOT SERVICED SEPARATELY, Rod, Piston
3		YT01V00017S003		1	CYLINDER HEAD
4		YT01V00017S004		1	BUSHING
5		2438U721S7		1	SNAP RING
6		YT01V00017S006		1	RING, Back Up
7		2438U381S4		1	RING, U
8		YT01V00001S009		1	RING
9		ZD12G10500		2	O-RING
10		PY01V00036S008		1	RING, Back Up
11		ZD11G11000		1	O-RING
12		YT01V00017S012		1	HOLDER
13		YT01V00017S013		2	SEAL
14		YT01V00017S014		1	COLLAR
15		2438U1949S12		1	RING, Back Up
16		YT01V00017S016		1	BEARING, Ring
17		YT01V00017S017		1	PISTON
18		2438U716S23		1	SEALRING
19		YM01V00019S018		2	RING
20		YM01V00009S020		1	NUT
21		2438U999S21		1	SCREW
22		2436U330S16		1	BALL
23		YT01V01001P2		2	BUSHING
24		2438U1946S25		2	RING
25		YT01V01003P2		2	BUSHING
26		LP01V00007S026		2	RING, Wiper
		YT01V00017R100		1	SEAL, Consists Of Item: 6(1), 7(1), 8(1), 10(1), 11(1), 15(1), 9(2), 13(2)
		YT01V00017R600		1	SEAL KIT, Consists Of Item: 18(1), 19(2)
		YT01V00030R300		1	REPAIR KIT, Consists Of Item: 6(1), 7(1), 8(1), 10(1), 11(1), 15(1), 18(1), 9(2), 13(2), 19(2)
		YT01V00030R400		1	PIPE, Consists Of Item: 1(1), 23(2), 24(2)
		YT01V00030R500		1	SERVICE KIT, Consists Of Item: 2(2), 25(2), 26(2)

MidWestTech | Kobelco SK80CS-2 Center Swing Excavator Parts Catalog | Publication S3... Order the manual at mid-west-tech.com >

BUCKET CYLINDER INSTALLATION

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		YT01V00019R300		1	REPAIR KIT, Consists Of Item: 6(1), 7(1), 8(1), 9(1), 10(1), 11(1), 13(1), 14(2)
		YT01V00032R400		1	REPAIR KIT, Consists Of Item: 1(1), 17(1), 18(2)
		YT01V00032R500		1	REPAIR KIT, Consists Of Item: 2(1), 19(1),18(2)

MidWestTech | Kobelco SK80CS-2 Center Swing Excavator Parts Catalog | Publication S3... Order the manual at mid-west-tech.com >