KOBELCO®

PARTS CATALOG

50SR-5
Compact Crawler Excavator

APPLICABLE
ASN PJ06-09807

S3PJ00045ZE02
Issued 9/2010

Printed in U.S.A.

MidWestTech | Kobelco 50SR-5 Compact Crawler Excavator Parts Catalog | Publication S3PJ00045ZE02

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
ALARM ASSY, PROPEL	05-002	
ARM	03-015	
ARM GROUP	03-016	
ARM INSTAL	03-017	
BATTERY ASSY	01-072	
BOOM GROUP	03-002	
BOOM INSTAL	03-003	
BOOM, HOE	03-001	
BRACKET GROUP, SWING	01-003	
BRACKET INSTAL, SWING	01-002	
BUCKET ASSY, 450W	03-024	
BUCKET ASSY, 550W	03-025	
BUCKET ASSY, 650W	03-023	
BUCKET ASSY, 650W	03-022	
BUCKET ASSY, 700W	03-027	
BUCKET ASSY, 750W	03-026	
BUCKET INSTAL	03-021	
CAB ASSY	01-050	09
CAB ASSY	01-050	08
CAB ASSY	01-050	07
CAB ASSY	01-050	06
CAB ASSY	01-050	05
CAB ASSY	01-050	04
CAB ASSY	01-050	03
CAB ASSY	01-050	02
CAB ASSY	01-050	01
CAB INSTAL	01-052	08
CAB INSTAL	01-052	07
CAB INSTAL	01-052	06
CAB INSTAL	01-052	05
CAB INSTAL	01-052	04
CAB INSTAL	01-052	03
CAB INSTAL	01-052	02
CAB INSTAL	01-052	01
CAB INSTAL	01-051	09
CAB INSTAL	01-053	
CAB INSTAL, HEAD GUARD, COOLER	01-051	08
CAB INSTAL, HEAD GUARD, COOLER	01-051	07
CAB INSTAL, HEAD GUARD, COOLER	01-051	06
CAB INSTAL, HEAD GUARD, COOLER	01-051	05
CAB INSTAL, HEAD GUARD, COOLER	01-051	04
CAB INSTAL, HEAD GUARD, COOLER	01-051	03
CAB INSTAL, HEAD GUARD, COOLER	01-051	02
CAB INSTAL, HEAD GUARD, COOLER	01-051	01
CAB INSTAL, WITH HEAD GUARD	01-054	09
CAB INSTAL, WITH HEAD GUARD	01-054	08
CAB INSTAL, WITH HEAD GUARD	01-054	07
CAB INSTAL, WITH HEAD GUARD	01-054	06
CAB INSTAL, WITH HEAD GUARD	01-054	05
CAB INSTAL, WITH HEAD GUARD	01-054	04
CAB INSTAL, WITH HEAD GUARD	01-054	03
CAB INSTAL, WITH HEAD GUARD	01-054	02
CAB INSTAL, WITH HEAD GUARD	01-054	01
CAMSHAFT & DRIVING GEAR	08-007	
CANOPY ASSY	01-059	
CANOPY INSTAL	01-056	

Order the manual at mid-west-tech.com >

CAP ASSY	03-018	
CLEANER ASSY, AIR, CAB	01-012	
CLEANER ASSY, AIR, CANOPY	01-011	
CONDITIONER INSTAL	01-069	
CONTROL ASSY, ENGINE	01-020	02
CONTROL ASSY, ENGINE	01-020	01
CONTROL LINES, MAIN	01-040	
CONTROL LINES, MULTI	01-041	
CONTROL LINES, PROPEL, ALARM	05-001	02
CONTROL LINES, PROPEL, ALARM	05-001	01
CONTROL LINES, PROPEL, ANGLE DOZER	01-047	03
CONTROL LINES, PROPEL, ANGLE DOZER	01-047	02
CONTROL LINES, PROPEL, ANGLE DOZER	01-047	01
CONTROL LINES, REMOTE	01-042	02
CONTROL LINES, REMOTE	01-042	01
CONTROL LINES, REMOTE, DOZER	01-043	02
CONTROL LINES, REMOTE, DOZER	01-043	01
CONTROL LINES, VALVE	01-044	03
CONTROL LINES, VALVE	01-044	02
CONTROL LINES, VALVE	01-044	01
CONTROL LINES, VALVE, COOLER	01-046	03
CONTROL LINES, VALVE, COOLER	01-046	04
CONTROL LINES, VALVE, COOLER	01-046	02
CONTROL LINES, VALVE, COOLER	01-046	01
CONTROL LINES, VALVE, N&B PROPORTIONAL	01-045	01
CONTROL LINES, VALVE, N&B PROPORTIONAL	01-045	02
CONTROLS, OPERATORS	01-033	03
CONTROLS, OPERATORS	01-033	02
CONTROLS, OPERATORS	01-033	01
CONTROLS, OPERATORS, CANOPY	01-035	02
CONTROLS, OPERATORS, CANOPY	01-035	01
CONTROLS, OPERATORS, CANOPY	01-034	02
CONTROLS, OPERATORS, CANOPY	01-034	01
COOLER ASSY	01-070	02
COOLER ASSY	01-070	01
COOLER ASSY	01-071	
COOLING WATER SYSTEM	08-010	
COUNTERWEIGHT ASSY	01-006	
COVER ASSY	01-036	
COVER ASSY, UNDER	01-065	
CRANKSHAFT & PISTON	08-008	
CYLINDER BLOCK	08-001	
CYLINDER HEAD & BONNET	08-004	
CYLINDER INSTAL	02-017	01
CYLINDER INSTAL	02-017	02
CYLINDER INSTAL, ARM	03-006	02
CYLINDER INSTAL, BUCKET	03-007	02
CYLINDER INSTAL, BUCKET	03-007	01
CYLINDER INSTAL, CAB	03-006	01
CYLINDER INSTAL, CAB	03-005	02
CYLINDER INSTAL, CAB	03-005	01
CYLINDER INSTAL, CANOPY	03-004	01
CYLINDER INSTAL, CANOPY	03-004	02
CYLINDER INSTAL, SWING	01-004	
DOZER ASSY	02-014	
DOZER GROUP	02-015	
DOZER INSTAL	02-016	
ELEC ASSY, UPP	01-075	05

Order the manual at mid-west-tech.com >

ELEC ASSY, UPP	01-075	03
ELEC ASSY, UPP	01-075	04
ELEC ASSY, UPP	01-075	02
ELEC ASSY, UPP	01-075	01
ENGINE INSTAL	01-008	
ENGINE INSTAL, COOLER	01-007	
EXHAUST MANIFOLD	08-006	
FILTER_LIST	00-001	
FLYWHEEL HOUSING & OIL SUMP	08-003	
FRAME GROUP, UPP	01-001	
FUEL INJECTION PUMP	08-011	
FUEL INJECTION VALVE	08-013	
FUEL LINE	08-014	
FUEL LINES	01-014	
GASKET SET	08-017	
GEAR HOUSING	08-002	
GENERATOR	08-016	
GOVERNOR	08-012	
GRIP ASSY	01-038	
GROMMET, CAB	01-068	
GROMMET, CANOPY	01-067	
GUARD ASSY, HEAD	01-055	
GUARD INSTAL, CAB/COOLER	01-064	03
GUARD INSTAL, CAB/COOLER	01-064	02
GUARD INSTAL, CAB/COOLER	01-064	01
GUARD INSTAL, CANOPY	01-063	03
GUARD INSTAL, CANOPY	01-063	02
GUARD INSTAL, CANOPY	01-063	01
HARNESS ASSY, BOOM	03-013	
HARNESS ASSY, CAB	01-079	
HARNESS ASSY, CLEANER AIR	01-076	
HARNESS ASSY, COOLER	01-078	
HARNESS ASSY, ENGINE	01-080	
HARNESS ASSY, PROPORTIONAL	01-077	02
HARNESS ASSY, PROPORTIONAL	01-077	01
HOSE ASSY, HEATER	01-073	
HOSE ASSY, HEATER	01-074	
HYD LINES, ARM	03-019	
HYD LINES, ARM	03-020	
HYD LINES, BOOM	03-008	
HYD LINES, BOOM, NIBBLER AND BREAKER	03-009	
HYD LINES, CYLINDER	02-018	
HYD LINES, CYLINDER, ARM	03-011	
HYD LINES, CYLINDER, BOOM	03-010	
HYD LINES, CYLINDER, BUCKET	03-012	
HYD LINES, CYLINDER, SWING	01-005	
HYD LINES, LOW	02-011	
HYD LINES, PROPEL	02-012	
HYD LINES, PUMP	01-028	
HYD LINES, RETURN	01-032	
HYD LINES, SWIVEL	02-013	
HYD LINES, SWIVEL	01-031	
HYD LINES, UPP	01-029	02
HYD LINES, UPP	01-029	01
HYD LINES, UPP, NIBBLER AND BREAKER	01-030	
IDLER ASSY, CRAWLER	02-006	
JOINT ASSY, SWIVEL	02-004	02
JOINT ASSY, SWIVEL	02-004	01

Order the manual at mid-west-tech.com >