KOBELCO

PARTS CATALOG

COMPACT EXCAVATOR

17SR-3

TIER 4

S3PU00002ZE02 NA
Replaces 87632212 NA

Issued 01April 08

APPLICABLE: PU08-05001~

MidWestTech | Kobelco 17SR-3 Tier 4 Compact Excavator Parts Catalog | Publication S3PU00002ZE02

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001		FILTER, FUEL - FILTER, OIL
00-002		SLEEVE
00-003		NUT
00-004		PAINT COLOR
01-001		FRAME ASSEMBLY, UPPER (PU52F00032F1) (PU24C00012F1 COVER)
01-002		BRACKET ASSEMBLY, SWING (PU02B00066F1, 76F1, 69F1, 65F1)
01-003	01	COUNTERWEIGHT INSTAL (PU60C00016F1, 15F1)
01-003	02	COUNTERWEIGHT INSTAL (CAB)
01-004		ENGINE ASSEMBLY (PU02P00013F1)
01-005		ENGINE INSTAL (PU02P00016F1)
01-006		RADIATOR INSTAL (PU05P00016F1, 17F1)
01-007		RADIATOR ASSY (PU05P00015F1)
01-008		AIR CLEANER ASSEMBLY (PU11P00006F1)
01-009		MUFFLER (PU12P00014F1)
01-010		FUEL LINES (PU21P00002F1)
01-011		FUEL LINES
01-012		TANK INSTAL, FUEL (PU20P00015F1, 14F1)
01-013		TANK INSTAL, HYDRAULIC (PU33H00016F1, 19F1)
01-014		CONTROL ASSEMBLY, ENGINE (PU11M00012F1)
01-015		POWER TAKE-OFF ASSEMBLY (PU30P00013F1)
01-016		MOTOR INSTAL, SWING (PU32W00012F1)
01-017		LUBRICATION LINES (PU71H00012F1)
01-018		CONTROL VALVE INSTAL (PU64H00019F1)
01-019		HYDRAULICS - PUMP TO CONTROL VALVE (PU30H00013F1)
01-020		HYDRAULICS - UPPER / SWING MOTOR TO CYLINDER (PU03H00016F1, PU19H00018F1, PU42H00024F1)
01-021		HYDRAULICS - UPPER / AT CONTROL VALVE
01-022		HYDRAULICS - UPPER / NIBBLER & BREAKER (PU03H00017F1)
01-023		HYDRAULICS - RETURN / NIBBLER & BREAKER (PU32H00018F1, 16F1)
01-024		HYDRAULICS - RETURN / NIBBLER & BREAKER / AT TANK & VALVE
01-025		CONTROLS, OPERATOR (PU03M00033F1)
01-026	01	CONTROLS OPERATORS (PU03M00038F1)
01-026	02	CONTROLS OPERATORS
01-027		COVER ASSEMBLY
01-028		WRIST SUPPORT, OPERATOR CONTROLS (PU03M01368F1)
01-029		CONTROL BOX ASSEMBLY (LH) (PU03M00036F1)
01-030		LOCK ASSEMBLY (PU03M01122F1)
01-031		LEVER ASSEMBLY, CONTROL (CRAWLER) (PU50M00014F1)
01-032		LEVER ASSEMBLY (DOZER)
01-033		LEVER ASSEMBLY (CAB DOZER)(PU03M01438F1)
01-034		LEVER ASSEMBLY, CONTROL (PM50M00004F3)
01-035		LEVER ASSEMBLY CONTROL (CAB) (PU55M00003F1)
01-036	01	CONTROL LINES, REMOTE, (MULTI) (PU64H00022F1, PU68H00033F1, 28F1, 34F1)
01-036	02	CONTROL LINES, REMOTE, (MULTI) (PU06H00020F1, 15F1, 21F1)
01-037		HYDRAULICS - CONTROL LINES, VALVE INSTAL (PU64H00024F1, 25F1)
01-038		HYDRAULICS - CONTROL LINES, PROPEL (PU62H00003F1, 04F1, 05F1)
01-039		CONTROL LINES PROPEL (TRAVEL ALARM) (PU62H00006F1, 04F1, 07F1)
01-040		HYDRAULICS - CONTROL LINES, VALVE (AT TANK, PUMP, SOLENOID VALVE) (PU64H00023F1)
01-041		PLATE GROUP, FLOOR, CANOPY (NIBBLER AND BREAKER) (PU03M00035F1)
01-042		PLATE GROUP, FLOOR, CAB (PU03M00040F1)

MidWestTech | Kobelco 17SR-3 Tier 4 Compact Excavator Parts Catalog | Publication S3P... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-043		CAB INSTAL (PU02C00024F1, 20F1)
01-044	01	CAB ASSEMBLY (PU02C00019F1)
01-044	02	CAB ASSEMBLY
01-044	03	CAB ASSEMBLY
01-045		GUARD ASSEMBLY, HEAD (PU02C01167F1)
01-046		WINDOW ASSEMBLY, FR (PF50C00002F1)
01-047		DOOR ASSEMBLY (PF51C00004F2)
01-048		CANOPY ASSEMBLY (PU06C00014F1)
01-049		WORK LAMP ASSEMBLY (PA80S00003F1)
01-050		WORKING LIGHT ASSEMBLY (CAB)(PF80S00002F1)
01-051		SEAT ASSEMBLY INSTAL (PU25M00022F1)
01-052		SEAT INSTAL (CAB) (PU25M00030F1)
01-053		GUARDS & COVERS (EXTERIOR, UPPER) (PU21C00017F1)
01-054		KEY ASSEMBLY (PW03M01865F1)
01-055		GAUGE ASSEMBLY, CLUSTER (PU59S00001F1)
01-056		BATTERY INSTAL (PU72E00012F1)
01-057	01	ELECTRICAL ASSEMBLY, UPPER (HARNESS) (PU03E00002F1)
01-057	02	ELECTRICAL ASSEMBLY, UPPER (HARDWARE)
01-057	03	ELECTRICAL ASSEMBLY, UPPER (CABLE, FUSE, RELAY)
01-057	04	ELECTRICAL ASSEMBLY, UPPER (HORN)
01-058		HARNESS ASSEMBLY (CAB) (PU14E00002F1)
01-059		HARNESS ASSEMBLY (AT AIR CLEANER) (PU11E00001F1)
01-060		RELAY ASSEMBLY (HARNESS) (PU24E00016F1)
02-001		LOWER FRAME GROUP (PU02F00034F1, PU53D00016F1, PU19H00016F1)
02-002		CYLINDER INSTAL (CRAWLER FRAME WIDTH) (PU01V00034F1)
02-003		SLEWING RING ASSEMBLY (PF40F00002F1)
02-004		IDLER ASSEMBLY (PU52D00017F1)
02-005		IDLER ASSEMBLY (PU52D00019F1)
02-006		IDLER ADJUSTER ASSEMBLY (PE54D00001F1)
02-007		TRACK ROLLER ASSEMBLY (PU64D00015F1)
02-008		SHOE ASSEMBLY, TRACK / BELT (PE61D00002F1, PE60D00003F1)
02-009	01	HYDRAULICS - LOWER / AT SWIVEL (PU02H00015F1, PU19H00017F1, PU13H00012F1)
02-009	02	HYDRAULICS - LOWER (PU12H00012F1, PU13H00013F1)
02-010		DOZER ASSEMBLY, FRAME (PU51B00023F1, 25F1, 26F1, 24F1)
03-001		BOOM ASSEMBLY, STANDARD 1.8M (6 FT) (PU02B00061F1, 64F1, 67F1)
03-002		HYDRAULIC LINES - BOOM 1.8M (6 FT) & CYLINDER (PU42H00026F1, 21F1, 23F1, 22F1)
03-003		HYDRAULIC LINES - BOOM 1.8M (6 FT) & ARM (NIBBLER & BREAKER) (PU42H00020F1, PU43H00017F1)
03-004	01	CYLINDER INSTAL (BOOM) (PU02B00077F1)
03-004	02	CYLINDER INSTAL (CAB)
03-005	01	LAMP INSTAL & HARNESS (BOOM) (PU80S00012F1)
03-005	02	LIGHT INSTAL (CAB)
03-006		ARM ASSEMBLY, STANDARD 0.98M (3 FT 2 IN) (PU12B00049F1)
03-007		HYDRAULIC LINES - ARM, STANDARD 0.98M (3 FT 2 IN)(PU43H00018F1)
03-008		BUCKET INSTAL (PU61B00049F1)
04-001		TOOLS & ACCESSORIES (PM01T00002FE)
04-002		MANUAL ASSEMBLY
05-001		COUNTERWEIGHT INSTAL (PU60C00023F1)
05-002		CONTROL ASSEMBLY, EXTRA (PU14M00001F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

05-003		HEATER ASSEMBLY
05-004		ALARM ASSEMBLY (PU53E00002F1)
05-005		ARM ASSEMBLY, LONG 1.20M (4 FT) (PU12B00052F1)
05-006		HYDRAULIC LINES - ARM, LONG 1.20M (4 FT) (PU43H00022F1)
05-007		HYDRAULIC LINES - BOOM & ARM 1.20M (4 FT) (NIBBLER & BREAKER) (PU42H00020F1)
05-008		HOOK INSTAL
06-001	01	NAME PLATE INSTAL (PU22T00048F1)
06-001	02	NAME PLATE INSTAL (CAB) (PU22T00048F1)
06-001	03	NAME PLATE INSTAL (PU22T00048F1)
06-002		NAME PLATE INSTAL (CEMA MARK)(PU22T00048F1)
06-003		NAME PLATE INSTAL (CAB)(PU22T00066F1)
06-004		NAME PLATE INSTAL (PU22T00044F1)
07-001		VALVE ASSEMBLY, CONTROL (PU30V00017F1,F2)
07-002		VALVE ASSEMBLY O-RINGS (PU30V00017F1,F2)
07-003		VALVE SECTION, CONTROL VALVE - SLEWING/SWING (PU30V00019F1, F2)
07-004		VALVE SECTION, CONTROL VALVE - DOZER (PU30V00020F1)
07-005		VALVE SECTION, CONTROL VALVE - SUPPLY, TRAVEL INDEPENDENCE (PU30V00021F1)
07-006		VALVE SECTION, CONTROL VALVE - SERVICE (PU30V00022F1)
07-007		VALVE SECTION, CONTROL VALVE - ARM (PU30V00023F1)
07-008		VALVE SECTION, CONTROL VALVE - BOOM SWING (PU30V00024F1)
07-009		VALVE SECTION, CONTROL VALVE - TRAVEL RIGHT (PU30V00025F1)
07-010		VALVE SECTION, CONTROL VALVE - SUPPLY, CONNECTING (PU30V00026F1)
07-011		VALVE SECTION, CONTROL VALVE - TRAVEL LEFT (PU30V00027F1)
07-012		VALVE SECTION, CONTROL VALVE - BOOM (PU30V00028F1)
07-013		VALVE SECTION, CONTROL VALVE - BUCKET (PU30V00029F1)
07-014		VALVE ASSEMBLY, OVERLOAD RELIEF (PM22V00005F1-FG)
07-015		VALVE ASSEMBLY, ANTI-CAVITATION (PH21V00001F1)
07-016		PLUG ASSEMBLY, SERVICE SECTION (PH50T00001F1)
07-017		VALVE ASSEMBLY, RELIEF (PR22V00004F1-FA)
07-018		MOTOR ASSEMBLY, SWING (PU15V00019F1)
07-019		VALVE ASSEMBLY, RELIEF (SWING MOTOR) (PU22V00001F1)
07-020	01	MOTOR ASSEMBLY, PROPELLING (PU15V00021F1)
07-020	02	MOTOR ASSEMBLY, PROPELLING (PU15V00021F1)
07-021		PUMP ASSEMBLY (PU10V00014F1)
07-022	01	CYLINDER ASSEMBLY, BOOM (CANOPY) (PU01V00024F1)
07-022	02	CYLINDER ASSEMBLY, BOOM (CANOPY) (PU01V00044F1)
07-022	03	CYLINDER ASSEMBLY, BOOM (CAB) (PU01V000445F1)
07-023		CYLINDER ASSEMBLY, ARM (PU01V00036F1)
07-024		CYLINDER ASSEMBLY, BUCKET (PU01V00035F1)
07-025		CYLINDER ASSEMBLY, DOZER (PU01V00029F1)
07-026		CYLINDER ASSEMBLY, SWING (PU01V00028F1)
07-027		CYLINDER ASSEMBLY, CRAWLER (PU01V00030F1)
07-028		VALVE ASSEMBLY, PILOT (PX30V00043F1)
07-029		VALVE ASSEMBLY, PILOT (PROPELLING) (PM30V00019F1)
07-030		VALVE ASSEMBLY, SOLENOID (PX35V00003F1)
07-031		VALVE ASSEMBLY, RELIEF (YR22V00001F1)
07-032		VALVE ASSEMBLY, SELECTOR (PX30V00074F1)
07-033		JOINT ASSEMBLY, SWIVEL (PA55V00001F1 - F4)
08-001		CYLINDER HEAD

Order the manual at mid-west-tech.com >

TANK INSTAL, FUEL (PU20P00015F1, 14F1)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			Tank Instal, Fuel, PU20P00015F1, Includes Ref. A1 - A10
		{}			Tank Instal, Fuel, PU20P00014F1, Includes Ref. A1 - A10
A1		PU20P01055P1		1	BRACKET
A2		PU20P01054P1		1	RUBBER
A3		PU20P01028P1		1	RUBBER SLEEVE
A4		YN05P00010S007		1	COCK, DRAIN
A5		PM05P01046P1		1	BOSS
A6		PA21P01005DK		1	HOSE
A7		PH05P01088D6		2	BAND, Clip
A8		ZM73C12025		2	BOLT
A9		ZM73C10020		1	BOLT
A10		PU20P01036P1		2	SHIN
		{}			Tank Assembly, Fuel, PU20P00013F1, Includes Ref. B1 - B15
B1		PU20P01022P1		2	FLANGE
B3		PU20P01038P1		1	FLANGE
B7		PA20P01018F1		1	CAP
B8		2446R314		1	FILTER, STRAINER
B9		ZM61C05012		5	BOLT
B10		2445Z1453D2		3	O-RING
B11		ZS18C06016		6	SCREW
B13		ZW16P06000		6	WASHER
B14		ZW26X06000		6	WASHER, LOCK
B15		PU52S00013F1		1	SENSOR, Level
		{}			Tank, Fuel, PU20P00017P1, Includes Ref. C1 - C2-4
C1		PU20P00012P1		1	TANK, FUEL
C2		PA20P01018F1		1	CAP
C2-1		PA20P01019P1		1	CAP
C2-2		PA20P01021P1		1	PACKING
C2-2		PA20P01020P1		1	PACKING
C2-4		PA20P01022P1		1	RUBBER SLEEVE

MidWestTech | Kobelco 17SR-3 Tier 4 Compact Excavator Parts Catalog | Publication S3P... Order the manual at mid-west-tech.com >

HYDRAULIC LINES - ARM, STANDARD 0.98M (3 FT 2 IN)(PU43H00018F1)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			Hydraulic Lines, Arm 0.98M, PU43H00018F1, Includes: Ref. A1 - A6
A1		HX25L04092DY		1	HOSE
A2		HX35L04058DY		1	HOSE
A3		PW68H01005D3	BTW PU08-05001 & PU08-05037	1	TUBE, Guard
A4		PW68H01005D1	BTW PU08-05001 & PU08-05037	1	TUBE, Guard
A4		PW68H01005D1	ASN PU08-05038	2	TUBE, Guard
A5		ZC46X12011		1	CLIP
A6		ZM73C10016		1	BOLT
		{}			Cylinder Instal, PU12B00043F1, Includes: Ref. B1 - C1
		{}			Cylinder Instal, PU12B00036F1, Includes: Ref. B1 - C1
B1		PU12B01138P1		1	PIN
B2		HS18C10065G2		1	SCREW
B3		ZN18C10008		2	NUT
B4		PE12B01048D3		2	SHIM, (t=0.5)
B5		PE12B01048D2		2	SHIM, (t=1.0)
C1	1	PU01V00035F1		1	CYLINDER, Bucket
		{}			Hydraulic Lines, Cylinder, PU43H00020F1, Includes: Ref. D1 - D2
D1		HH25S04004G1		1	CONNECTOR, HYD.
D2		HH35S04004G1		1	ELBOW
		{}			Cap Assembly, PW43H01036F1, Includes: Ref. E1
E1		PV02B01073D4		4	CAP

(1) See C.P.M.

MidWestTech | Kobelco 17SR-3 Tier 4 Compact Excavator Parts Catalog | Publication S3P... Order the manual at mid-west-tech.com >

VALVE ASSEMBLY, OVERLOAD RELIEF (PM22V00005F1-FG)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{}			Valve Assembly, Overload Relief, PM22V00005F1, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005F2, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005F3, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005F4, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005F5, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005F6, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005F7, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005F8, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005F9, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005FA, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005FB, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005FC, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005FD, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005FE, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005FF, Includes: Ref. 1-16
		{}			Valve Assembly, Overload Relief, PM22V00005FG, Includes: Ref. 1-16
1		NSS		1	NOT SERVICED SEPARATELY, Socket
2		NSS		1	NOT SERVICED SEPARATELY, Valve, Control
3		NSS		1	NOT SERVICED SEPARATELY, Piston

MidWestTech | Kobelco 17SR-3 Tier 4 Compact Excavator Parts Catalog | Publication S3P... Order the manual at mid-west-tech.com >