KOBELCO

PARTS CATALOG

COMPACT EXCAVATOR

SK27SR-3

S3PV00015ZE04 NA
Replaces S3PV00015ZE02 NA

Issued 01June07

APPLICABLE:
SK27SR-3 . . . . . PV10-27001~28408

MidWestTech | Kobelco SK27SR-3 Hydraulic Excavator Parts Catalog | Publication S3PV00015ZE04

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001		FILTER LIST
00-002		SLEEVE
00-003		NUT
00-004		PAINT COLOR
01-001		FRAME ASSY, UPPER
01-002		BRACKET ASSY, SWING
01-003		COUNTERWEIGHT INSTAL
01-004		ENGINE ASSEMBLY
01-005		ENGINE INSTAL
01-006		RADIATOR INSTAL
01-007		RADIATOR ASSEMBLY
01-008		CLEANER ASSEMBLY, AIR
01-009		CLEANER ASSEMBLY, AIR (W ELEMENT)
01-010		MUFFLER ASSEMBLY
01-011		FUEL LINES
01-012		TANK ASSEMBLY, FUEL (CANOPY)
01-013		TANK ASSY, FUEL (CAB)
01-014		TANK ASSEMBLY, HYDRAULIC (NIBBLER & BREAKER)
01-015	01	CONTROL ASSY, ENGINE (WITH DECEL)
01-015	02	CONTROL ASSY, ENGINE (WITH DECEL)
01-016		POWER TAKE-OFF ASSEMBLY
01-017		MOTOR INSTAL, SLEWING
01-018		HYDRAULIC LINES, CYLINDER (SWING)
01-019		VALVE INSTAL
01-020		HYDRAULIC LINES, PUMP
01-021	01	HYDRAULIC LINES, UPPER
01-021	02	HYDRAULIC LINES, UPPER
01-022		HYDRAULIC LINES, UPPER (NIBBLER & BREAKER)
01-023		HYDRAULIC LINES, RETURN
01-024		CONTROLS, OPERATORS
01-025		COVER ASSEMBLY
01-026		GRIP ASSEMBLY
01-027		CONTROL BOX ASSEMBLY (LEFT HAND)
01-028		STAND ASSEMBLY, CONTROL (CANOPY)
01-029		STAND ASSEMBLY, CONTROL (CAB)
01-030		LEVER ASSY, CONTROL
01-031	01	CONTROL LINES, REMOTE (NIBBLER & BREAKER)
01-031	02	CONTROL LINES, REMOTE (NIBBLER & BREAKER)
01-032		CONTROL LINES, REMOTE (MULTI)
01-033		CONTROL LINES, REMOTE (DOZER)
01-034	01	CONTROL LINES, REMOTE
01-034	02	CONTROL LINES, REMOTE
01-035		CONTROL LINES, VALVE, P/N PV64H00015F1
01-036		CONTROL LINES, VALVE, P/N PV64H00016F1
01-037		PLATE GROUP, FLOOR (CANOPY)
01-038		PLATE GROUP, FLOOR (CAB)
01-039		CAB INSTAL, P/N PM02C00036F1
01-040		CAB, P/N PM02C00034F1
01-041	01	CAB ASSY, P/N PW02C00015F1
01-041	02	CAB ASSY, P/N PW50C00002F1
01-041	03	CAB ASSY, P/N PW02C01145P2
01-041	04	CAB ASSY, P/N PW02C01071P1
01-041	05	CAB ASSY, P/N PA33H01057P1

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-042	01	CAB ASSY, P/N PW02C00068F1
01-042	02	CAB ASSY, P/N PW50C00002F1
01-042	03	CAB ASSY, P/N PW02C01145P2
01-042	04	CAB ASSY, P/N PW02C01071P1
01-042	05	CAB ASSY, P/N PA33H01057P1
01-043	01	GUARD ASSY, HEAD, P/N PW25C00002F1
01-043	02	GUARD ASSY, HEAD, P/N PW25C00003F1
01-044		WINDOW ASSEMBLY, FR.
01-045		DOOR ASSEMBLY, CAB
01-046		HOLDER ASSEMBLY
01-047		CANOPY ASSEMBLY
01-048		CANOPY INSTAL
01-049		HOLDER ASSEMBLY
01-050		LAMP ASSEMBLY (CAB)
01-051		LAMP, P/N PW80S00003F1
01-052		LAMP ASSEMBLY, P/N PW80S00004F1
01-053	01	LAMP ASSEMBLY, P/N PM80S00007F1
01-053	02	LAMP ASSEMBLY, P/N PM80S00008F1
01-054		SEAT INSTAL
01-055	01	GUARD INSTAL (CANOPY)
01-055	02	GUARD INSTAL (CANOPY)
01-055	03	GUARD INSTAL (CANOPY)
01-055	04	GUARD INSTAL (CANOPY)
01-056	01	GUARD INSTAL (CAB)
01-056	02	GUARD INSTAL (CAB)
01-056	03	GUARD INSTAL (CAB)
01-056	04	GUARD INSTAL (CAB)
01-057		KEY ASSY
01-058		GAUGE ASSY, CLUSTER
01-059		BATTERY INSTAL
01-060	01	ELECTRICAL ASSEMBLY, UPPER
01-060	02	ELECTRICAL ASSEMBLY, UPPER
01-060	03	ELECTRICAL ASSEMBLY, UPPER
01-061	01	HARNESS ASSY, CAB
01-061	02	HARNESS ASSY, CAB
01-062		HARNESS ASSY (CLEANER AIR)
01-063		HARNESS ASSY
01-064		HARNESS ASSY, ENGINE
01-065		RELAY ASSY, P/N PM24E00039F1
01-066	01	RELAY ASSY, P/N PM24E00040F1
01-066	02	RELAY ASSY, P/N PM24E00041F1
01-066	03	RELAY ASSY, P/N PM24E00042F1
02-001		LOW GROUP
02-002		SLEWING RING ASSEMBLY
02-003		IDLER ASSY, CRAWLER
02-004		IDLER ASSEMBLY
02-005		IDLER ADJUST ASSEMBLY
02-006		TRACK ROLLER ASSEMBLY
02-007		ROLLER ASSEMBLY, UPPER
02-008		SHOE ASSY
02-009		SHOE ASSY
02-010		HYDRAULIC LINES, LOW
02-011		DOZER ASSEMBLY

MidWestTech | Kobelco SK27SR-3 Hydraulic Excavator Parts Catalog | Publication S3PV0... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-001		BOOM ASSEMBLY, STANDARD 2.15M
03-002		HYDRAULIC LINES, BOOM 2.15M
03-003		HYDRAULIC LINES, BOOM 2.15M (NIBBLER & BREAKER)
03-004		CYLINDER INSTAL (CANOPY)
03-005		CYLINDER INSTAL (CAB)
03-006		LAMP INSTAL (BOOM)
03-007		ARM ASSY, 1.12M (REINFORCE TYPE)
03-008		HYDRAULIC LINES, ARM 1.12M
03-009		BUCKET INSTAL
04-001		TOOLS & ACCESSORIES
04-002		MANUAL ASSEMBLY
05-001		COUNTERWEIGHT INSTAL (GAIN)
05-002		CONTROL LINES PROPEL (NIBBLER, BREAKER + TRAVEL ALARM)
05-003		RADIO INSTAL
05-004		HEATER ASSY (WITH HEATER)
05-005		HEATER ASSY (WITHOUT HEATER)
05-006		ALARM ASSY (TRAVEL ALARM)
05-007		DOZER ASSY
05-008		HOOK INSTAL
06-001	01	NAME PLATE INSTAL, P/N PW22T00083F1
06-001	02	NAME PLATE INSTAL, P/N PW22T00083F1
06-002		NAME PLATE INSTAL, P/N PM22T00064F1
06-003		NAME PLATE INSTAL, P/N PW22T00116F1
06-004		NAME PLATE INSTAL, P/N PV22T00106F1
06-005		NAME PLATE INSTAL, P/N PV22T00107F1
06-006		NAME PLATE INSTAL, P/N PW22T00181F1
06-007		NAME PLATE INSTAL, P/N PW22T00174F1
06-008		NAME PLATE INSTAL (DECEL), P/N PW22T00088F1
06-009		NAME PLATE INSTAL, P/N PW22T00183F1
06-010		NAME PLATE INSTAL (CAB), P/N PV22T00113F1
06-011		NAME PLATE INSTAL (CAB), P/N PW22T00207F1
06-012		NAME PLATE INSTAL, P/N PV22T00101F1
06-013		NAME PLATE INSTAL (JOHN-DEERE), P/N PW22T00172F1
06-014		NAME PLATE INSTAL, P/N PW22T00087F1
06-015		NAME PLATE INSTAL (ATTACHMENTS), P/N PW22T00184F1
07-001	01	VALVE ASSY, CONTROL
07-001	02	VALVE ASSY, CONTROL
07-002		VALVE ASSY, CONTROL (DOZER)
07-003		VALVE ASSY, CONTROL (SLEWING)
07-004		VALVE ASSY, CONTROL (SUPPLY & STRAIGHT TRAVEL)
07-005		VALVE ASSY, CONTROL (ARM)
07-006		VALVE ASSY, CONTROL (SERVICE)
07-007		VALVE ASSY, CONTROL (BOOM SWING)
07-008		VALVE ASSY, CONTROL (TRAVEL RIGHT)
07-009		VALVE ASSY, CONTROL (SUPPLY)
07-010		VALVE ASSY, CONTROL (TRAVEL LEFT)
07-011		VALVE ASSY, CONTROL (BOOM)
07-012		VALVE ASSY, CONTROL (BOOM LOCK)
07-013		VALVE ASSY, CONTROL (BUCKET)
07-014		VALVE ASSY, OVERLOAD RELIEF
07-015		VALVE ASSY, ANTICAVITATION
07-016		PLUG ASSY
07-017		VALVE ASSY, RELIEF, P/N PR22V00004F1

MidWestTech | Kobelco SK27SR-3 Hydraulic Excavator Parts Catalog | Publication S3PV0... Order the manual at mid-west-tech.com >

CYLINDER ASSY, BOOM (CAB)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
32		(PM01V00060S031)		1	BUSHING, (FOR F2 ONLY)
		PV01V00053R100		1	REPAIR KIT, CONSISTS OF REF 1(1), 2(1), 28(2) (FOR F1 ONLY)
		PM01V00060R200		1	KIT, REPAIR, CONSISTS OF REF 2(1), 3(1), 28(2) (FOR F1 ONLY)
		PV01V00051R300		1	KIT, REPAIR, CONSISTS OF REF 6(1), 7(1), 8(1), 9(1), 10(1), 15(1), 16(1), 18(1), 19(2)
		(PV01V00053R400)		1	REPAIR KIT, CONSISTS OF REF 2(1), 30(1), 28(2) (FOR F2 ONLY)
		PM01V00060R400		1	SPARE PART, REPAIR KIT, CONSISTS OF REF 2(1), 31(1), 28(2) (FOR F2 ONLY)

MidWestTech | Kobelco SK27SR-3 Hydraulic Excavator Parts Catalog | Publication S3PV0... Order the manual at mid-west-tech.com >

GEAR HOUSING

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{719802-01500}		1	HOUSING ASSY, GEAR
4		{23876-030000}		1	PLUG PT3/8, SCREW
6		{129795-01800}		1	SEAL, OIL
7		{119802-32100}		1	COVER ASSY, PUMP
8		{119802-32070}		1	COVER, LUB. OIL PUMP
9		{129900-32130}		1	VALVE, RELIEF
10		{129418-32320}		1	SPRING
11		{129001-32330}		1	PLUG
12		{119802-01520}		1	FRANGE, GEAR CASE
13		{119802-01560}		3	STUD, M8 X 25
14		{124160-01751}		1	COVER, FILLER
15		{124240-01871}		1	COVER, HO-P
16		{129795-01950}		2	PIPE, KNOCK L=18
17		{119609-32040}		4	O-RING P16
18		{119802-32111}		1	ROTOR, INNER
19		{119802-32120}		1	ROTOR, OUTER
20		{119802-32130}		7	SCREW, M6 X 16
21		{121850-51960}		1	O-RING, F. I. PUMP
22		{129001-91841}		3	BOLT, M8 X 85
23		{24311-000320}		1	O-RING 1A P-32.0
24		{26106-080162}		4	BOLT M8 X 16 PLATED
25		{26106-080162}		3	BOLT M8 X 16 PLATED
26		{26106-080552}		12	BOLT M8 X 55 PLATED
27		{26306-080002}		3	NUT
28		{121023-01550}		1	COVER, BLIND
29		{24341-000240}		1	O-RING 1A S-24.0
30		{26106-060162}		2	BOLT M6 X 16 PLATED
31	1	{977770-01212}		1	GASKET, LIQUID

(1) OPTIONAL PART

SK27SR-3

MidWestTech | Kobelco SK27SR-3 Hydraulic Excavator Parts Catalog | Publication S3PV0... Order the manual at mid-west-tech.com >

FUEL INJECTION VALVE

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{729646-53100}		3	FUEL INJECTOR WCM
2		{129646-53000}		3	NOZZLE ASSY
5		{114250-53080}		3	NUT, NOZZLE CASE
6		{119802-53100}		3	HOLDER ASSY, NOZZLE
10		{114250-53120}		3	SPRING, NOZZLE
11		{114250-53130}		3	SEAT, NOZZLE SPRING
12		{114250-53140}		3	PLATE, STOP
13		{114250-53210}		6	PIN
14		{114250-53400}		3	SHIM PACK
26		{119305-59120}		1	RETAINER
29		{129150-59131}		1	BOLT, M4 X 14, HEX. SCKT.
30		{129150-59120}		1	RETAINER, INJ. PIPE
33		{129150-59131}		2	BOLT, M4 X 14, HEX. SCKT.
35		{119802-59810}		1	PIPE ASSY, INJECTION
39		{119802-59820}		1	PIPE ASSY, INJECTION
43		{119802-59830}		1	PIPE ASSY, INJECTION
48		{119802-59550}		1	PIPE ASSY, RETURN
49		{124722-59050}		2	CLAMP 9
50		{119802-59560}		1	PIPE, FUEL RETURN
51		{129486-59551}		2	PIPE, FUEL RETURN
52		{124722-59050}		4	CLAMP 9
54		{119593-59580}		1	CAP
55		{124060-77680}		1	CLAMP 10

MidWestTech | Kobelco SK27SR-3 Hydraulic Excavator Parts Catalog | Publication S3PV0... Order the manual at mid-west-tech.com >