CX27B Compact Crawler Excavator Tier IV

ASN PV13-33001 (ASN N7TN41480)

Parts Catalog

Print No. S3PV00030ZE02
Issued 6/2010
Replaces S3PV00030ZE01

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE SEQ.
ALARM ASSY (TRAVEL ALARM)	05-006
ARM ASSY 1.12 M (REINFORCE TYPE)	03-007
ARM ASSY, LONG 1.37M	05-008
BATTERY INSTAL	01-074
BLOCK ASSY	07-025
BOOM ASSY, STD 2.15M	03-001
BRACKET ASSEMBLY, SWING (NIBBLER & BREAKER)	01-002
BUCKET INSTAL	03-009
CAB ASSY	01-048
CAB ASSY	01-050
CAB ASSY	01-049
CAB ASSY, P/N PW02C00068F1	01-046
CAB ASSY, P/N PW50C00002F1	01-047
CAB INSTAL	01-044
CAB INSTAL	01-045
CAMSHAFT & DRIVING GEAR	08-007
CANOPY ASSY	01-055
CANOPY INSTAL	01-056
CLEANER ASSY, AIR	01-008
CLEANER ASSY, AIR (W ELEMENT)	01-009
CONTROL ASSEMBLY ENGINE (WITH DECAL), P/N PM11M00008F1	01-016
CONTROL ASSEMBY ENGINE (WITH DECAL) , P/N PH51M00011F1	01-017
CONTROL BOX ASSY (LEFT HAND)	01-030
CONTROL LINES REMOTE	01-038
CONTROL LINES, PROPEL (NIBBLER & BREAKER + TRAVEL ALARM)	05-002
CONTROL LINES, REMOTE (DOZER)	01-037
CONTROL LINES, REMOTE (MULTI)	01-036
CONTROL LINES, REMOTE (NIBBLER & BREAKER)	01-034
CONTROL LINES, REMOTE (NIBBLER &BREAKER)	01-035
CONTROL LINES, REMOTE , P/N PX35V00003F1	01-039
CONTROL LINES, VALVE	01-041
CONTROL LINES, VALVE	01-040
CONTROLS, OPERATORS	01-027
COOLING WATER SYSTEM	08-010
COUNTERWEIGHT INSTAL	01-003
COUNTERWEIGHT INSTAL (GAIN)	05-001
COVER ASSY	01-028
COVER ASSY	07-027
CRANKSHAFT & PISTON	08-008
CYINDER INSTAL (CANOPY)	03-004
CYLINDER ASSY, ARM	07-032
CYLINDER ASSY, BOOM, P/N PV01V00061F1	07-030
CYLINDER ASSY, BOOM, P/N PV01V00064F1	07-031
CYLINDER ASSY, BUCKET	07-033
CYLINDER ASSY, DOZER	07-034
CYLINDER ASSY, SWING	07-035
CYLINDER BLOCK	08-001
CYLINDER HEAD & BONNET	08-004
CYLINDER INSTAL (CAB)	03-005
DOOR ASSY, CAB	01-053
DOZER ASSY	05-007
DOZER ASSY	02-011
ELEC ASSY, UPP	01-075
ENGINE ASSY	01-004
ENGINE INSTAL	01-005
EXHAUST MANIFOLD	08-006

MidWestTech | Case CX27B Tier IV Compact Crawler Excavator Parts Catalog | Publicatio... Order the manual at mid-west-tech.com >

FILTER LIST	00-001
FLYWHEEL HOUSING & LUB. OIL SUMP	08-003
FRAME ASSEMBLY, UPPER	01-001
FUEL INJECTION PUMP	08-011
FUEL INJECTION PUMP, (VV71994051340)	08-017
FUEL INJECTION VALVE	08-012
FUEL LINE	08-013
FUEL LINES	01-011
GASKET SET	08-016
GAUGE ASSY, CLUSTER	01-073
GEAR HOUSING	08-002
GENERATOR	08-015
GOVERNOR	08-018
GRIP ASSY	01-029
GUARD ASSY, HEAD	01-051
GUARD INSTAL (CAB)	01-071
GUARD INSTAL (CAB)	01-070
GUARD INSTAL (CAB), P/N PM21C00024F1	01-067
GUARD INSTAL (CAB), P/N PM21C01588F1	01-068
GUARD INSTAL (CANOPY)	01-065
GUARD INSTAL (CANOPY)	01-066
GUARD INSTAL (CANOPY)	01-063
GUARD INSTAL (CANOPY), P/N PM21C01588F1	01-064
HARNESS ASSY	01-078
HARNESS ASSY (CLEANER AIR)	01-077
HARNESS ASSY, CAB	01-076
HARNESS ASSY, ENGINE	01-079
HOLDER ASSY	01-057
HOLDER ASSY	01-054
HOOK INSTAL	05-012
HOOK INSTAL	05-011
HOSE ASSY, (WITHOUT HEATER)	05-005
HOSE ASSY, HEATER (WITH HEATER)	05-004
HYD LINES ARM 1.12M (3FT 8 IN)	03-008
HYD LINES RETURN	01-026
HYD LINES, ARM 1.37M	05-009
HYD LINES, ARM 1.37M (NIBBLER & BREAKER)	05-010
HYD LINES, BOOM 2.15 M (NIBBLER & BREAKER)	03-003
HYD LINES, BOOM 2.15M	03-002
HYD LINES, CYLINDER (SWING)	01-020
HYD LINES, LOW	02-010
HYD LINES, PUMP	01-022
HYD LINES, UPP	01-023
HYD LINES, UPP	01-024
HYD LINES, UPP (NIBBLER & BREAKER)	01-025
IDLER ADJUST ASSY	02-005
IDLER ASSY	02-004
IDLER ASSY, CRAWLER	02-003
JOINT ASSY, SWIVEL	07-045
KEY ASSY	01-072
LEVER ASSY, CONTROL	01-033
LIGHT ASSY, P/N PM80S00008F1	01-061
LIGHT ASSY, P/N PW80S00003F1	01-059
LIGHT ASSY, P/N PW80S00004F1	01-060
LIGHT INSTAL (BOOM)	03-006
LIGHT INSTAL (CAB)	01-058
LOW GROUP	02-001
LUB. OIL SYSTEM	08-009

Order the manual at mid-west-tech.com >

MOTOR ASSY (PROPELLING), (PM15V00021F1), PAGE 1 OF 2	07-021	
MOTOR ASSY (PROPELLING), (PM15V00021F1), PAGE 2 OF 2	07-022	
MOTOR ASSY (SLEWING)	07-019	
MOTOR INSTAL, SLEWING	01-019	
MUFFLER ASSEMBLY	01-010	
NAME PLATE INSTALL (LIFTING CAPACITES)	06-024	00
NAME PLATE INSTALL (LIFTING CAPACITES) (LONG ARM)	06-026	00
NAME PLATE INSTALL (LIFTING CAPACITES) (LONG ARM) (CANOPY)	06-025	00
NAME PLATE INSTALLATION (ATTACHMENTS) (PV22T00100F1)	06-021	00
NAME PLATE INSTALLATION (CAB) (PM22T00048F1)	06-013	00
NAME PLATE INSTALLATION (CAB) (PW22T00085F1)	06-014	00
NAME PLATE INSTALLATION (DECEL) (PW22T00113F1)	06-009	00
NAME PLATE INSTALLATION (ISO) (PW22T00114F1)	06-019	00
NAME PLATE INSTALLATION (JOHN DEERE) (PW22T00172F1)	06-018	00
NAME PLATE INSTALLATION (NIBBLER & BREAKER) (PW22T00087F1 & PW22T00087F2)	06-020	00
NAME PLATE INSTALLATION (PM22T00049F1)	06-023	00
NAME PLATE INSTALLATION (PM22T00050F1)	06-008	00
NAME PLATE INSTALLATION (PM22T00095F1)	06-005	00
NAME PLATE INSTALLATION (PV22T00083F1)	06-017	00
NAME PLATE INSTALLATION (PW22T00083F3), PAGE 1 OF 2	06-001	01
NAME PLATE INSTALLATION (PW22T00083F3), PAGE 2 OF 2	06-001	02
NAME PLATE INSTALLATION (PW22T00117F1)	06-004	00
NAME PLATE INSTALLATION (PW22T00123F1)	06-003	00
NAME PLATE INSTALLATION (PW22T00169F1)	06-002	00
NAME PLATE INSTALLATION (PW22T00173F1)	06-007	00
NAME PLATE INSTALLATION (PW22T00181F1)	06-006	00
NAME PLATE INSTALLATION (PW22T00182F1)	06-011	00
NAME PLATE INSTALLATION (PW22T00183F1)	06-010	00
NAME PLATE INSTALLATION (STD ARM FOR CANOPY) (PV22T00109F1)	06-022	00
NAME PLATE INSTALLATION (YN22T00288F1)	06-012	00
NUT	00-003	
PAINT COLOR	00-004	
PLATE GROUP FLOOR (CAB)	01-043	
PLATE GROUP FLOOR (CANOPY)	01-042	
POWER TAKE-OFF ASSY	01-018	
PUMP ASSY , P/N PM10V00017F1	07-023	
PUMP ASSY , P/N PX10V00015F1	07-028	
PUMP ASSY, GEAR	07-029	
RADIATOR ASSY	01-007	
RADIATOR INSTAL	01-006	
RADIO INSTAL	05-003	
RELAY ASSY	01-080	
RING ASSY, SLEWING	02-002	
ROLLER ASSY, TRACK	02-006	
ROLLER ASSY, UPP	02-007	
ROTARY ASSY	07-026	
SEAT INSTAL	01-062	
SHAFT ASSY	07-024	
SHOE ASSY	02-009	
SHOE ASSY, P/N PV60D00008F1	02-008	
SLEEVE	00-002	
STAND ASSY, CONTROL (CANOPY)	01-031	
STAND ASSY, CONTROL (CAB)	01-032	
STARTING MOTOR	08-014	
SUCTION MANIFOLD	08-005	
TANK ASSEMBLY HYD (NIBBLER & BREAKER)	01-015	
TANK ASSEMBLY, FUEL (CANOPY)	01-012	

Order the manual at mid-west-tech.com >