NEW HOLLAND

COMPACT CRAWLER EXCAVATOR

E27BSR TIER 4 INTERIM

PARTS CATALOG

ASN PV13-33001~

S3PV00031ZE01 NA

Issued 01Jan 08

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001	FILTER LIST
00-002	SLEEVE
00-003	NUT
00-004	PAINT COLOR
01-001	FRAME ASSY, UPP
01-002	BRACKET ASSY, SWING (NIBBLER & BREAKER)
01-003	COUNTERWEIGHT INSTAL
01-004	ENGINE ASSY
01-005	ENGINE INSTAL
01-006	RADIATOR INSTAL
01-007	RADIATOR ASSY
01-008	CLEANER ASSY, AIR
01-009	CLEANER ASSY, AIR (W ELEMENT)
01-010	MUFFLER ASSY
01-011	FUEL LINES
01-012	TANK ASSY, FUEL (CANOPY)
01-013	TANK ASSY, FUEL (CAB)
01-014	TANK ASSY, HYD (NIBBLER & BREAKER)
01-015	CONTROL ASSY, ENGINE (WITH DECEL)
01-016	CONTROL ASSY, ENGINE (WITH DECEL) PH51M00011F1
01-017	POWER TAKE-OFF ASSY
01-018	MOTOR INSTAL, SLEWING
01-019	HYD LINES, CYLINDER (SWING)
01-020	VALVE INSTAL
01-021	HYD LINES, PUMP
01-022	HYD LINES, UPP
01-023	HYD LINES, UPP
01-024	HYD LINES, UPP (NIBBLER & BREAKER)
01-025	HYD LINES, RETURN
01-026	CONTROLS, OPERATORS
01-027	COVER ASSY
01-028	GRIP ASSY
01-029	CONTROL BOX ASSY (LEFT HAND)
01-030	STAND ASSY, CONTROL (CANOPY)
01-031	STAND ASSY, CONTROL (CAB)
01-032	LEVER ASSY, CONTROL
01-033	CONTROL LINES, REMOTE (NIBBLER & BREAKER)
01-034	CONTROL LINES, REMOTE (NIBBLER AND BREAKER)
01-035	CONTROL LINES, REMOTE (NIBBLER & BREAKER)
01-036	CONTROL LINES, REMOTE (DOZER)
01-037	CONTROL LINES, REMOTE
01-038	CONTROL LINES, REMOTE PX35V00003F1
01-039	CONTROL LINES, VALVE
01-040	CONTROL LINES, VALVE
01-041	PLATE GROUP, FLOOR (CANOPY)
01-042	PLATE GROUP, FLOOR (CAB)
01-043	CAB INSTAL
01-044	CAB INSTAL
01-045	CAB ASSY PW02C00068F1
01-046	CAB ASSY PW50C00002F1
01-047	CAB ASSY

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-048		CAB ASSY
01-049		CAB ASSY
01-050		GUARD ASSY, HEAD
01-051		WINDOW ASSY, FR.
01-052		DOOR ASSY, CAB
01-053		HOLDER ASSY
01-054		CANOPY ASSY
01-055		CANOPY INSTAL
01-056		HOLDER ASSY
01-057		LIGHT INSTAL (CAB)
01-058		LIGHT ASSY
01-059		LIGHT ASSY PW80S00004F1
01-060		LIGHT ASSY PM80S00008F1
01-061		SEAT INSTAL
01-062		GUARD INSTAL
01-063		GUARD INSTAL (CANOPY) PM21C01588F1
01-064		GUARD INSTAL (CANOPY)
01-065		GUARD INSTAL
01-066		GUARD INSTAL (CAB)
01-067		GUARD INSTAL (CAB) PM21C01588F1
01-068		GUARD INSTAL
01-069		GUARD INSTAL
01-070		KEY ASSY
01-071		GAUGE ASSY, CLUSTER
01-072		BATTERY INSTAL
01-073		ELEC ASSY, UPP
01-074		HARNESS ASSY, CAB
01-075		HARNESS ASSY (CLEANER AIR)
01-076		HARNESS ASSY
01-077		HARNESS ASSY, ENGINE
01-078		RELAY ASSY
02-003		IDLER ASSY, CRAWLER
02-001		LOW GROUP
02-002		RING ASSY, SLEWING
02-004		IDLER ASSY
02-005		IDLER ADJUST ASSY
02-006		ROLLER ASSY, TRACK
02-007		ROLLER ASSY, UPP
02-008		SHOE ASSY
02-009		SHOE ASSY PV61D00018F1
02-010		HYD LINES, LOW
02-011		DOZER ASSY
03-001		BOOM ASSY, STD 2.15M
03-002	01	HYD LINES, BOOM 2.15M
03-003		HYD LINES, BOOM 2.15M (NIBBLER AND BREAKER)
03-004		CYLINDER INSTAL (CANOPY)
03-005		CYLINDER INSTAL (CAB)
03-006		LIGHT INSTAL (BOOM)
03-007		ARM ASSY 1.12M (REINFORCE TYPE)
03-008		HYD LINES, ARM 1.12M (3FT 8IN)
03-009		BUCKET INSTAL

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

04-001		TOOL & ACCESSORY
05-001		COUNTERWEIGHT INSTAL (GAIN)
05-002		CONTROL LINES, PROPEL (NIBBLER AND BREAKER + TRAVEL ALARM)
05-003		RADIO INSTAL
05-004		HOSE ASSY, HEATER (WITH HEATER)
05-005		HOSE ASSY, HEATER (WITHOUT HEATER)
05-006		ALARM ASSY (TRAVEL ALARM)
05-007		DOZER ASSY
05-008		HOOK INSTAL
05-009		HOOK INSTAL
06-001	01	NAME PLATE INSTAL (PW22T00083F2), PAGE 1 OF 2
06-001	02	NAME PLATE INSTAL (PW22T00083F2), PAGE 2 OF 2
06-002		NAME PLATE INSTAL (PW22T00123F1)
06-003		NAME PLATE INSTAL (PW22T00117F1)
06-004		NAME PLATE INSTAL (PM22T00095F1)
06-005		NAME PLATE INSTAL (PV22T00111F3)
06-006		NAME PLATE INSTAL (PW22T00112F1)
06-007		NAME PLATE INSTAL (PW22T00181F1)
06-008		NAME PLATE INSTAL (PW22T00185F1)
06-009		NAME PLATE INSTAL (PW22T00113F1)
06-010		NAME PLATE INSTAL (PW22T00183F1)
06-011		NAME PLATE INSTAL (PW22T00182F1)
06-012		NAME PLATE INSTAL (YN22T00286F1)
06-013		NAME PLATE INSTAL (PH22T00094F1)
06-014		NAME PLATE INSTAL (PW22T00085F1)
06-015		NAME PLATE INSTAL (PM22T00081F2)
06-016		NAME PLATE INSTAL (ATTACHMENTS) (PV22T00099F2)
06-016	01	NAME PLATE INSTAL (MODEL) (PV22T00132F1)
06-017		NAME PLATE INSTAL (PW22T00172F1)
06-018		NAME PLATE INSTAL (ISO) (PW22T00114F1)
06-019		NAME PLATE INSTAL (NIBBLER & BREAKER) (PW22T00087F1 & PW22T00087F2)
06-020		NAME PLATE INSTAL (ATTACHMENTS) (PV22T00099F2)
06-021		NAME PLATE INSTAL (PW22T00169F1)
07-001		VALVE ASSY, CONTROL PM30V00052F1
07-002		VALVE ASSY, CONTROL
07-003		VALVE ASSY, CONTROL (DOZER)
07-004		VALVE ASSY, CONTROL (SLEWING)
07-005		VALVE ASSY, CONTROL (BOOM SWING)
07-006		VALVE ASSY, CONTROL (SERVICE)
07-007		VALVE ASSY, CONTROL (TRAVEL RIGHT)
07-008		VALVE ASSY, CONTROL (INLET)
07-009		VALVE ASSY, CONTROL (TRAVEL LEFT)
07-010		VALVE ASSY, CONTROL (BOOM)
07-011		VALVE ASSY, CONTROL (BOOM LOCK)
07-012		VALVE ASSY, CONTROL (BUCKET)
07-013		VALVE ASSY, CONTROL
07-014		VALVE ASSY, CONTROL
07-015		VALVE ASSY, OVERLOAD RELIEF
07-016		VALVE ASSY, RELIEF
07-017		VALVE ASSY, RELIEF
07-018		MOTOR ASSY (SLEWING)

Order the manual at mid-west-tech.com >

CYLINDER ASSY, DOZER

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		PV01V00047F1		AR	CYLINDER, CYLINDER ASSY,DOZER
		{PV01V00047F2}		AR	
1		NSS		1	NOT SERVICED SEPARATELY, TUBE,CYLINDER
2		PM01V00045S002		2	BUSHING
3		NSS		AR	NOT SERVICED SEPARATELY, ROD
4		PV01V00047S004		AR	CYLINDER HEAD
5		2438U1169S4		AR	BUSHING, LARGE, (F1 ONLY)
6		2438U635S3		AR	RING, U
7		PH01V00006S006		AR	WIPER, RING
8		ZD12G08000		1	O-RING
9		PX01V00030S008		1	BACK-UP RING
10		ZD12G08500		1	O-RING
11		PV01V00047S011		1	PISTON
12		YR01V00003S014		1	SEAL, RING
13		PX01V00030S017		2	RING, SLIDE
14		2438U1057S16		1	VALVE, HYDRAULIC, SETSCREW
15		2436U946S11		1	BALL
16		ZG91S02000		1	NIPPLE, LUBE
17		ZG91U02000		1	NIPPLE, LUBE
18		PR01V00002S027		4	SEAL, DUST
19		{PV01V00047S019}		1	(F2 ONLY)
		PV01V00047R100		1	KIT, REPAIR, PISTON SIDE CONSISTS OF REF. 1(1), 2(1), 18(2)
		PV01V00047R200		1	KIT, REPAIR, ROD SIDE CONSISTS OF REF. 2(1), 3(1), 18(2)
		PV01V00047R300		1	KIT, REPAIR, CONSISTS OF REF. 6(10, 7(1), 8(10, 9(1), 10(1), 12(10, 13(2)

MidWestTech | New Holland E27BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >

CYLINDER BLOCK

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		{719802-01560}		1	ASSY, CYLINDER
4		{124160-01910}		2	PT1/4
5		{171051-01921}		1	
6		{124060-01050}		1	PT1/8
7		{129001-01250}		1	50
8		{27241-120000}		2	12
9		{27241-300000}		6	30
12		{119620-02020}		8	
13		{129795-02411}		1	BUSH
14		{124160-01910}		1	PT1/4
24		{719810-02980}		4	MAIN (STD) (3) REPAIR PART.
27		{119810-02930}		1	THRUST
30		{119810-01200}		14	CYL. HEAD
31		{119812-01330}		1	HEAD
32		{119810-02870}		4	MAIN BEARING US=O. 25 (1) UNDER-SIZE UNDER-SIZE
35		{119810-02940}		2	THRUST . 250S (2) OVER-SIZE (0. S=25) PART.
38		{119802-01190}		1	

MidWestTech | New Holland E27BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >

GOVERNOR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
2		{158553-61050}		1	PACKING, CASE
3		{158553-61070}		1	PACKING
5		{129155-51280}		1	S6
21		{129255-61410}		1	
22		{119807-61420}		1	
23		{158552-61441}		1	LEVER, REGULATOR
24		{129155-61460}		1	IDLE LIMIT
53		{26106-060102}		1	M6X10 PLATED
59		{119660-61901}		1	RETAINER, SHAFT
63		{22190-120000}		1	WASHER MI 2 (BOLT)
65		{23887-120002}		1	MI 2, HEX.
67		{26106-060102}		1	M6X10 PLATED
68		{26756-060002}		1	NUT M6
82		{24341-000280}		1	1A S-28.0
83		{26106-060142}		2	M6X14 PLATED
84		{26106-060142}		4	M6X14 PLATED
85		{26106-060202}		10	H6X20 PLATED
96		{119233-77932}		1	STOP
97		{129642-61060}		1	CASE

MidWestTech | New Holland E27BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >