PROFESSIONAL PARTNER

PARTS CATALOG
COMPACT CRAWLER EXCAVATOR

CX27B
TIER 4

ASN PV13-33292~

S3PV00034ZE01 NA

Issued 01Nov 08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001	FILTER LIST
00-002	SLEEVE
00-003	NUT
00-004	PAINT COLOR
01-001	FRAME ASSY, UPPER (PM52F00041F1, PM24C00006F1)
01-002	BRACKET ASSY, SWING (NIBBLER & BREAKER) (PV02B00169F1, PM02B00162F1, PV02B00145F1)
01-003	COUNTERWEIGHT INSTAL (PV60C00010F1)
01-004	ENGINE ASSY (PM02P00016F1)
01-005	ENGINE INSTAL (PM02P00017F1, PM02P00012F1)
01-006	RADIATOR INSTAL (PM05P00014F1, PM05P00015F1)
01-007	RADIATOR ASSY (PM05P00016F1, PM05P01121F1)
01-008	CLEANER ASSY, AIR (PM11P00014F1)
01-009	CLEANER ASSY, AIR (W ELEMENT) (PM11P00015F1)
01-010	MUFFLER ASSY (PV12P00003F1)
01-011	FUEL LINES (PM21P00006F1)
01-012	TANK ASSY, FUEL (CANOPY) (PM20P00009F1, PM20P00019F1)
01-014	TANK ASSY, FUEL (CAB) (PM20P00009F,PM20P00018F1)
01-015	TANK ASSY HYDRAULICS (NIBBLER & BREAKER) (PM33H00037F1, PM33H00026F1)
01-016	CONTROL ASSY, ENGINE (WITH DECEL) 1 OF 2 (PM11M00008F1)
01-017	CONTROL ASSY, ENGINE (WITH DECEL) 2 OF 2 (PM11M00008F1)
01-018	POWER TAKE-OFF ASSY (PM30P00006F1)
01-019	MOTOR INSTAL, SLEWING (PM32W00007F1)
01-020	HYDRAULIC LINES, CYLINDER (SWING) (PM42H00028F1, PM71H00001F1)
01-021	VALVE INSTAL (PM64H00051F1)
01-022	HYDRAULIC LINES, PUMP (PM30H00006F1)
01-023	HYDRAULIC LINES, UPPER 1 OF 2 (PM03H00018F1)
01-024	HYDDRAULIC LINES, UPPER 2 OF 2 (PM03H00018F1, PM19H00011F1)
01-025	HYDRAULIC LINES, UPPER (NIBBLER & BREAKER) (PM03H00019F1)
01-026	HYDRAULIC LINES RETURN (PM32H00006F1)
01-027	CONTROLS, OPERATORS (PW03M00092F1)
01-028	COVER ASSY (PW03M01702F1)
01-029	GRIP ASSY (PW03M01954F1, PW03M01718F1)
01-030	CONTROL BOX ASSY (LEFT HAND) (PW03M00093F1)
01-031	STAND ASSY, CONTROL (CANOPY) (PM03M00058F1, PW03M01715F1)
01-032	STAND ASSY, CONTROL (CAB) (PM03M00059F1, PW03M01716F1)
01-033	LEVER ASSY, CONTROL (PH50M00011F1, PM55M00019F1)
01-034	CONTROL LINES, REMOTE (NIBBLER & BREAKER) 1 OF 2 (PW64H00037F1, PW64H00038F1, PV68H00018F1)
01-035	CONTROL LINES, REMOTE (NIBBLER &BREAKER) 2 OF 2 (PV68H00018F1)
01-036	CONTROL LINES, REMOTE (MULTI) (PM06H00009F1, PV64H00017F1, PV64H00019F1)
01-037	CONTROL LINES, REMOTE (DOZER) (PM68H00021F1)
01-038	CONTROL LINES REMOTE 1 OF 2 (PM62H00010F1, PM64H00048F1)
01-039	CONTROL LINES, REMOTE 2 OF 2 (PM64H00048F1)
01-041	CONTROL LINES, VALVE (PROPORTIONAL) (PV64H00022F1)
01-042	PLATE GROUP FLOOR (CANOPY) (PM03M00063F1)
01-043	PLATE GROUP FLOOR (CAB) (PM03M00062F1)
01-044	CAB INSTAL 1 OF 2 (PM02C00036F1, PW02C00050F1%K2)
01-045	CAB INSTAL 2 OF 2 (PM02C00035F1)
01-046	CAB ASSY 1 OF 5 (PW02C00068F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-047	CAB ASSY 2 OF 5 (PW02C00068F1)
01-048	CAB ASSY 3 OF 5 (PW02C00068F1)
01-049	CAB ASSY 4 OF 5 (PW02C00068F1)
01-050	CAB ASSY 5 OF 5 (PW02C00068F1)
01-051	GUARD ASSY, HEAD (PW25C00003F1)
01-052	WINDOW ASSY, FRONT (PW50C00002F1)
01-053	DOOR ASSY, CAB (PM51C00006F1%LD)
01-054	HOLDER ASSY (PW02C01344F1)
01-055	CANOPY ASSY (PW06C00036F1, PW80E00006F1, PW22T00169F1)
01-056	CANOPY INSTAL (PW06C00022F1)
01-057	HOLDER ASSY (PM21C01575F1)
01-058	LIGHT INSTAL (CAB) (PW80E00007F1)
01-059	LIGHT ASSY (PWB0S00003F1)
01-060	LIGHT ASSY (PW80S00004F1)
01-061	LIGHT ASSY (PM80S00008F1)
01-062	SEAT INSTAL (PW25M00029F1)
01-063	GUARD INSTAL (CANOPY) 1 OF 4 (PM21C00022F1)
01-064	GUARD INSTAL (CANOPY) 2 OF 4 (PM21C00022F1)
01-065	GUARD INSTAL (CANOPY) 3 OF 4 (PM21C00022F1)
01-066	GUARD INSTAL (CANOPY) 4 OF 4 (PM21C00022F1)
01-067	GUARD INSTAL (CAB) 1 OF 4 (PM21C00024F1)
01-068	GUARD INSTAL (CAB) 2 OF 4 (PM21C00024F1)
01-070	GUARD INSTAL (CAB) 3 OF 4 (PM21C00024F1)
01-071	GUARD INSTAL (CAB) 4 OF 4 (PM21C00024F1)
01-072	KEY ASSY (PW03M01870F1, PW22T00112F1)
01-073	GAUGE ASSY, CLUSTER (PH59S00005F1)
01-074	BATTERY INSTAL (PW72E00011F1)
01-075	ELEC ASSY, UPPER (PM03E00010F1)
01-076	HARNESS ASSY, CAB (PW14E00002F1)
01-077	HARNESS ASSY (CLEANER AIR) (PM11E00005F1)
01-078	HARNESS ASSY (PRPORTIONAL) 1 OF 2 (PH11E00021F1)
01-079	HARNESS ASSY (PROPORTIONAL) 2 OF 2 (PH11E00021F1)
01-080	HARNESS ASSY, ENGINE (PM16E00005F1)
01-081	RELAY ASSY (PM24E00046F1)
02-001	LOW GROUP (PV01F00005F1, PV53D00008F1, PM19H00009F2)
02-002	RING ASSY, SLEWING (PM40F00013F1)
02-003	IDLER ASSY, CRAWLER (PV52D00005F1)
02-004	IDLER ASSY (PV52D00013F1, PV52D00014F1)
02-005	IDLER ADJUST ASSY (PV54D00008F1)
02-006	ROLLER ASSY, TRACK (PV64D00013F1)
02-007	ROLLER ASSY, UPPER (PW64D00008F1)
02-008	SHOE ASSY (PV60D00008F1)
02-009	SHOE ASSY (PV61D00018F1)
02-010	HYDRAULIC LINES, LOW (PV02H00006F1, PV19H00006F1, PM12H00002F1, PM13H00001F1)
02-011	DOZER ASSY (PV51B00059F1,PV51B00055F1, PW51B00028F1, PX51B00072F1)
03-001	BOOM ASSY, STD 2.15M (PV02B00178F1, PM02B00163F1, PV02B00183F1)
03-002	HYDRAULIC LINES, BOOM 2.15M (PV42H00039F1, PV42H00022F1, PV42H00041F1, PV42H00042F1)
03-003	HYDRAULIC LINES, BOOM 2.15 M (NIBBLER & BREAKER) (PV42H00021F1, PV43H00010F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-004	CYINDER INSTAL (CANOPY) (PV02B00167F1, PV02B00154F1)
03-005	CYLINDER INSTAL (CAB) (PV02B00166F1, PV02B00154F1)
03-006	LIGHT INSTAL (BOOM) (PW80E00012F1, PM15E00004F1)
03-007	ARM ASSY 1.12 M (REINFORCE TYPE) (PV12B00101F1, PV12B00120F1, PM12B00137F1)
03-008	HYDRAULIC LINES ARM 1.12M (3FT 8 IN) (PV43H00014F1, PV12B00113F1, PM43H00021F1)
03-009	BUCKET INSTAL (PM61B00030F2)
04-001	TOOL AND ACCESSORY (PM01T00002FA)
05-001	COUNTERWEIGHT INSTAL (GAIN) (PM60C00023F2)
05-003	RADIO INSTAL (PW54E00002F1, PM54E00003F2)
05-004	HOSE ASSY, HEATER (WITH HEATER) (PM21M00017F1)
05-005	HOSE ASSY, (WITHOUT HEATER) (PM21M00012F1)
05-006	ALARM ASSY (TRAVEL ALARM) (PM53E00005F1)
05-007	DOZER ASSY (PV51B00062F1)
05-008	HOOK INSTAL 1 OF 2 (PM71F00004F1)
05-009	HOOK INSTAL 2 OF 2 (PV71F00002F1)
05-010	ARM ASSY, LONG 1.37 M (PV12B00126F1, PV12B00120F1, PM12B00137F1)
05-011	HYD LINES, ARM 1.37M (PV43H00015F1, PV12B00113F1, PM43H00021F1
05-012	HYD LINES, ARM 1.37M (NIBBLER & BREAKER) (PV42H00021F1, PV43H00012F1)
06-001	NAME PLATE INSTALLATION 1 OF 2 (PW22T00083F2)
06-002	NAME PLATE INSTALLATION 2 OF 2 (PW22T00083F2)
06-003	NAME PLATE INSTALLATION (PW22T00123F1)
06-004	NAME PLATE INSTALLATION (PW22T00117F1)
06-005	NAME PLATE INSTALLATION (PM22T00095F1)
06-006	NAME PLATE INSTALLATION (PW22T00111F1)
06-007	NAME PLATE INSTALLATION (PW22T00173F1)
06-008	NAME PLATE INSTALLATION (PM22T00050F1)
06-009	NAME PLATE INSTALLATION (DECEL) (PW22T00113F1)
06-010	NAME PLATE INSTALLATION (PW22T00183F1)
06-011	NAME PLATE INSTALLATION (PW22T00182F1)
06-012	NAME PLATE INSTALLATION (CEMA MARK) (YN22T00288F1)
06-013	NAME PLATE INSTALLATION (CAB) (PM22T00048F1)
06-014	NAME PLATE INSTALLATION (CAB) (PW22T00085F1)
06-015	NAME PLATE INSTAL (GRAPHICS) (PM22T00049F1)
06-016	NAME PLATE INSTALLATION (GRAPHIC) (PW22T00100F1)
06-017	NAME PLATE INSTALLATION (MODEL) (PV22T00083F1)
06-018	NAME PLATE INSTALLATION (WARNING) (PW22T00172F1)
06-020	NAME PLATE INSTALLATION (NIBBLER & BREAKER) (PW22T00087F1 & PW22T00087F2)
06-021	NAME PLATE INSTALLATION (ATTACHMENTS) (PV22T00100F1)
06-022	NAME PLATE INSTALLATION (STD ARM FOR CANOPY) (PV22T00109F1)
06-023	NAME PLATE INSTALLATION (PV22T00110F1)
06-024	NAME PLATE INSTALLATION (LONG ARM) 1 OF 2 (PV22T00144F1)
06-025	NAME PLATE INSTALLATION (LONG ARM) 2 OF 2 (PV22T00145F1)
07-001	VALVE ASSY, CONTROL 1 OF 2 (PM30V00051F1, PM30V00051F2)
07-002	VALVE ASSY, CONTROL 2 OF 2 (PM30V00051F1, PM30V00051F2)
07-003	VALVE ASSY, CONTROL (DOZER) (PM30V00039F1, PM30V00039F2)
07-004	VALVE ASSY, CONTROL (SLEWING) (PM30V00040F1, PM30V00040F2)
07-005	VALVE ASSY, CONTROL (BOOM SWING) (PM30V00043F1)
07-006	VALVE ASSY, CONTROL (SERVICE) (PX30V00052F1, PX30V00052F2)

Order the manual at mid-west-tech.com >