NEW HOLLAND

COMPACT CRAWLER EXCAVATOR

E30BSR TIER 4

PARTS CATALOG

ASN PW14-45964~

S3PW00040ZE01 NA

Issued 01Nov 08

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

MidWestTech | New Holland E30BSR Tier 4 Compact Crawler Excavator Parts Catalog | Publication S3PW00040ZE01

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001		FILTER LIST
00-002		SLEEVE
00-003		NUT
01-001		FRAME ASSY, UPPER (PW52F00047F1)
01-002		BRACKET ASSY, SWING (NIBBLER & BREAKER) (PX02B00148F1, PX02B00147F1, PX02B00149F1)
01-004		COUNTERWEIGHT INSTALLATION (PW60C00020F1, PW60C00013P1, PW60C00019F1)
01-005		ENGINE ASSY
01-006		ENGINE INSTALLATION (PW02P00019F1, PW02P00020F1)
01-007		RADIATOR INSTALLATION (PW05P00042F1, PW05P00047F1)
01-008		RADIATOR ASSY (PW05P00040F1, PW05P01214F1)
01-009	01	CLEANER ASSY, AIR (CAB) (PW11P00027F1,PW11P00028F1)
01-009	02	CLEANER ASSY, AIR (CANOPY) (PW11P00027F1, PW11P00020F1)
01-010		MUFFLER ASSY (PW12P00015F1)
01-011		FUEL LINES (PW21P00009F1)
01-012		TANK ASSY, FUEL (CANOPY) (PW20P00034F1)
01-013		TANK ASSY, FUEL (CAB) (PW20P00033F1)
01-014		TANK ASSY, HYD (NIBBLER & BREAKER) (PW33H00050F1, PW33H00039F1)
01-015		CONTROL ASSY, ENGINE (WITH DECEL) P/N PH51M00011F1 (PW11M00010F1)
01-016		CONTROL ASSY, ENGINE (WITH DECEL) P/N PM20S00009S005
01-017		POWER TAKE-OFF ASSY (PW30P00007F1)
01-018		MOTOR INSTAL, SWING (PW32W00005F1)
01-019		HYD LINES, CYLINDER (SWING) (PX42H00027F1)
01-020		VALVE INSTAL (PW64H00079F1)
01-021		HYD LINES, PUMP (PW30H00007F1)
01-022		HYD LINES, UPP (PW03H00035F1, PW19H00019F1)
01-023		HYD LINES, UPP
01-024		HYD LINES, UPP (PW03H00036F1)
01-025		HYD LINES, RETURN (PW32H00012F1)
01-026		CONTROLS, OPERATORS (PW03M00092F1)
01-027		COVER ASSY (PW03M01702F1)
01-028		GRIP ASSY (PW03M01954F1, PW03M01718F1)
01-029		CONTROL BOX ASSY (LEFT HAND) (PW03M00093F1)
01-030		STAND ASSY, CONTROL (CANOPY) (PW03M00108F1)
01-031		STAND ASSY, CONTROL (CAB) (PW03M00109F1)
01-032		LEVER ASSY, CONTROL (PH50M00011F1, PW55M00015F1)
01-033		CONTROL LINES, REMOTE (NIBBLER & BREAKER) (PW64H00037F1, PW64H00038F1, PW68H00031F1)
01-034		CONTROL LINES, REMOTE (NIBBLER & BREAKER) (PW68H00031F1)
01-035		CONTROL LINES, REMOTE (MULTI) (PW06H00008F1, PW64H00055F1, PW64H00056F1)
01-036		CONTROL LINES, REMOTE (DOZER) (PW68H00043F1)
01-037	01	CONTROL LINES, REMOTE (PW62H00021F1, PW64H00043F1)
01-037	02	CONTROL LINES, REMOTE (PW64H00043F1)
01-038		CONTROL LINES, REMOTE (PW64H00087F1)
01-040		PLATE GROUP, FLOOR (CANOPY) (PW03M00115F1)
01-041		PLATE GROUP, FLOOR (CAB) (PW03M00114F1)
01-042		CAB ASSY (PW02C00050F1%K2, PW02C00060F1%K2)
01-043		CAB ASSY (PW02C00068F1)
01-044		CAB ASSY (PW02C00068F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-045		CAB ASSY (PW02C00068F1)
01-046		CAB ASSY (PW02C00068F1)
01-047		CAB ASSY (PW02C00068F1)
01-049		GUARD ASSY, HEAD (PW25C00003F1)
01-050		WINDOW ASSY, FRONT (PW50C00002F1)
01-051		DOOR ASSY, CAB (PM51C00006F1%LD)
01-053		CANOPY ASSY (PW06C00036F1, PW22T00169F1)
01-054		CANOPY INSTALLATION (PW06C00027F1)
01-056		LIGHT INSTAL (CAB) (PW80E00007F1)
01-057		LIGHT ASSY, (PW80S00003F1)
01-058		LIGHT ASSY (PW80S00004F1)
01-059		LIGHT ASSY, (PM80S000008F1)
01-060		SEAT INSTALLATION (PW25M00029F1)
01-061		GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-062		GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-063		GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-064		GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-065		GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-066		GUARD INSTALLATION (CAB) (PW21C00033F1)
01-067		GUARD INSTALLATION (CAB) (PW21C00033F1)
01-068		GUARD INSTALLATION (CAB) (PW21C00033F1)
01-069		GUARD INSTALLATION (CAB) (PW21C00033F1)
01-070		GUARD INSTALLATION (CAB) (PW21C00033F1)
01-071		KEY ASSY (PW03M01869F1, PW22T00112F1)
01-072		GAUGE ASSY, CLUSTER (PH59S00005F1)
01-073		BATTERY INSTALLATION (PW72E00011F1)
01-074		HEATER ASSY (WITH HEATER) (PW21M00013F1)
01-075		HEATER ASSY (WITHOUT HEATER) (PW21M00012F1)
01-076		ELECTRICAL ASSY, UPPER (PX03E00002F1)
01-077		HARNESS ASSY, CAB (PW14E00002F1)
01-078		HARNESS ASSY (CLEANER AIR) (PW11E00013F1)
01-079	01	HARNESS ASSY (PH11E00021F1)
01-079	02	HARNESS ASSY (PH11E00021F1)
01-080		HARNESS ASSY, ENGINE (PW16E00005F1)
01-081		RELAY ASSY (PX24E00007F1)
02-001		LOW GROUP (PW01F00010F1, PX53D00010F1, PW19H00023F1)
02-002		RING ASSY, SLEWING (PW40F00006F1)
02-003		IDLER ASSY, CRAWLER (PX52D00032F1)
02-004		IDLER ASSY, CRAWLER, (PX52D00033F1)
02-005		IDLER ASSY (PX52D00034F1)
02-007		IDLER ADJUST ASSY (PX54D00011F1)
02-008		ROLLER ASSY, TRACK (PX64D00010F1)
02-009		ROLLER ASSY, UPPER (PW64D00008F1)
02-010		SHOE ASSY (PX61D00018F1)
02-012		HYDRAULIC LINES, LOW (PW02H00021F1, PW19H00012F1, PW12H00002F1, PW13H00001F1)
02-013		DOZER ASSY (PW51B00082F1, PX51B00071F1, PW51B00028F1, PX51B00072F1)
03-001		BOOM ASSY, STD 2.3M (7FT 7IN) (PW02B00123F1, PX02B00168F1, PX02B00161F1)
03-002		HYD LINES, BOOM 2.3M (7.7 FT) (PW42H00040F1, PX42H00056F1, PW42H00042F1)
03-003		HYD LINES, BOOM 2.3M (NIBBLER & BREAKER) (PW42H00048F1, PW43H00028F1)
03-004		CYLINDER INSTALLATION (CANOPY) (PW02B00122F1, PW02B00120F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-005	CYLINDER INSTALLATION (CAB) (PW02B00121F1, PW02B00120F1)
03-006	LIGHT INSTALLATION (BOOM) (PW80E00012F1, PW15E00005F1)
03-007	ARM ASSY, STD 1.18M (3FT 10IN) (PW12B00120F1, PW12B00147F1, PX12B00134F1)
03-008	HYD LINES, ARM 1.18M (3FT 10 IN) (PW43H00029F1, PW12B00136F1, PX43H00024F1, PX43H01021F1)
03-009	BUCKET INSTALLATION (PX61B00072F1)
04-001	TOOL & ACCESSORY (PM01T00002FA)
05-002	ENGINE INSTALLATION (COOLER) (PW02P00021F1, PW02P00022F1)
05-003	RADIATOR INSTALLATION (COOLER) (PW05P00042F1, PW05P00048F1)
05-004	RADIATOR ASSY (COOLER) (PW05P00040F1, PW05P01217F1)
05-005	FUEL LINES (COOLER) (PW21P00011F1)
05-006	POWER TAKE-OFF ASSY (COOLER) (PW30P00006F1)
05-007	CONTROL LINES, REMOTE (COOLER) (PW64H00047F1)
05-008	CONTROL LINES, REMOTE (COOLER), (PW64H00047F1)
05-012	CAB INSTAL (COOLER) (PW02C00073F1, PW02C00060F1%KS)
05-013	CAB INSTAL (COOLER) (PW02C00041F1)
05-014	CAB ASSY (COOLER) (PW02C00069F1)
05-015	CAB ASSY (COOLER) (PW02C00069F1)
05-016	CAB ASSY (COOLER) (PW02C00069F1)
05-017	CAB ASSY (COOLER) (PW02C00069F1)
05-018	CAB ASSY (COOLER) (PW02C00069F1)
05-019	RADIO INSTALLATION (WITHOUT RADIO) (PM54E00003F2)
05-020	STOPPER ASSY (COOLER) (PW25M01067F1)
05-021	GUARD INSTALLATION (COOLER) (PW21C00034F1)
05-022	GUARD INSTALLATION (COOLER) (PW21C00034F1)
05-023	GUARD INSTALLATION (COOLER) (PW21C00034F1)
05-024	GUARD INSTALLATION (COOLER) (PW21C00034F1)
05-025	GUARD INSTALLATION (COOLER) (PW21C00034F1)
05-026	COOLER ASSY (PW20M00028F1, PW20M00025F1)
05-027	COOLER ASSY (PW20M00022F1)
05-028	DRYER ASSY, AIR (PW96V00005F1)
05-029	COOLER ASSY P/N PH20M00019F1
05-030	COOLER ASSY (PH20M00019F1)
05-031	HARNESS ASSY (COOLER) (PH11E00012F1)
06-001	NAME PLATE INSTALLATION (PW22T00083F3), PAGE 1 OF 2
06-002	NAME PLATE INSTALLATION (PW22T00083F3), PAGE 2 OF 2
06-003	NAME PLATE INSTALLATION (PW22T00123F1)
06-004	NAME PLATE INSTALLATION (PW22T00116F1)
06-005	NAME PLATE INSTALLATION (PW22T00195F2)
06-006	NAME PLATE INSTALLATION (PW22T00196F2)
06-007	NAME PLATE INSTALLATION (DECEL) (PW22T00113F1)
06-008	NAME PLATE INSTALLATION (PW22T00183F1)
06-009	NAME PLATE INSTALLATION (PW22T00182F1)
06-010	NAME PLATE INSTALLATION (CEMA MARK) (YN22T00288F1)
06-011	NAME PLATE INSTALLATION (CAB) (PW22T00085F1)
06-012	NAME PLATE INSTALLATION (PW22T00156F2)
06-016	NAME PLATE INSTALLATION (JOHN DEERE) (PW22T00172F1)
06-017	NAME PLATE INSTALLATION (NIBBLER & BREAKER) (PW22T00087F1 & PW22T00087F2)
07-001	VALVE ASSY, CONTROL (PX30V00041F1, PX30V00041F2, PX30V00041F3)
07-003	VALVE ASSY CONTROL (DOZER) (PX30V00048F1)

Order the manual at mid-west-tech.com >

HYD LINES, UPP

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		REF			INSTRUCTION, FOR HOSE PART NUMBERS, SEE FIGURE 01-022
A1		HH25S06006G1		16	CONNECTOR, HYD.

MidWestTech | New Holland E30BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >

COOLER ASSY P/N PH20M00019F1

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		PH20M00016F1		1	COOLER, ASSY
1		{PH20M00019F1}		1	COOLER ASSY; See Figure 05-030
2		YR20M01136P1		1	TEE, TEE
3		PH20M01115D5		1	HOSE, HOSE
4		PH20M01115D6		1	HOSE, HOSE
5		PH20M01115D4		1	HOSE, HOSE
6		24100U1176S5		3	CLAMP

MidWestTech | New Holland E30BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >

STARTING MOTOR

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
1		VV12924277010		1	MOTOR, STARTER
2		VV12969877020		1	SWITCH, MAGNETIC ASSY
3		VV12924277100		1	ARMATURE, ASSY
4		VV12924277110		1	VALVE, YOKE ASSY
5		VV12924277120		1	BRUSH HOLDER, ASSY
6		VV12924277130		2	BRUSH, (-)
7		VV12924277140		1	SET, BRUSHES, (+)
8		VV12924277150		4	SPRING, BRUSH
9		VV12924277160		1	COVER, REAR ASSY
10		VV12924277170		1	COVER, REAR METAL
11		VV11840077170		3	GEAR, PLANET GEAR
12		VV12924277180		1	BRACKET, CENTER (P)
13		VV12969877190		1	BRACKET
14		VV12969877200		1	GEAR, INTERNAL
15		VV12924277210		1	BRACKET, CENTER (A)
16		VV12969877220		1	PINION, ASSY
17		VV12969877230		1	SHAFT, (PINION)
18		VV12969877250		1	WASHER, SET
19		VV12924277260		1	CASE, GEAR ASSY
20		VVX2114535200		1	SLEEVE, METAL, STARTER
21		VV12924277270		1	LEVER, SHIFT SET
22		VV12924277280		1	COVER, DUST KIT
23		VV12419577770		2	BOLT, THROUGH
24		VV26116120252		2	BOLT, M12 X 25 PLATED

MidWestTech | New Holland E30BSR Tier 4 Compact Crawler Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >