KOBELCO®

# PARTS CATALOG

## 30SR-5
## Compact Crawler Excavator

APPLICABLE
ASN PW14-46519

S3PW00041ZE02
Issued 9/2010

Printed in U.S.A.

MidWestTech | Kobelco 30SR-5 Compact Crawler Excavator Parts Catalog | Publication S3PW00041ZE02

Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX


| | FIGURE | SEQ. |
|---|---|---|
| ALARM ASSY | 05-002 | |
| ARM ASSY, 1.18M | 03-016 | |
| ARM ASSY, 1.18M - NIBBLER & BREAKER | 03-017 | |
| ARM GROUP | 03-018 | |
| ARM INSTAL | 03-019 | |
| BATTERY ASSY | 01-087 | |
| BOOM ASSY, 2.3M | 03-001 | |
| BOOM GROUP | 03-002 | |
| BOOM INSTAL | 3-003 | |
| BRACKET GROUP, SWING - NIBBLER & BREAKER | 01-003 | |
| BRACKET INSTAL, SWING | 01-004 | |
| BUCKET ASSY, 350W 0.05M³ (0.04M³) | 03-026 | |
| BUCKET ASSY, 450W 0.07M³ (006M³) | 03-027 | |
| BUCKET ASSY, 500W 0.09M³ (0.08M³) | 03-024 | |
| BUCKET ASSY, 600W 0.11M³ (0.10M³) | 03-025 | |
| BUCKET ASSY, 700W 0.13M³ (0.11M³) | 03-028 | |
| BUCKET INSTAL | 03-023 | |
| CAB - WITH HEAD GUARD | 01-066 | 03 |
| CAB INSTAL | 01-065 | 09 |
| CAB INSTAL | 01-065 | 08 |
| CAB INSTAL | 01-065 | 07 |
| CAB INSTAL | 01-065 | 05 |
| CAB INSTAL | 01-065 | 06 |
| CAB INSTAL | 01-065 | 04 |
| CAB INSTAL | 01-065 | 03 |
| CAB INSTAL | 01-065 | 02 |
| CAB INSTAL | 01-065 | 01 |
| CAB INSTAL | 01-064 | 08 |
| CAB INSTAL | 01-064 | 07 |
| CAB INSTAL | 01-064 | 06 |
| CAB INSTAL | 01-064 | 05 |
| CAB INSTAL | 01-064 | 04 |
| CAB INSTAL | 01-064 | 03 |
| CAB INSTAL | 01-064 | 02 |
| CAB INSTAL | 01-064 | 01 |
| CAB INSTAL | 01-069 | |
| CAB INSTAL - WITH HEAD GUARD | 01-066 | 05 |
| CAB INSTAL - COOLER | 01-070 | |
| CAB INSTAL - HEAD GUARD, COOLER | 01-067 | 09 |
| CAB INSTAL - HEAD GUARD, COOLER | 01-067 | 08 |
| CAB INSTAL - HEAD GUARD, COOLER | 01-067 | 07 |
| CAB INSTAL - HEAD GUARD, COOLER | 01-067 | 06 |
| CAB INSTAL - HEAD GUARD, COOLER | 01-067 | 05 |
| CAB INSTAL - HEAD GUARD, COOLER | 01-067 | 04 |
| CAB INSTAL - HEAD GUARD, COOLER | 01-067 | 03 |
| CAB INSTAL - HEAD GUARD, COOLER | 01-067 | 02 |
| CAB INSTAL - HEAD GUARD, COOLER | 01-067 | 01 |
| CAB INSTAL - WITH HEAD GUARD | 01-066 | 09 |
| CAB INSTAL - WITH HEAD GUARD | 01-066 | 08 |
| CAB INSTAL - WITH HEAD GUARD | 01-066 | 07 |
| CAB INSTAL - WITH HEAD GUARD | 01-066 | 06 |
| CAB INSTAL - WITH HEAD GUARD | 01-066 | 04 |
| CAB INSTAL - WITH HEAD GUARD | 01-066 | 02 |
| CAB INSTAL - WITH HEAD GUARD | 01-066 | 01 |
| CAMSHAFT & DRIVING GEAR | 08-007 | |
| CANOPY ASSY | 01-074 | 02 |



Order the manual at mid-west-tech.com >

| | | |
|---|---|---|
| CANOPY ASSY - CANOPY | 01-074 | 01 |
| CANOPY INSTAL | 01-071 | |
| CAP ASSY | 03-020 | |
| CLEANER ASSY, AIR - CAB | 01-014 | |
| CLEANER ASSY, AIR - CANOPY | 01-013 | |
| CONDITIONER INSTAL | 01-084 | |
| CONTROL ASSY, ENGINE - WITH DECEL | 01-024 | |
| CONTROL ASSY, ENGINE - WITH DECEL | 01-023 | |
| CONTROL LINES, MAIN - ANGLE DOZER | 01-051 | |
| CONTROL LINES, MAIN - J/D MULTI | 01-050 | 01 |
| CONTROL LINES, MULTI - J/D MULTI | 01-052 | |
| CONTROL LINES, PROPEL - ANGLE DOZER | 01-062 | 01 |
| CONTROL LINES, PROPEL - ANGLE DOZER | 01-062 | 02 |
| CONTROL LINES, PROPEL - NIBBLER & BREAKER | 01-061 | 01 |
| CONTROL LINES, PROPEL - NIBBLER & BREAKER | 01-061 | 02 |
| CONTROL LINES, REMOTE | 01-054 | 02 |
| CONTROL LINES, REMOTE | 01-054 | 01 |
| CONTROL LINES, REMOTE - ANGLE DOZER | 01-055 | 02 |
| CONTROL LINES, REMOTE - ANGLE DOZER | 01-055 | 01 |
| CONTROL LINES, REMOTE - DOZER | 01-053 | 02 |
| CONTROL LINES, REMOTE - DOZER | 01-053 | 01 |
| CONTROL LINES, VALVE | 01-056 | 02 |
| CONTROL LINES, VALVE | 01-056 | 01 |
| CONTROL LINES, VALVE - ANGLE DOZER | 01-060 | 03 |
| CONTROL LINES, VALVE - ANGLE DOZER | 01-060 | 02 |
| CONTROL LINES, VALVE - ANGLE DOZER | 01-060 | 01 |
| CONTROL LINES, VALVE - ANGLE DOZER | 01-058 | 02 |
| CONTROL LINES, VALVE - ANGLE DOZER | 01-058 | 01 |
| CONTROL LINES, VALVE - COOLER | 01-059 | 04 |
| CONTROL LINES, VALVE - COOLER | 01-059 | 03 |
| CONTROL LINES, VALVE - COOLER | 01-059 | 02 |
| CONTROL LINES, VALVE - COOLER | 01-059 | 01 |
| CONTROL LINES, VALVE - NIBBLER & BREAKER | 01-057 | |
| CONTROLS, OPERATORS | 01-041 | 02 |
| CONTROLS, OPERATORS | 01-041 | 03 |
| CONTROLS, OPERATORS | 01-041 | 01 |
| CONTROLS, OPERATORS - CAB | 01-045 | 02 |
| CONTROLS, OPERATORS - CAB | 01-045 | 01 |
| CONTROLS, OPERATORS - CAB, ANGLE DOZER | 01-044 | 02 |
| CONTROLS, OPERATORS - CAB, ANGLE DOZER | 01-044 | 03 |
| CONTROLS, OPERATORS - CAB, ANGLE DOZER | 01-044 | 01 |
| CONTROLS, OPERATORS - CANOPY | 01-043 | 02 |
| CONTROLS, OPERATORS - CANOPY | 01-043 | 01 |
| CONTROLS, OPERATORS - CANOPY, ANGLE DOZER | 01-042 | 03 |
| CONTROLS, OPERATORS - CANOPY, ANGLE DOZER | 01-042 | 01 |
| CONTROLS, OPERATORS - CANOPY, ANGLE DOZER | 01-042 | 02 |
| COOLER ASSY | 01-085 | 03 |
| COOLER ASSY | 01-085 | 01 |
| COOLER ASSY | 01-085 | 02 |
| COOLER ASSY | 01-086 | |
| COOLING WATER SYSTEM | 08-010 | |
| COUNTERWEIGHT INSTAL | 01-007 | |
| COVER ASSY | 01-046 | |
| COVER ASSY, UNDER | 01-080 | |
| CRANKSHAFT & PISTON | 08-008 | |
| CYLINDER BLOCK | 08-001 | |
| CYLINDER HEAD & BONNET | 08-004 | |
| CYLINDER INSTAL | 03-007 | 01 |



Order the manual at mid-west-tech.com >

| | | |
|---|---|---|
| CYLINDER INSTAL | 03-007 | 02 |
| CYLINDER INSTAL | 01-005 | 02 |
| CYLINDER INSTAL | 01-005 | 01 |
| CYLINDER INSTAL | 03-006 | |
| CYLINDER INSTAL - ANGLE DOZER | 02-021 | 01 |
| CYLINDER INSTAL - ANGLE DOZER | 02-021 | 02 |
| CYLINDER INSTAL - CAB | 03-005 | 02 |
| CYLINDER INSTAL - CAB | 03-005 | 01 |
| CYLINDER INSTAL - CANOPY | 03-004 | 01 |
| CYLINDER INSTAL - CANOPY | 03-004 | 02 |
| CYLINDER INSTAL - DOZER | 02-022 | 01 |
| CYLINDER INSTAL - DOZER | 02-022 | 02 |
| DOZER ASSY | 02-016 | |
| DOZER ASSY - ANGLE DOZER | 02-017 | |
| DOZER GROUP | 02-018 | |
| DOZER GROUP - ANGLE DOZER | 02-019 | |
| DOZER INSTAL | 02-020 | |
| ELEC ASSY, UPP | 01-090 | 01 |
| ELEC ASSY, UPP | 01-090 | 02 |
| ELEC ASSY, UPP - ANGLE DOZER | 01-091 | 01 |
| ELEC ASSY, UPP - ANGLE DOZER | 01-091 | 02 |
| ENGINE INSTAL | 01-008 | |
| ENGINE INSTAL - COOLER | 01-009 | |
| EXHAUST MANIFOLD | 08-006 | |
| FILTER LIST | 00-001 | |
| FLYWHEEL HOUSING & OIL SUMP | 08-003 | |
| FRAME GROUP, UPP | 01-001 | |
| FRAME GROUP, UPP - ANGLE DOZER | 01-002 | |
| FUEL INJECTION PUMP | 08-011 | |
| FUEL INJECTION VALVE | 08-013 | |
| FUEL LINE | 08-014 | |
| FUEL LINES | 01-016 | |
| FUEL LINES - COOLER | 01-017 | |
| GASKET SET | 08-017 | |
| GEAR HOUSING | 08-002 | |
| GENERATOR | 08-016 | |
| GOVERNOR | 08-012 | |
| GRIP ASSY | 01-048 | |
| GROMMET - CAB | 01-083 | |
| GROMMET - CANOPY | 01-082 | |
| GUARD ASSY, HEAD | 01-068 | |
| GUARD INSTAL - CAB | 01-079 | 05 |
| GUARD INSTAL - CAB | 01-079 | 04 |
| GUARD INSTAL - CAB | 01-079 | 03 |
| GUARD INSTAL - CAB | 01-079 | 02 |
| GUARD INSTAL - CAB | 01-079 | 01 |
| GUARD INSTAL - CANOPY | 01-078 | 06 |
| GUARD INSTAL - CANOPY | 01-078 | 05 |
| GUARD INSTAL - CANOPY | 01-078 | 04 |
| GUARD INSTAL - CANOPY | 01-078 | 03 |
| GUARD INSTAL - CANOPY | 01-078 | 02 |
| GUARD INSTAL - CANOPY | 01-078 | 01 |
| HARNESS ASSY | 01-093 | 02 |
| HARNESS ASSY | 01-093 | 01 |
| HARNESS ASSY | 01-094 | |
| HARNESS ASSY | 01-092 | |
| HARNESS ASSY, BOOM | 03-013 | |
| HARNESS ASSY, CAB | 01-095 | |



Order the manual at mid-west-tech.com >