CX31B
Compact Crawler Excavator
ASN PW14-46519

Parts Catalog

Print No. S3PW00042ZE02
Issued 9/2010

CASE CONSTRUCTION

MidWestTech | Case CX31B Compact Crawler Excavator Parts Catalog | Publication S3PW00042ZE02

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
ALARM ASSY	05-002	00
ARM ASSY, 1.18M	03-016	00
ARM ASSY, 1.18M, NIBBLER & BREAKER	03-018	00
ARM ASSY, LONG 1.47M	03-017	00
ARM GROUP	03-020	00
ARM INSTAL	03-021	00
ARM INSTAL	03-022	00
ARM, LONG 1.47M, NIBBLER & BREAKER	03-019	00
BATTERY ASSY	01-092	00
BOOM ASSY, 2.3M	03-001	00
BOOM GROUP	03-002	00
BOOM INSTAL	03-003	00
BRACKET GROUP, SWING, NIBBLER & BREAKER	01-003	00
BRACKET INSTAL,SWING	01-004	00
BUCKET ASSY, 350W 0.05M³ (0.04M³)	03-031	00
BUCKET ASSY, 450W 0.07M³ (0.06M³)	03-032	00
BUCKET ASSY, 500W 0.09M³ (0.08M³)	03-029	00
BUCKET ASSY, 600W 0.11M³ (0.10M³)	03-030	00
BUCKET ASSY, 700W 0.13M³ (0.11M³)	03-033	00
BUCKET INSTAL	03-028	00
CAB INSTAL	01-068	09
CAB INSTAL	01-068	08
CAB INSTAL	01-068	07
CAB INSTAL	01-068	06
CAB INSTAL	01-068	05
CAB INSTAL	01-068	04
CAB INSTAL	01-068	03
CAB INSTAL	01-068	02
CAB INSTAL	01-068	01
CAB INSTAL	01-067	08
CAB INSTAL	01-067	07
CAB INSTAL	01-067	05
CAB INSTAL	01-067	06
CAB INSTAL	01-067	04
CAB INSTAL	01-067	03
CAB INSTAL	01-067	02
CAB INSTAL	01-067	01
CAB INSTAL	01-072	00
CAB INSTAL, COOLER	01-073	00
CAB INSTAL, HEAD GUARD, COOLER	01-070	09
CAB INSTAL, HEAD GUARD, COOLER	01-070	08
CAB INSTAL, HEAD GUARD, COOLER	01-070	07
CAB INSTAL, HEAD GUARD, COOLER	01-070	06
CAB INSTAL, HEAD GUARD, COOLER	01-070	05
CAB INSTAL, HEAD GUARD, COOLER	01-070	04
CAB INSTAL, HEAD GUARD, COOLER	01-070	03
CAB INSTAL, HEAD GUARD, COOLER	01-070	02
CAB INSTAL, HEAD GUARD, COOLER	01-070	01
CAB INSTAL, WITH HEAD GUARD	01-069	09
CAB INSTAL, WITH HEAD GUARD	01-069	08
CAB INSTAL, WITH HEAD GUARD	01-069	07
CAB INSTAL, WITH HEAD GUARD	01-069	05
CAB INSTAL, WITH HEAD GUARD	01-069	06
CAB INSTAL, WITH HEAD GUARD	01-069	04
CAB INSTAL, WITH HEAD GUARD	01-069	03
CAB INSTAL, WITH HEAD GUARD	01-069	02

Order the manual at mid-west-tech.com >

CAB INSTAL, WITH HEAD GUARD	01-069	01
CAMSHAFT & DRIVING GEAR	08-007	00
CANOPY ASSY	01-077	01
CANOPY ASSY	01-077	02
CANOPY INSTAL	01-074	00
CAP ASSY	03-023	00
CLEANER ASSY, AIR, CAB	01-015	00
CLEANER ASSY, AIR, CANOPY	01-014	00
CONDITIONER INSTAL	01-089	00
CONTROL ASSY, ENGINE, WITH DECEL	01-024	02
CONTROL ASSY, ENGINE, WITH DECEL	01-024	01
CONTROL LINES, MAIN, ANGLE DOZER	01-051	00
CONTROL LINES, MAIN, J/D MULTI	01-050	00
CONTROL LINES, MULTI, J/D MULTI	01-052	00
CONTROL LINES, PROPEL, ANGLE DOZER	01-064	02
CONTROL LINES, PROPEL, ANGLE DOZER	01-064	01
CONTROL LINES, PROPEL, NIBBLER & BREAKER	01-063	02
CONTROL LINES, PROPEL, NIBBLER & BREAKER	01-063	01
CONTROL LINES, REMOTE	01-054	02
CONTROL LINES, REMOTE	01-054	01
CONTROL LINES, REMOTE, ANGLE DOZER	01-055	02
CONTROL LINES, REMOTE, ANGLE DOZER	01-055	01
CONTROL LINES, REMOTE, DOZER	01-053	01
CONTROL LINES, REMOTE, DOZER	01-053	02
CONTROL LINES, VALVE	01-056	02
CONTROL LINES, VALVE	01-056	01
CONTROL LINES, VALVE, ANGLE DOZER	01-060	02
CONTROL LINES, VALVE, ANGLE DOZER	01-060	03
CONTROL LINES, VALVE, ANGLE DOZER	01-060	01
CONTROL LINES, VALVE, ANGLE DOZER	01-058	02
CONTROL LINES, VALVE, ANGLE DOZER	01-058	01
CONTROL LINES, VALVE, COOLER	01-059	04
CONTROL LINES, VALVE, COOLER	01-059	02
CONTROL LINES, VALVE, COOLER	01-059	03
CONTROL LINES, VALVE, COOLER	01-059	01
CONTROL LINES, VALVE, NIBBLER & BREAKER	01-057	00
CONTROL LINES, VALVE, WITH A PUMP Z PORT	01-062	04
CONTROL LINES, VALVE, WITH A PUMP Z PORT	01-062	03
CONTROL LINES, VALVE, WITH A PUMP Z PORT	01-062	02
CONTROL LINES, VALVE, WITH A PUMP Z PORT	01-062	01
CONTROL LINES, VALVE, WITH A PUMP Z PORT	01-061	04
CONTROL LINES, VALVE, WITH A PUMP Z PORT	01-061	03
CONTROL LINES, VALVE, WITH A PUMP Z PORT	01-061	02
CONTROL LINES, VALVE, WITH A PUMP Z PORT	01-061	01
CONTROLS, OPERATORS	01-041	03
CONTROLS, OPERATORS	01-041	01
CONTROLS, OPERATORS	01-041	02
CONTROLS, OPERATORS, CAB	01-045	02
CONTROLS, OPERATORS, CAB	01-045	01
CONTROLS, OPERATORS, CAB, ANGLE DOZER	01-044	02
CONTROLS, OPERATORS, CAB, ANGLE DOZER	01-044	03
CONTROLS, OPERATORS, CAB, ANGLE DOZER	01-044	01
CONTROLS, OPERATORS, CANOPY	01-043	02
CONTROLS, OPERATORS, CANOPY	01-043	01
CONTROLS, OPERATORS, CANOPY, ANGLE DOZER	01-042	03
CONTROLS, OPERATORS, CANOPY, ANGLE DOZER	01-042	01
CONTROLS, OPERATORS, CANOPY, ANGLE DOZER	01-042	02
COOLER ASSY	01-090	03

Order the manual at mid-west-tech.com >

COOLER ASSY	01-090	02
COOLER ASSY	01-090	01
COOLER ASSY	01-091	00
COOLING WATER SYSTEM	08-010	00
COUNTERWEIGHT INSTAL	01-007	00
COUNTERWEIGHT INSTAL, GAIN	01-008	00
COVER ASSY	01-046	00
COVER ASSY, UNDER	01-085	00
CRANKSHAFT & PISTON	08-008	00
CYLINDER BLOCK	08-001	00
CYLINDER HEAD & BONNET	08-004	00
CYLINDER INSTAL	03-007	01
CYLINDER INSTAL	03-007	02
CYLINDER INSTAL	01-005	01
CYLINDER INSTAL	01-005	02
CYLINDER INSTAL, ANGLE DOZER	02-021	02
CYLINDER INSTAL, ANGLE DOZER	02-021	01
CYLINDER INSTAL, ARM	03-006	00
CYLINDER INSTAL, CAB	03-005	01
CYLINDER INSTAL, CAB	03-005	02
CYLINDER INSTAL, CANOPY	03-004	02
CYLINDER INSTAL, CANOPY	03-004	01
CYLINDER INSTAL, DOZER	02-022	01
CYLINDER INSTAL, DOZER	02-022	02
DOZER ASSY	02-016	00
DOZER ASSY, ANGLE DOZER	02-017	00
DOZER GROUP	02-018	00
DOZER GROUP, ANGLE DOZER	02-019	00
DOZER INSTAL	02-020	00
ELEC ASSY, UPP	01-095	02
ELEC ASSY, UPP	01-095	01
ELEC ASSY, UPP, ANGLE DOZER	01-096	02
ELEC ASSY, UPP, ANGLE DOZER	01-096	01
ENGINE INSTAL	01-009	00
ENGINE INSTAL, COOLER	01-010	00
EXHAUST MANIFOLD	08-006	00
FILTER LIST	00-001	00
FLYWHEEL HOUSING & OIL SUMP	08-003	00
FRAME GROUP, UPP	01-001	00
FRAME GROUP, UPP, ANGLE DOZER	01-002	00
FUEL INJECTION PUMP	08-011	00
FUEL INJECTION VALVE	08-013	00
FUEL LINE	08-014	00
FUEL LINES	01-017	00
FUEL LINES, COOLER	01-018	00
GASKET SET	08-017	00
GEAR HOUSING	08-002	00
GENERATOR	08-016	00
GOVERNOR	08-012	00
GRIP ASSY	01-048	00
GROMMET, CAB	01-088	00
GROMMET, CANOPY	01-087	00
GUARD ASSY, HEAD	01-071	00
GUARD INSTAL, CAB	01-084	05
GUARD INSTAL, CAB	01-084	04
GUARD INSTAL, CAB	01-084	03
GUARD INSTAL, CAB	01-084	02
GUARD INSTAL, CAB	01-084	01

Order the manual at mid-west-tech.com >