CASE
CONSTRUCTION

PARTS CATALOG

COMPACT CRAWLER EXCAVATOR

CX36B
TIER 4

ASN PX15-20658~

S3PX00037ZE01 NA

Issued 01Nov 08

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001	FILTER LIST
00-002	SLEEVE
00-003	NUT
01-001	FRAME ASSY, UPPER (PW52F00047F1, PW24C00005F1)
01-002	BRACKET ASSY, SWING (NIBBLER & BREAKER) (PX02B00148F1, PX02B00147F1, PX02B00149F1)
01-003	COUNTERWEIGHT INSTALLATION (PX60C00017F1, PW60C00018F1, PW60C00019F1)
01-004	ENGINE ASSY (PW02P00018F1)
01-005	ENGINE INSTALLATION (PW02P00019F1, PW02P00020F1)
01-006	RADIATOR INSTALLATION (PW05P00042F1, PW05P00047F1)
01-007	RADIATOR ASSY (PW05P00040F1, PW05P01214F1)
01-008	CLEANER ASSY, AIR - CAB MODELS (PW11P00031F1, PW11P00027F1, PW11P00028F1)
01-009	CLEANER ASSY, AIR - CANOPY (PW11P00021F1, PW11P00027F1, PW11P00020F1)
01-010	MUFFLER ASSY (PX12P00011F1)
01-011	FUEL LINES (PW21P00009F1)
01-012	TANK ASSY, FUEL (CANOPY) (PW20P00022F1, PW20P00034F1)
01-013	TANK ASSY, FUEL (CAB) (PW20P00022F1, PW20P00033F1)
01-014	TANK ASSY, HYD (NIBBLER & BREAKER) (PW33H00050F1, PW33H00039F1)
01-015	CONTROL ASSY, ENGINE (WITH DECELERATION), (PW11M00010F1)
01-016	CONTROL ASSY, ENGINE (WITH DECELERATION) (PW20S00012F1)
01-017	POWER TAKE-OFF ASSY (PW30P00007F1)
01-018	MOTOR INSTALLATION, SWING (PW32W00005F1)
01-019	HYDRAULIC LINES, CYLINDER (PX42H00027F1)
01-020	VALVE INSTALLATION (PW64H00079F1)
01-021	HYDRAULIC LINES, PUMP (PW30H00007F1)
01-022	HYDRAULIC LINES, UPPER (PW03H00035F1, PW19H00019F1)
01-023	HYDRAULIC LINES, UPPER (PW03H00035F1)
01-024	HYDRAULIC LINES, UPPER (PW03H00036F1)
01-025	HYDRAULIC LINES, RETURN (PW32H00012F1)
01-026	CONTROLS, OPERATORS (PW03M00092F1)
01-027	COVER ASSY (PW03M01702F1)
01-028	GRIP ASSY, (PW03M01954F1, PW03M01718F1)
01-029	CONTROL BOX ASSY (LEFT HAND) (PW03M00093F1)
01-030	STAND ASSY, CONTROL (CANOPY) (PW03M00108F1, PW03M01713F1)
01-031	STAND ASSY, CONTROL (CAB) (PW03M00109F1, PW03M01714F1)
01-032	LEVER ASSY, CONTROL (PH50M00011F1, PW55M00015F1)
01-033	CONTROL LINES, REMOTE (NIBBLER & BREAKER) (PW64H00037F1, PW64H00038F1, PW68H00031F1)
01-034	CONTROL LINES, REMOTE (NIBBLER & BREAKER) (PW68H00031F1)
01-035	CONTROL LINES, REMOTE (MULTI) (PW06H00008F1, PW64H00055F1, PW64H00056F1)
01-036	CONTROL LINES, REMOTE (DOZER) (PW68H00043F1)
01-037	CONTROL LINES, REMOTE (PW62H00021F1, PW64H00043F1)
01-038	CONTROL LINES, REMOTE (PW64H00043F1)
01-039	CONTROL LINES, REMOTE (PW64H00087F1)
01-040	PLATE GROUP, FLOOR (CANOPY) (PW03M00115F1)
01-041	PLATE GROUP, FLOOR (CAB) (PW03M00114F1)
01-042	CAB INSTALLATION (PW02C00039F1)
01-043	CAB INSTALLATION (PW02C00025F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-044	CAB ASSY (PW02C00050F1%K2, PW02C00060F1%K2)
01-045	CAB ASSY (PW02C00068F1)
01-046	CAB ASSY (PW02C00068F1)
01-047	CAB ASSY (PW02C00068F1)
01-048	CAB ASSY (PW02C00068F1)
01-049	CAB ASSY (PW02C00068F1)
01-050	GUARD ASSY, HEAD (PW25C00003F1)
01-051	WINDOW ASSY, FRONT (PW50C00002F1)
01-052	DOOR ASSY, CAB (PM51C00006F1%LD)
01-054	CANOPY ASSY (PW06C00036F1, PW22T00169F1)
01-055	CANOPY INSTALLATION (PW06C00022F1)
01-057	LIGHT INSTALLATION (CAB) (PW80E00007F1)
01-058	LIGHT ASSY, (PW80S00003F1)
01-059	LIGHT ASSY (PW80S00004F1)
01-060	LIGHT ASSY, (PM80S000008F1)
01-061	SEAT INSTALLATION (PW25M00029F1)
01-062	GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-063	GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-064	GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-065	GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-066	GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-067	GUARD INSTALLATION (CAB) (PW21C00033F1)
01-068	GUARD INSTALLATION (CAB) (PW21C00033F1)
01-069	GUARD INSTALLATION (CAB) (PW21C00033F1)
01-070	GUARD INSTALLATION (CAB) (PW21C00033F1)
01-071	GUARD INSTALLATION (CAB) (PW21C00033F1)
01-072	KEY ASSY (PW03M01870F1, PW22T00112F1)
01-073	GAUGE ASSY, CLUSTER (PH59S00005F1)
01-074	BATTERY INSTALLATION (PW72E00011F1)
01-075	HEATER ASSY (WITH HEATER) (PW21M00013F1)
01-076	HEATER ASSY (WITHOUT HEATER) (PW21M00012F1)
01-077	ELECTRICAL ASSY, UPPER (PX03E00002F1)
01-078	HARNESS ASSY, CAB (PW14E00002F1)
01-079	HARNESS ASSY (CLEANER AIR) (PW11E00013F1)
01-080	HARNESS ASSY (PH11E00021F1)
01-081	HARNESS ASSY (PH11E00021F1)
01-082	HARNESS ASSY, ENGINE (PW16E00005F1)
01-083	RELAY ASSY (PX24E00007F1)
02-001	LOW GROUP (PX01F00008F1, PX53D00010F1, PW19H00023F1)
02-002	RING ASSY, SLEWING (PW40F00006F1)
02-003	IDLER ASSY, CRAWLER (PX52D00032F1)
02-004	IDLER ASSY, CRAWLER (PX52D00033F1)
02-005	IDLER ASSY (PX52D00034F1)
02-006	IDLER ADJUST ASSY (PX54D00011F1)
02-007	ROLLER ASSY, TRACK (PX64D00010F1)
02-008	ROLLER ASSY, UPPER (PW64D00008F1)
02-009	SHOE ASSY (PX60D00019F1, PX60D00021F2)
02-010	SHOE ASSY (PX61D00018F1)
02-011	HYDRAULIC LINES, LOW (PX02H00007F1, PW19H00012F1, PW12H00002F1, PW13H00001F1)
02-012	DOZER ASSY (PX51B00078F1, PX51B00071F1, PW51B00028F1, PX51B00072F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-001	BOOM ASSY, STD 2.5M (8FT 2IN) (PX02B00142F1, PX02B00168F1, PX02B00161F1)
03-002	HYDRAULIC LINES, BOOM 2.5M (8FT 2 IN) (PX42H00053F1, PX42H00056F1, PX42H00057F1)
03-003	HYDRAULIC LINES, BOOM 2.5M (8FT 2IN) (NIBBLER & BREAKER) (PX42H00068F1, PX43H00017F1)
03-004	CYLINDER INSTALLATION (CANOPY) (PX02B00146F1, PX02B00141F1)
03-005	CYLINDER INSTALLATION (CAB) (PX02B00145F1, PX02B00141F1)
03-006	LIGHT INSTALLATION (BOOM) (PW80E00012F1, PW15E00005F1)
03-008	ARM ASSY, STD 1.32M (4FT 4IN) (PX12B00092F1, PX12B00120F1, PX12B00072F1)
03-009	HYDRAULIC LINES, ARM 1.32M (4FT 4IN) (PX43H00025F1, PX12B00108F1, PX43H00024F1, PX43H01011F1, PX43H01011F1)
03-010	BUCKET INSTALLATION (PX61B00072F1)
04-001	TOOL & ACCESSORY (PM01T00002FA)
05-002	ENGINE INSTALLATION (COOLER) (PW02P00021F1, PW02P00022F1)
05-003	RADIATOR INSTALLATION (COOLER) (PW05P00042F1, PW05P00048F1)
05-004	RADIATOR ASSY (COOLER) (PW05P00040F1, PW05P01217F1)
05-005	FUEL LINES (COOLER) (PW21P00011F1)
05-006	POWER TAKE-OFF ASSY (COOLER) (PW30P00006F1)
05-007	CONTROL LINES, REMOTE (COOLER) (PW64H00047F1)
05-008	CONTROL LINES, REMOTE (COOLER), (PW64H00047F1)
05-009	CONTROL LINES, REMOTE (WITH A PUMP Z PORT) (PW62H00029F1, PW64H00069F1)
05-010	CONTROL LINES, REMOTE (WITH A PUMP Z PORT) (PW64H00069F1)
05-012	CAB INSTALLATION (COOLER) (PW02C00073F1, PW02C00060F1%KS)
05-013	CAB INSTALLATION (COOLER) (PW02C00037F1)
05-014	CAB ASSY (COOLER) (PW02C00069F1)
05-015	CAB ASSY (COOLER) (PW02C00069F1)
05-016	CAB ASSY (COOLER) (PW02C00069F1)
05-017	CAB ASSY (COOLER) (PW02C00069F1)
05-018	CAB ASSY (COOLER) (PW02C00069F1)
05-019	RADIO INSTALLATION (WITHOUT RADIO) (PM54E00003F2)
05-020	STOPPER ASSY (COOLER) (PW25M01067F1)
05-021	GUARD INSTALLATION (COOLER) (PW21C00034F1)
05-022	GUARD INSTALLATION (COOLER) (PW21C00034F1)
05-023	GUARD INSTALLATION (COOLER) (PW21C00034F1)
05-024	GUARD INSTALLATION (COOLER) (PW21C00034F1)
05-025	GUARD INSTALLATION (COOLER) (PW21C00034F1)
05-026	COOLER ASSY (PW20M00028F1, PW20M00025F1)
05-027	COOLER ASSY (PW20M00022F1)
05-028	DRYER ASSY, AIR (PW96V00005F1)
05-029	COOLER ASSY (PH20M00016F1)
05-030	COOLER ASSY (PH20M00019F1)
05-031	HARNESS ASSY (COOLER) (PH11E00012F1)
06-001	NAME PLATE INSTALLATION (PW22T00083F2), PAGE 1 OF 2
06-001A	NAME PLATE INSTALLATION (PW22T00083F2), PAGE 2 OF 2
06-002	NAME PLATE INSTALLATION (PW22T00123F1)
06-003	NAME PLATE INSTALLATION (PW22T00105F1)
06-004	NAME PLATE INSTALLATION (PW22T00117F1)
06-005	NAME PLATE INSTALLATION (PW22T00111F1)
06-006	NAME PLATE INSTALLATION (PW22T00173F1)
06-007	NAME PLATE INSTALLATION (PW22T00113F1)

MidWestTech | Case CX36B Tier 4 Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >