NEW HOLLAND

COMPACT CRAWLER EXCAVATOR

E35BSR TIER 4

PARTS CATALOG

ASN PX15-20658~

S3PX00038ZE01 NA

Issued 01Nov 08

NEW HOLLAND CONSTRUCTION

www.newhollandconstruction.com

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

00-001	00	FILTER LIST
00-002	00	SLEEVE
00-003	00	NUT
00-004	00	PAINT COLOR
01-001	00	FRAME ASSY, UPPER (PW52F00047F1, PW24C00005F1)
01-003	00	BRACKET ASSY, SWING (NIBBLER & BREAKER) (9PX02B00148F1, PX02B00147F1, PX02B00149F1)
01-004	00	COUNTERWEIGHT INSTALLATION (PX60C00017F1, PW60C00018F1, PW60C00019F1)
01-005	00	ENGINE ASSY (PW02P00018F1)
01-006	00	ENGINE INSTALLATION (PW02P00019F1, PW02P00020F1)
01-007	00	RADIATOR INSTALLATION (PW05P00042F1, PW05P00047F1)
01-008	00	RADIATOR ASSY (PW05P00040F1, PW05P01214F1)
01-009	00	CLEANER ASSY, AIR (PW11P00031F1, PW11P00027F1, PW11P00028F1)
01-009	01	CLEANER ASSY, AIR (PW11P00021F1, PW11P00027F1, PW11P00020F1)
01-010	00	MUFFLER ASSY (PX12P00011F1)
01-011	00	FUEL LINES (PW21P00009F1)
01-012	00	TANK ASSY, FUEL (CANOPY) (PW20P00022F1, PW20P00034F1)
01-013	00	TANK ASSY, FUEL (CAB) (PW20P00022F1, PW20P00033F1)
01-014	00	TANK ASSY, HYD (NIBBLER & BREAKER) (PW33H00050F1, PW33H00039F1)
01-015	00	CONTROL ASSY, ENGINE (WITH DECELERATION), (PW11M00010F1)
01-016	00	CONTROL ASSY, ENGINE (WITH DECELERATION)
01-017	00	POWER TAKE-OFF ASSY (PW30P00007F1)
01-018	00	MOTOR INSTALLATION, SWING (PW32W00005F1)
01-019	00	HYD LINES, CYLINDER (SWING) (PX42H00027F1)
01-020	00	VALVE INSTALLATION (PW64H00079F1)
01-021	00	HYD LINES, PUMP (PW30H00007F1)
01-022	00	HYD LINES, UPPER (PW03H00035F1, PW19H00019F1)
01-022	01	HYD LINES, UPPER (PW03H00035F1)
01-023	00	HYD LINES, UPPER (PW03H00036F1)
01-024	00	HYD LINES, RETURN (PW32H00012F1)
01-025	00	CONTROLS, OPERATORS (PW03M00092F1)
01-026	00	COVER ASSY (PW03M01702F1)
01-027	00	GRIP ASSY (PW03M01954F1, PW03M01718F1)
01-028	00	CONTROL BOX ASSY (LEFT HAND) (PW03M00093F1)
01-029	00	STAND ASSY, CONTROL (CANOPY) (PW03M00108F1, PW03M01715F1)
01-030	00	STAND ASSY, (CAB) (PW03M00109F1, PW03M01716F1)
01-031	00	LEVER ASSY, CONTROL (PH50M00011F1, PW55M00015F1)
01-032	00	CONTROL LINES, REMOTE (NIBBLER & BREAKER) (PW64H00037F1, PW64H00038F1, PW68H00031F1)
01-032	01	CONTROL LINES, REMOTE (NIBBLER & BREAKER) (PW64H00037F1, PW68H00031F1)
01-034	00	CONTROL LINES, REMOTE (MULTI) (PW06H00008F1, PW64H00055F1, PW64H00056F1)
01-035	00	CONROL LINES, REMOTE (DOZER) (PW68H00043F1)
01-036	00	CONTROL LINES, REMOTE (PW62H00021F1, PW64H00043F1)
01-036	01	CONTROL LINES, REMOTE (PW62H00021F1, PW64H00043F1)
01-037	00	CONTROL LINES, REMOTE, (PW64H00087F1)
01-040	00	PLATE GROUP, FLOOR (CANOPY) (PW03M00115F1)
01-041	00	PLATE GROUP, FLOOR (CAB) (PW03M00114F1)
01-042	00	CAB INSTALLATION (PW02C00039F1, PW02C00050F1%K2)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-043	00	CAB INSTALLATION (PW02C00024F1)
01-044	00	CAB ASSY, (PW02C00050F1%K2, PW02C00060F1%K2)
01-045	00	CAB ASSY, (PW02C00068F1)
01-045	01	CAB ASSY, (PW02C00068F1)
01-045	02	CAB ASSY, (PW02C00068F1)
01-045	03	CAB ASSY, (PW02C00068F1)
01-045	04	CAB ASSY, (PW02C00068F1)
01-049	00	GUARD ASSY, HEAD (PW25C00003F1)
01-050	00	WINDOW ASSY, FRAME (PW50C00002F1)
01-051	00	DOOR ASSY, CAB (PM51C00006F1%LD)
01-053	00	CANOPY ASSY (PW06C00036F1, PW80E00006F1, PW22T00169F1)
01-054	00	CANOPY INSTALLATION (PW06C00027F1)
01-056	00	LIGHT INSTALLATION (CAB) (PW80E00007F1)
01-057	00	LIGHT ASSY, (PW80S00003F1)
01-058	00	LIGHT ASSY, (PW80S00004F1)
01-059	00	LIGHT ASSY, (PM80S00008F1)
01-060	00	SEAT INSTALLATION (PW25M00029F1)
01-061	00	GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-061	01	GUARD INSTALLATION (CANOPY) (PW21C00032F1)
01-062	00	GUARD INSTALLATION (CANOPY) (PW21C00027F1)
01-063	00	GUARD INSTALLATION (CANOPY)
01-064	00	GUARD INSTALLATION (CANOPY) (PW22C01151F1)
01-065	00	GUARD INSTALLATION (CAB) (PW21C00033F1)
01-066	00	GUARD INSTALLATION (CAB) (PW21C00033F1)
01-067	00	GUARD INSTALLATION (CAB) (PW21C00027F1)
01-068	00	GUARD INSTALLATION (CAB)
01-069	00	GUARD INSTALLATION (CAB) (PW22C01151F1)
01-070	00	KEY ASSY (PW03M01869F1)
01-071	00	GUAGE ASSY, CLUSTER (PH59S00005F1)
01-072	00	BATTERY INSTALLATION (PW72E00011F1)
01-073	00	HEATER ASSY (WITH HEATER) (PW21M00013F1)
01-074	00	HEATER ASSY (WITHOUT HEATER) (PW21M00012F1)
01-075	00	ELEC ASSY, UPPER (PX03E00002F1)
01-076	00	HARNESS ASSY, CAB (PW14E00002F1)
01-077	00	HARNESS ASSY (AIR CLEANER) (PW11E00013F1)
01-078	00	HARNESS ASSY (PH11E00021F1)
01-078	01	HARNESS ASSY (PH11E00021F1)
01-079	00	HARNESS ASSY, ENGINE (PW16E00005F1)
01-080	00	RELAY ASSY (PX24E00007F1)
02-001	00	LOW GROUP (PX01F00008F1, PX53D00010F1, PW19H00023F1)
02-002	00	RING ASSY, SLEWING (PW40F00006F1)
02-003	00	IDLER ASSY, CRAWLER (PX52D00032F1)
02-004	00	IDLER ASSY, CRAWLER (PX52D00033F1)
02-005	00	IDLER ASSY (PX52D00034F1)
02-006	00	IDLER ADJUST ASSY (PX54D00011F1)
02-007	00	ROLLER ASSY, TRACK (PX64D00010F1)
02-008	00	ROLLER ASSY, UPP (PW64D00008F1)
02-009	00	SHOE ASSY, (PX60D00019F1, PX60D00021F2)
02-010	00	SHOE ASSY (PX61D00018F1)
02-011	00	HYD LINES, LOW (PX02H00007F1, PW19H00012F1, PW13H00001F1)
02-012	00	DOZER ASSY (PX51B00078F1, PX51B00071F1, PW51B00028F1, PX51B00072F1)

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-001	00	BOOM ASSY, STD 2.5M (8FT 2IN) (PX02B00142F1, PX02B00168F1, PX02B00161F1)
03-002	00	HYD LINES, BOOM 2.5M (8FT 2IN) (PX42H00053F1, PX42H00056F1, PX42H00057F1)
03-003	00	HYD LINES, BOOM 2.5M (8FT 2IN) (NIBBLER & BREAKER) (PX42H00068F1, PX43H00017F1)
03-004	00	CYLINDER INSTAL (CANOPY) (PX02B00146F1, PX02B00141F1)
03-005	00	CYLINDER INSTAL (CAB) (PX02B00145F1, PX02B00141F1)
03-006	00	LIGHT INSTAL (BOOM) (PW80E00012F1, PW15E00005F1)
03-007	00	ARM ASSY, STD 1.32M (4FT 4IN) (PX12B00092F1, PX12B00120F1)
03-008	00	HYD LINES, ARM 1.32M (4FT 4IN) (PX43H00025F1, PX12B00108F1, PX43H00024F1, PX43H01011F1, PX43H01021F1)
03-009	00	BUCKET INSTAL (PX61B00072F1)
04-001	00	TOOL & ACCESSORY (PM01T00002FA)
04-002	00	MANUAL ASSY (PX91Z00011FE)
05-002	00	ENGINE INSTAL (COOLER) (PW02P00021F1, PW02P00022F1)
05-003	00	RADIATOR INSTAL (COOLER) (PW05P00042F1, PW05P00048F1)
05-004	00	RADIATOR ASSY (COOLER) (PW05P00040F1, PW05P01217F1)
05-005	00	FUEL LINES (COOLER) (PW21P00011F1)
05-006	00	POWER TAKE-OFF ASSY (COOLER) (PW30P00006F1)
05-007	00	CONTROL LINES, REMOTE (COOLER) (PW64H00047F1)
05-008	00	CONTROL LINES, REMOTE (COOLER) (PW64H00047F1)
05-009	00	CONTROL LINES, REMOTE (WITH A PUMP Z PORT) (PW62H00029F1, PW64H00069F1)
05-010	00	CONTROL LINES, REMOTE (WITH A PUMP Z PORT) (PW62H00069F1)
05-012	00	CAB INSTAL (COOLER) (PW02C00073F1, PW02C00060F1%K2)
05-013	00	CAB INSTAL (COOLER) (PW02C00041F1)
05-014	00	CAB ASSY (COOLER) (PW02C00069F1)
05-015	00	CAB ASSY (COOLER) (PW02C00069F1, PW50C00002F1)
05-016	00	CAB ASSY (COOLER) (PW02C00069F1)
05-017	00	CAB ASSY (COOLER) (PW02C00069F1)
05-018	00	CAB ASSY (COOLER) (PW02C00069F1)
05-019	00	RADIO INSTAL (WITHOUT RADIO) (PM54E00003F2)
05-020	00	STOPPER ASSY (COOLER) (PW25M01067F1)
05-021	00	GUARD INSTAL (COOLER) (PW21C00034F1, PW22C00022F1)
05-022	00	GUARD INSTAL (COOLER) (PW21C00034F1)
05-023	00	GUARD INSTAL (COOLER) (PW21C00034F1, PW21C00027F1)
05-024	00	GUARD INSTAL (COOLER) (PW21C00034F1)
05-025	00	GUARD INSTAL (COOLER) (PW21C00034F1, PW22C01151F1)
05-026	00	COOLER ASSY (PW20M00028F1, PW20M00025F1)
05-027	00	COOLER ASSY (PW20M00022F1)
05-028	00	DRIER ASSY, AIR (PW96V00005F1)
05-029	00	COOLER ASSY (PH20M00016F1)
05-030	00	COOLER ASSY (PH20M00019F1)
05-031	00	HARNESS ASSY (COOLER) (PH11E00012F1)
06-001	00	NAME PLATE INSTALLATION (PW22T00083F2), PAGE 1 OF 2
06-001	01	NAME PLATE INSTALLATION (PW22T00083F2), PAGE 2 OF 2
06-002	00	NAME PLATE INSTALLATION (PW22T00123F1)
06-005	00	NAME PLATE INSTALLATION (PW22T00185F1)
06-006	00	NAME PLATE INSTALLATION (DECEL) (PW22T00113F1)
06-007	00	NAME PLATE INSTALLATION (PW22T00183F1)
06-008	00	NAME PLATE INSTALLATION (PW22T00182F1)
06-009	00	NAME PLATE INSTALLATION (CEMA MARK) (YN22T00288F1)

Order the manual at mid-west-tech.com >