# PARTS CATALOG

## E35B
## Compact Crawler Excavator

ASN PX15-21105

Print No. S3PX00041ZE02
9/2010

NEW HOLLAND CONSTRUCTION



Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX


| | FIGURE | SEQ. |
|---|---|---|
| ALARM ASSY | 05-002 | 00 |
| ARM ASSY | 03-017 | 00 |
| ARM ASSY (1.32M) | 03-016 | 00 |
| ARM ASSY, LONG | 03-018 | 00 |
| ARM GROUP | 03-020 | 00 |
| ARM INSTAL | 03-021 | 00 |
| ARM INSTAL | 03-022 | 00 |
| ARM, LONG | 03-019 | 00 |
| BATTERY ASSY | 01-094 | 00 |
| BOOM GROUP | 03-002 | 00 |
| BOOM HOE, 2.5M | 03-001 | 00 |
| BOOM INSTAL | 03-003 | 00 |
| BRACKET GROUP, SWING | 01-003 | 00 |
| BRACKET INSTAL,SWING | 01-004 | 00 |
| BUCKET ASSY, 350W 0.05M³ (0.04M³) | 03-031 | 00 |
| BUCKET ASSY, 450W 0.07M³ (0.06M³) | 03-032 | 00 |
| BUCKET ASSY, 500W 0.09M³ (0.08M³) | 03-029 | 00 |
| BUCKET ASSY, 600W 0.11M³ (0.10M³) | 03-030 | 00 |
| BUCKET ASSY, 700W 0.13M³ (0.11M³) | 03-033 | 00 |
| BUCKET INSTAL | 03-028 | 00 |
| CAB INSTAL | 01-069 | 09 |
| CAB INSTAL | 01-069 | 08 |
| CAB INSTAL | 01-069 | 07 |
| CAB INSTAL | 01-069 | 06 |
| CAB INSTAL | 01-069 | 05 |
| CAB INSTAL | 01-069 | 04 |
| CAB INSTAL | 01-069 | 03 |
| CAB INSTAL | 01-069 | 02 |
| CAB INSTAL | 01-069 | 01 |
| CAB INSTAL | 01-068 | 08 |
| CAB INSTAL | 01-068 | 07 |
| CAB INSTAL | 01-068 | 06 |
| CAB INSTAL | 01-068 | 05 |
| CAB INSTAL | 01-068 | 04 |
| CAB INSTAL | 01-068 | 03 |
| CAB INSTAL | 01-068 | 02 |
| CAB INSTAL | 01-068 | 01 |
| CAB INSTAL | 01-073 | 00 |
| CAB INSTAL, COOLER | 01-074 | 00 |
| CAB INSTAL, HEAD GUARD, COOLER | 01-071 | 09 |
| CAB INSTAL, HEAD GUARD, COOLER | 01-071 | 08 |
| CAB INSTAL, HEAD GUARD, COOLER | 01-071 | 07 |
| CAB INSTAL, HEAD GUARD, COOLER | 01-071 | 06 |
| CAB INSTAL, HEAD GUARD, COOLER | 01-071 | 05 |
| CAB INSTAL, HEAD GUARD, COOLER | 01-071 | 04 |
| CAB INSTAL, HEAD GUARD, COOLER | 01-071 | 03 |
| CAB INSTAL, HEAD GUARD, COOLER | 01-071 | 02 |
| CAB INSTAL, HEAD GUARD, COOLER | 01-071 | 01 |
| CAB INSTAL, WITH HEAD GUARD | 01-070 | 09 |
| CAB INSTAL, WITH HEAD GUARD | 01-070 | 08 |
| CAB INSTAL, WITH HEAD GUARD | 01-070 | 07 |
| CAB INSTAL, WITH HEAD GUARD | 01-070 | 06 |
| CAB INSTAL, WITH HEAD GUARD | 01-070 | 05 |
| CAB INSTAL, WITH HEAD GUARD | 01-070 | 04 |
| CAB INSTAL, WITH HEAD GUARD | 01-070 | 03 |
| CAB INSTAL, WITH HEAD GUARD | 01-070 | 02 |



Order the manual at mid-west-tech.com >

| | | |
|---|---|---|
| CAB INSTAL, WITH HEAD GUARD | 01-070 | 01 |
| CAMSHAFT & DRIVING GEAR | 08-007 | 00 |
| CANOPY ASSY | 01-078 | 02 |
| CANOPY ASSY | 01-078 | 01 |
| CANOPY INSTAL | 01-075 | 00 |
| CAP ASSY | 03-023 | 00 |
| CLEANER ASSY, AIR, CAB | 01-015 | 00 |
| CLEANER ASSY, AIR, CANOPY | 01-014 | 00 |
| CONDITIONER INSTAL | 01-091 | 00 |
| CONTROL ASSY, ENGINE, WITH DECEL | 01-024 | 02 |
| CONTROL ASSY, ENGINE, WITH DECEL | 01-024 | 01 |
| CONTROL LINES, MAIN, ANGLE DOZER | 01-050 | 00 |
| CONTROL LINES, MAIN, J/D MULTI | 01-049 | 00 |
| CONTROL LINES, MULTI, J/D MULTI | 01-051 | 00 |
| CONTROL LINES, PROPEL, ANGLE DOZER | 01-065 | 02 |
| CONTROL LINES, PROPEL, ANGLE DOZER | 01-065 | 01 |
| CONTROL LINES, PROPEL, NIBBLER & BREAKER | 01-064 | 02 |
| CONTROL LINES, PROPEL, NIBBLER & BREAKER | 01-064 | 01 |
| CONTROL LINES, REMOTE | 01-053 | 02 |
| CONTROL LINES, REMOTE | 01-053 | 01 |
| CONTROL LINES, REMOTE, ANGLE DOZER | 01-054 | 02 |
| CONTROL LINES, REMOTE, ANGLE DOZER | 01-054 | 01 |
| CONTROL LINES, REMOTE, DOZER | 01-052 | 02 |
| CONTROL LINES, REMOTE, DOZER | 01-052 | 01 |
| CONTROL LINES, VALVE | 01-063 | 02 |
| CONTROL LINES, VALVE | 01-063 | 03 |
| CONTROL LINES, VALVE | 01-063 | 01 |
| CONTROL LINES, VALVE | 01-057 | 03 |
| CONTROL LINES, VALVE | 01-057 | 02 |
| CONTROL LINES, VALVE | 01-057 | 01 |
| CONTROL LINES, VALVE | 01-056 | 03 |
| CONTROL LINES, VALVE | 01-056 | 02 |
| CONTROL LINES, VALVE | 01-056 | 01 |
| CONTROL LINES, VALVE | 01-055 | 02 |
| CONTROL LINES, VALVE | 01-055 | 01 |
| CONTROL LINES, VALVE, ANGLE DOZER | 01-061 | 02 |
| CONTROL LINES, VALVE, ANGLE DOZER | 01-061 | 03 |
| CONTROL LINES, VALVE, ANGLE DOZER | 01-061 | 01 |
| CONTROL LINES, VALVE, ANGLE DOZER | 01-059 | 02 |
| CONTROL LINES, VALVE, ANGLE DOZER | 01-059 | 01 |
| CONTROL LINES, VALVE, COOLER | 01-060 | 03 |
| CONTROL LINES, VALVE, COOLER | 01-060 | 04 |
| CONTROL LINES, VALVE, COOLER | 01-060 | 02 |
| CONTROL LINES, VALVE, COOLER | 01-060 | 01 |
| CONTROL LINES, VALVE, NIBBLER AND BREAKER | 01-058 | 00 |
| CONTROL LINES, VALVE, WITH A PUMP Z PORT | 01-062 | 03 |
| CONTROL LINES, VALVE, WITH A PUMP Z PORT | 01-062 | 04 |
| CONTROL LINES, VALVE, WITH A PUMP Z PORT | 01-062 | 02 |
| CONTROL LINES, VALVE, WITH A PUMP Z PORT | 01-062 | 01 |
| CONTROLS, OPERATORS | 01-040 | 03 |
| CONTROLS, OPERATORS | 01-040 | 02 |
| CONTROLS, OPERATORS | 01-040 | 01 |
| CONTROLS, OPERATORS, CAB | 01-044 | 02 |
| CONTROLS, OPERATORS, CAB | 01-044 | 01 |
| CONTROLS, OPERATORS, CAB, ANGLE DOZER | 01-043 | 02 |
| CONTROLS, OPERATORS, CAB, ANGLE DOZER | 01-043 | 03 |
| CONTROLS, OPERATORS, CAB, ANGLE DOZER | 01-043 | 01 |
| CONTROLS, OPERATORS, CANOPY | 01-042 | 02 |

MidWestTech | New Holland E35B Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >

| | | |
|---|---|---|
| CONTROLS, OPERATORS, CANOPY | 01-042 | 01 |
| CONTROLS, OPERATORS, CANOPY, ANGLE DOZER | 01-041 | 03 |
| CONTROLS, OPERATORS, CANOPY, ANGLE DOZER | 01-041 | 02 |
| CONTROLS, OPERATORS, CANOPY, ANGLE DOZER | 01-041 | 01 |
| COOLER ASSY | 01-092 | 03 |
| COOLER ASSY | 01-092 | 02 |
| COOLER ASSY | 01-092 | 01 |
| COOLER ASSY | 01-093 | 00 |
| COOLING WATER SYSTEM | 08-010 | 00 |
| COUNTERWEIGHT INSTAL | 01-007 | 00 |
| COUNTERWEIGHT INSTAL, GAIN | 01-008 | 00 |
| COVER ASSY | 01-045 | 00 |
| COVER ASSY, UNDER | 01-087 | 00 |
| CRANKSHAFT & PISTON | 08-008 | 00 |
| CYLINDER BLOCK | 08-001 | 00 |
| CYLINDER HEAD & BONNET | 08-004 | 00 |
| CYLINDER INSTAL | 03-007 | 02 |
| CYLINDER INSTAL | 03-007 | 01 |
| CYLINDER INSTAL | 03-006 | 01 |
| CYLINDER INSTAL | 03-006 | 02 |
| CYLINDER INSTAL | 01-005 | 01 |
| CYLINDER INSTAL | 01-005 | 02 |
| CYLINDER INSTAL, ANGLE DOZER | 02-022 | 01 |
| CYLINDER INSTAL, ANGLE DOZER | 02-022 | 02 |
| CYLINDER INSTAL, CAB | 03-005 | 02 |
| CYLINDER INSTAL, CAB | 03-005 | 01 |
| CYLINDER INSTAL, CANOPY | 03-004 | 02 |
| CYLINDER INSTAL, CANOPY | 03-004 | 01 |
| CYLINDER INSTAL, DOZER | 02-023 | 02 |
| CYLINDER INSTAL, DOZER | 02-023 | 01 |
| DOZER ASSY | 02-017 | 00 |
| DOZER ASSY, ANGLE DOZER | 02-018 | 00 |
| DOZER GROUP | 02-019 | 00 |
| DOZER GROUP, ANGLE DOZER | 02-020 | 00 |
| DOZER INSTAL | 02-021 | 00 |
| ELEC ASSY, UPP | 01-097 | 02 |
| ELEC ASSY, UPP | 01-097 | 01 |
| ELEC ASSY, UPP, ANGLE DOZER | 01-098 | 02 |
| ELEC ASSY, UPP, ANGLE DOZER | 01-098 | 01 |
| ENGINE INSTAL | 01-009 | 00 |
| ENGINE INSTAL, COOLER | 01-010 | 00 |
| EXHAUST MANIFOLD | 08-006 | 00 |
| FILTER LIST | 00-001 | 00 |
| FLYWHEEL HOUSING & OIL SUMP | 08-003 | 00 |
| FRAME GROUP, UPP | 01-001 | 00 |
| FRAME GROUP, UPP, ANGLE DOZER | 01-002 | 00 |
| FUEL INJECTION PUMP | 08-011 | 00 |
| FUEL INJECTION VALVE | 08-013 | 00 |
| FUEL LINE | 08-014 | 00 |
| FUEL LINES | 01-017 | 00 |
| FUEL LINES, COOLER | 01-018 | 00 |
| GASKET SET | 08-017 | 00 |
| GEAR HOUSING | 08-002 | 00 |
| GENERATOR | 08-016 | 00 |
| GOVERNOR | 08-012 | 00 |
| GRIP ASSY | 01-047 | 00 |
| GROMMET, CAB | 01-090 | 00 |
| GROMMET, CANOPY | 01-089 | 00 |


Order the manual at mid-west-tech.com >

## VALVE INSTAL, NIBBLER AND BREAKER

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | PX30V00058R200 | | 1 | REPAIR KIT, Consists Of Ref: 10-26C (1), 10-26D (1), 10-26E (1), 10-26F (1), 10-26S (1) |
| | | {PX30V00052R200} | | 1 | Consists Of Ref: 10-27C (1), 10-27D (1), 10-27E (1), 10-27F (1), 10-27U (1) |



MidWestTech | New Holland E35B Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >

VALVE INSTAL, ANGLE DOZER

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | {PX30V00051R200} | | 1 | Consists Of Ref: 10-22C (1), 10-22D (1), 10-22E (1), 10-22F (1), 10-22S (1) |
| | | {PX30V00054R200} | | 1 | Consists Of Ref: 10-23C (1), 10-23D (1), 10-23E (1), 10-23F (1), 10-23R (1) |
| | | {PX30V00054R200} | | 1 | Consists Of Ref: 10-24C (1), 10-24D (1), 10-24E (1), 10-24F (1), 10-24R (1) |
| | | PX30V00057R200 | | 1 | REPAIR KIT, Consists Of Ref: 10-25C (1), 10-25D (1), 10-25E (1), 10-25F (1), 10-25G (1), 10-25H (1), 10-25S (1) |
| | | PX30V00058R200 | | 1 | REPAIR KIT, Consists Of Ref: 10-26C (1), 10-26D (1), 10-26E (1), 10-26F (1), 10-26S (1) |
| | | {PX30V00052R200} | | 1 | Consists Of Ref: 10-27C (1), 10-27D (1), 10-27E (1), 10-27F (1), 10-27U (1) |
| | | {PX30V00049R300} | | 1 | Consists Of Ref: 10-27B (1), 10-27C (1), 10-27D (1), 10-27E (1), 10-27F (1) |



MidWestTech | New Holland E35B Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >

## CRANKSHAFT & PISTON

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | | {VV12900821000} | | 1 | Includes Refs. 2 - 5 |
| 2 | | VV12910001580 | | 1 | PIN, Parallel, 8 x 16 |
| 4 | | {VV11980321200} | | 1 | Crankshaft |
| 5 | | VV22512070140 | | 1 | KEY, 7 x 14 |
| 7 | | VV22351030010 | | 1 | PIN, Spring, 3 x 10 |
| 8 | | VV12900421650 | | 1 | PULLEY, V, Crankshaft |
| 9 | | VV12979521661 | | 1 | WASHER |
| 10 | | VV12185021680 | | 1 | BOLT, V-Pulley |
| 11 | | VV12111121501 | | 6 | BOLT, Flywheel |
| 12 | | VV12912821590 | | 1 | FLYWHEEL, W/Ring Gear, Includes Ref. 14 |
| 14 | | VV11986521600 | | 1 | GEAR, Ring |
| 15 | | VV12900522080 | | 3 | PISTON ASSY, Stud, Cyl. Head, Includes Ref. 17 |
| 17 | | VV12900522500 | | 3 | PISTON RING SET |
| 21 | | VV12920222300 | | 3 | PISTON PIN, (D26,L70) |
| 22 | | VV22252000260 | | 6 | CIRCLIP, 26 |
| 23 | | VV72940223100 | | 3 | ROD, Assy., Connecting, Includes Refs. 27 and 28 |
| 27 | | VV12155023200 | | 6 | BOLT, Connecting Rod |
| 28 | | VV12915023601 | | 3 | PIN, Metal, Crank |
| 30 | 1 | VV12910023910 | | 3 | BUSHING, Piston Pin |
| 31 | 2 | {VV12915023611} | | 3 | Pin |
| 33 | 3 | VV12900522900 | | 3 | PISTON, W/Ring, Includes Ref. 35 |
| 35 | 3 | VV12900522950 | | 3 | RING, Set |

(1) Repair Part
(2) Governor Assy. is Incorporated in This Fuel Injection Pump Assy.
(3) Over-Size (O.S=0.25) Part



MidWestTech | New Holland E35B Compact Crawler Excavator Parts Catalog | Publication... Order the manual at mid-west-tech.com >