KOBELCO®

# PARTS CATALOG

## SK235SRLC-2
## Short Radius
## Excavator

APPLICABLE
ASN YU06-03001

S3YF00014ZE03
Issued 3/2011



Order the manual at mid-west-tech.com >

# ALPHABETICAL INDEX


| | FIGURE | SEQ. |
|---|---|---|
| AIR CLEANER ASSY | 01-010 | 00 |
| AIR CONDITIONING | 01-080 | 03 |
| AIR CONDITIONING | 01-080 | 04 |
| AIR CONDITIONING | 01-080 | 05 |
| AIR CONDITIONING | 01-080 | 06 |
| AIR CONDITIONING | 01-080 | 07 |
| AIR CONDITIONING | 01-080 | 08 |
| AIR CONDITIONING | 01-080 | 01 |
| AIR CONDITIONING | 01-080 | 02 |
| ALARM ASSY | 01-088 | 00 |
| ALTERNATOR | 08-035 | 00 |
| ARM (HD) | 03-023 | 00 |
| ARM GROUP | 03-024 | 01 |
| ARM GROUP | 03-024 | 02 |
| ARM GROUP (NIBBLER & BREAKER) | 03-021 | 00 |
| ARM INSTALL | 03-022 | 00 |
| BATTERY ASSY | 01-079 | 00 |
| BOOM GROUP | 03-003 | 00 |
| BOOM INSTALL | 03-001 | 00 |
| BOOM, HOE 5.65M | 03-002 | 00 |
| BUCKET INSTALL | 03-025 | 00 |
| CAB INSTALL | 01-062 | 05 |
| CAB INSTALL | 01-062 | 06 |
| CAB INSTALL | 01-062 | 07 |
| CAB INSTALL | 01-062 | 08 |
| CAB INSTALL | 01-062 | 09 |
| CAB INSTALL | 01-062 | 10 |
| CAB INSTALL | 01-062 | 11 |
| CAB INSTALL | 01-062 | 12 |
| CAB INSTALL | 01-062 | 13 |
| CAB INSTALL | 01-062 | 01 |
| CAB INSTALL | 01-062 | 02 |
| CAB INSTALL | 01-062 | 03 |
| CAB INSTALL | 01-062 | 04 |
| CAMSHAFT AND IDLE GEAR | 08-016 | 00 |
| CAP ASSY | 03-019 | 00 |
| CAP ASSY | 03-020 | 00 |
| CAP ASSY (BOOM) | 03-018 | 00 |
| COMMON-RAIL (DENSO) | 08-015 | 00 |
| CONNECTOR ASSY (NIBBLER & BREAKER) | 03-012 | 00 |
| CONTROL LINES, BLOCK | 01-040 | 02 |
| CONTROL LINES, BLOCK | 01-040 | 03 |
| CONTROL LINES, BLOCK | 01-041 | 00 |
| CONTROL LINES, BLOCK | 01-042 | 00 |
| CONTROL LINES, BLOCK | 01-040 | 01 |
| CONTROL LINES, MAIN | 01-026 | 01 |
| CONTROL LINES, MAIN | 01-026 | 02 |
| CONTROL LINES, MULTI | 01-039 | 01 |
| CONTROL LINES, MULTI | 01-039 | 02 |
| CONTROL LINES, MULTI | 01-039 | 03 |
| CONTROL LINES, MULTI | 01-039 | 04 |
| CONTROL LINES, MULTI | 01-039 | 05 |
| CONTROL LINES, PROPEL | 01-038 | 01 |
| CONTROL LINES, PROPEL | 01-038 | 02 |
| CONTROL LINES, PUMP | 01-037 | 00 |
| CONTROL LINES, REMOTE | 01-034 | 01 |



Order the manual at mid-west-tech.com >

| | | |
|---|---|---|
| CONTROL LINES, REMOTE | 01-034 | 02 |
| CONTROL LINES, REMOTE | 01-034 | 03 |
| CONTROL LINES, REMOTE | 01-034 | 04 |
| CONTROL LINES, REMOTE (NIBBLER & BREAKER) | 01-036 | 02 |
| CONTROL LINES, REMOTE (NIBBLER & BREAKER) | 01-036 | 03 |
| CONTROL LINES, REMOTE (NIBBLER & BREAKER) | 01-036 | 04 |
| CONTROL LINES, REMOTE (NIBBLER & BREAKER) | 01-035 | 01 |
| CONTROL LINES, REMOTE (NIBBLER & BREAKER) | 01-035 | 02 |
| CONTROL LINES, REMOTE (NIBBLER & BREAKER) | 01-036 | 01 |
| CONTROL LINES, VALVE | 01-029 | 05 |
| CONTROL LINES, VALVE | 01-029 | 01 |
| CONTROL LINES, VALVE | 01-029 | 02 |
| CONTROL LINES, VALVE | 01-029 | 03 |
| CONTROL LINES, VALVE | 01-029 | 04 |
| CONTROL LINES, VALVE (NIBBLER & BREAKER) | 01-030 | 01 |
| CONTROL LINES, VALVE (NIBBLER & BREAKER) | 01-030 | 02 |
| CONTROL LINES, VALVE (NIBBLER & BREAKER) | 01-030 | 03 |
| CONTROL LINES, VALVE (NIBBLER & BREAKER) | 01-030 | 04 |
| CONTROL LINES, VALVE (NIBBLER & BREAKER) | 01-030 | 05 |
| CONTROL LINES, VALVE (NIBBLER & BREAKER) | 01-030 | 06 |
| CONTROL LINES, VALVE (NIBBLER & BREAKER) | 01-030 | 07 |
| CONTROLLER INSTALL | 01-054 | 01 |
| CONTROLLER INSTALL | 01-054 | 02 |
| CONTROLLER INSTALL | 01-054 | 03 |
| CONTROLLER INSTALL | 01-054 | 04 |
| CONTROLS, OPERATORS | 01-050 | 02 |
| CONTROLS, OPERATORS | 01-050 | 03 |
| CONTROLS, OPERATORS | 01-050 | 04 |
| CONTROLS, OPERATORS | 01-050 | 05 |
| CONTROLS, OPERATORS | 01-050 | 06 |
| CONTROLS, OPERATORS | 01-050 | 07 |
| CONTROLS, OPERATORS | 01-050 | 08 |
| CONTROLS, OPERATORS | 01-050 | 09 |
| CONTROLS, OPERATORS | 01-050 | 01 |
| CONTROLS, OPERATORS (NIBBLER & BREAKER) | 01-051 | 01 |
| CONTROLS, OPERATORS (NIBBLER & BREAKER) | 01-051 | 02 |
| CONTROLS, OPERATORS (NIBBLER & BREAKER) | 01-051 | 03 |
| CONTROLS, OPERATORS (NIBBLER & BREAKER) | 01-051 | 04 |
| CONTROLS, OPERATORS (NIBBLER & BREAKER) | 01-051 | 05 |
| CONTROLS, OPERATORS (NIBBLER & BREAKER) | 01-051 | 06 |
| CONTROLS, OPERATORS (NIBBLER & BREAKER) | 01-051 | 07 |
| CONTROLS, OPERATORS (NIBBLER & BREAKER) | 01-051 | 08 |
| COOLING SYSTEM | 08-030 | 00 |
| COUNTERWEIGHT INSTALL | 01-003 | 00 |
| COUNTERWEIGHT INSTALL (GAIN) | 01-004 | 00 |
| COVER ASSY, UNDER | 01-073 | 00 |
| CYLINDER BLOCK | 08-001 | 02 |
| CYLINDER BLOCK | 08-001 | 01 |
| CYLINDER HEAD | 08-006 | 02 |
| CYLINDER HEAD | 08-006 | 01 |
| CYLINDER INSTALL (ARM) | 03-030 | 01 |
| CYLINDER INSTALL (ARM) | 03-030 | 02 |
| CYLINDER INSTALL (BOOM) | 03-029 | 01 |
| CYLINDER INSTALL (BOOM) | 03-029 | 02 |
| CYLINDER INSTALL (BUCKET) | 03-031 | 01 |
| CYLINDER INSTALL (BUCKET) | 03-031 | 02 |
| ELECTRICAL ASSY, UPPER | 01-078 | 00 |
| ELECTRICAL PARTS (ENGINE) | 08-012 | 01 |



Order the manual at mid-west-tech.com >

| | | |
|---|---|---|
| ELECTRICAL PARTS (ENGINE) | 08-012 | 02 |
| ELECTRICAL PARTS (ENGINE) | 08-012 | 03 |
| ELEMENT KIT | 04-002 | 00 |
| ENGINE ACCESSORY PARTS | 08-008 | 00 |
| ENGINE INSTALL | 01-005 | 01 |
| ENGINE INSTALL | 01-005 | 02 |
| FILTER LIST | 00-001 | 00 |
| FRAME ASSY, LOW (LONG CRAWLER) | 02-002 | 00 |
| FRAME GROUP, UPPER | 01-006 | 01 |
| FRAME GROUP, UPPER | 01-006 | 02 |
| FRAME GROUP, UPPER | 01-002 | 01 |
| FRAME GROUP, UPPER | 01-002 | 02 |
| FRAME, UPPER | 01-001 | 00 |
| FUEL FILTER | 08-019 | 00 |
| FUEL LINES | 01-012 | 00 |
| FUEL SYSTEM | 08-017 | 00 |
| FUEL SYSTEM | 08-018 | 00 |
| FUEL TANK INSTALL | 01-013 | 00 |
| GASKET KIT (ENGINE OVERHAUL) | 08-007 | 00 |
| GUARD INSTALL | 01-069 | 05 |
| GUARD INSTALL | 01-069 | 06 |
| GUARD INSTALL | 01-069 | 07 |
| GUARD INSTALL | 01-069 | 08 |
| GUARD INSTALL | 01-069 | 09 |
| GUARD INSTALL | 01-069 | 10 |
| GUARD INSTALL | 01-069 | 11 |
| GUARD INSTALL | 01-069 | 12 |
| GUARD INSTALL | 01-069 | 13 |
| GUARD INSTALL | 01-069 | 14 |
| GUARD INSTALL | 01-069 | 01 |
| GUARD INSTALL | 01-069 | 02 |
| GUARD INSTALL | 01-069 | 03 |
| GUARD INSTALL | 01-069 | 04 |
| HARNESS ASSY, BOOM | 03-004 | 00 |
| HARNESS ASSY, CAB | 01-087 | 01 |
| HARNESS ASSY, CAB | 01-087 | 02 |
| HARNESS ASSY, ENGINE | 01-085 | 00 |
| HARNESS ASSY, UPPER | 01-086 | 01 |
| HARNESS ASSY, UPPER | 01-086 | 02 |
| HARNESS ASSY, UPPER | 01-083 | 08 |
| HARNESS ASSY, UPPER | 01-083 | 09 |
| HARNESS ASSY, UPPER | 01-083 | 01 |
| HARNESS ASSY, UPPER | 01-083 | 02 |
| HARNESS ASSY, UPPER | 01-083 | 03 |
| HARNESS ASSY, UPPER | 01-083 | 04 |
| HARNESS ASSY, UPPER | 01-083 | 05 |
| HARNESS ASSY, UPPER | 01-083 | 06 |
| HARNESS ASSY, UPPER | 01-083 | 07 |
| HARNESS ASSY, UPPER (NIBBLER & BREAKER) | 01-084 | 09 |
| HARNESS ASSY, UPPER (NIBBLER & BREAKER) | 01-084 | 10 |
| HARNESS ASSY, UPPER (NIBBLER & BREAKER) | 01-084 | 01 |
| HARNESS ASSY, UPPER (NIBBLER & BREAKER) | 01-084 | 02 |
| HARNESS ASSY, UPPER (NIBBLER & BREAKER) | 01-084 | 03 |
| HARNESS ASSY, UPPER (NIBBLER & BREAKER) | 01-084 | 04 |
| HARNESS ASSY, UPPER (NIBBLER & BREAKER) | 01-084 | 05 |
| HARNESS ASSY, UPPER (NIBBLER & BREAKER) | 01-084 | 06 |
| HARNESS ASSY, UPPER (NIBBLER & BREAKER) | 01-084 | 07 |
| HARNESS ASSY, UPPER (NIBBLER & BREAKER) | 01-084 | 08 |



Order the manual at mid-west-tech.com >

## HARNESS ASSY, CAB

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| | | {YY14E00028F1} | ASN YU06-03008 | AR | Cab |
| 1 | | LF14E01031P2 | BTW YU06-03008 & YU06-03010 | 1 | WIRE HARNESS |
| 1 | | LF14E01031P3 | ASN YU06-03011 | 1 | WIRE HARNESS |
| 2 | | PY01P01043D3 | | 29 | CLIP |
| 3 | | YN13E01375P1 | | 17 | CLIP |
| 4 | | LF14E01029P1 | BTW YU06-03008 & YU06-03010 | 1 | WIRE HARNESS |
| 4 | | LF14E01033P1 | ASN YU06-03011 | 1 | WIRE HARNESS |
| 5 | | PY01P01043D5 | BTW YU06-03008 & YU06-03010 | 2 | CLIP |
| 5 | | PY01P01043D5 | ASN YU06-03011 | 1 | CLIP |



MidWestTech | Kobelco SK235SRLC-2 Short Radius Hydraulic Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >

## CYLINDER HEAD

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | | VH111014950A | | 1 | HEAD, Sub Assy., Cyl., Includes Ref. 2-12 |
| 2 | | VH111221220A | | 16 | BUSHING, Valve Guide Intake, Repair Std. |
| 3 | | VH111311480A | | 8 | SEAT, Valve Intake |
| 4 | | VH111351720A | | 8 | SEAT/SLOT, Valve Exh. |
| 5 | | VH111761190A | | 4 | SEAT, Inj. Nozzle |
| 6 | | VH900115214A | | 4 | GASKET |
| 7 | | VH906808500A | | 10 | BOLT, Flange |
| 8 | | VH950404080A | | 10 | PIN, Straight |
| 9 | | VH963317120A | | 4 | PLUG, Sealing |
| 10 | | VH963322160A | | 8 | PLUG, Sealing |
| 11 | | VH963330160A | | 5 | PLUG, Sealing |
| 12 | | VH980006100A | | 4 | BALL, Steel |



MidWestTech | Kobelco SK235SRLC-2 Short Radius Hydraulic Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >

## STARTER MOTOR

| REF | FN | PART NUMBER | YR/SN | QTY | DESCRIPTION |
|---|---|---|---|---|---|
| 1 | | VH280111640A | | 1 | CLUTCH, Sub Assy., Start |
| 2 | 1 | VH281002894A | | 1 | STARTER MOTOR, Assy., Includes Ref. 1 & 3-37 |
| 3 | | VH281111470A | | 1 | DRIVE, Bosh, Housing |
| 4 | | VH281111480A | | 1 | DRIVE, Bosh, Housing |
| 5 | | VH281122620A | | 2 | BOLT, Housing Set |
| 6 | | VH281122000A | | 2 | BOLT, Housing Set |
| 7 | | VH281122610A | | 2 | BOLT, Housing Set |
| 8 | | VH281131360A | | 1 | LEVER, Pinion Drive |
| 9 | | VH281152231A | | 1 | HOUSING, Start Drive, Includes Ref. 3, 10 & 31 |
| 10 | | VH281171300A | | 1 | PACKING |
| 11 | | VH281171310A | | 1 | PACKING |
| 12 | | VH281181450A | | 1 | PLATE |
| 13 | | VH281181520A | | 1 | PLATE |
| 14 | | VH281181530A | | 1 | PLATE |
| 15 | | VH281181540A | | 1 | PLATE |
| 16 | | VH281181550A | | 1 | PLATE |
| 17 | | VH281181561A | | 1 | PLATE |
| 18 | | VH281181570A | | 1 | PLATE |
| 19 | | VH281201900A | | 1 | YOKE, Assy., Start, Includes Ref. 23 & 24 |
| 20 | | VH281332400A | | 1 | FRAME, Commutator End |
| 21 | | VH281381370A | | 2 | PACKING |
| 22 | | VH281401680A | | 1 | HOLDER, Assy., Start Brush, Includes Ref. 25 |
| 23 | | VH281421530A | | 1 | BRUSH, Start |
| 24 | | VH281421540A | | 1 | BRUSH, Start |
| 25 | | VH281431200A | | 4 | SPRING, Start Brush |
| 26 | | VH281502554A | | 1 | SWITCH, Assy., Start Magnet, Includes Ref. 4 |
| 27 | | VH281601760A | | 1 | ARMATURE, Assy., Start, Includes Ref. 34 |
| 28 | | VH281681400A | | 1 | RING, Retainer |
| 29 | | VH281681370A | | 2 | RING, Retainer |
| 30 | | VH281711210A | | 1 | HYD CONNECTOR, W/Lead Wire |
| 31 | | VH281991100A | | 1 | PROTECTOR, Dust Start |
| 32 | 2 | VH282271010A | | AR | GREASE, Starter Repair Service |

(1) 24V-5Kw
(2) Pyronoc No.2



MidWestTech | Kobelco SK235SRLC-2 Short Radius Hydraulic Excavator Parts Catalog | P... Order the manual at mid-west-tech.com >