KOBELCO

PARTS CATALOG

DYNAMIC ACERA EXCAVATOR

SK200-6ES

SK200LC-6ES

S3YN00028ZE01 NA

Issued 01June07

APPLICABLE:
SK200-6ES . . . . . YN10-38001~41732
SK200LC-6ES . . . . YQ10-05501~05981

MidWestTech | Kobelco SK200-6ES, SK200LC-6ES Dynamic Acera Hydraulic Excavator Parts Catalog | Publication S3YN00028ZE01

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

01-001		FILTER LIST
01-002		SLEEVE
01-003		NUT
01-004		PAINT COLOR
02-001		UPPER FRAME ASSEMBLY
02-002		COUNTERWEIGHT ASSY
02-003		COUNTERWEIGHT ASSY (GAIN)
02-004		ENGINE ASSY
02-005		ENGINE INSTAL
02-006	01	RADIATOR INSTAL
02-006	02	RADIATOR INSTAL
02-007		RADIATOR ASSY
02-008		CLEANER ASSY, AIR
02-009		W ELEMENT
02-010		MUFFLER ASSY
02-011		FUEL LINES
02-012		SEPARATOR ASSY, WATER
02-013		TANK ASSY, FUEL
02-014		TANK ASSY, HYD
02-015		CONTROL ASSY, ENGINE
02-016		POWER TAKE-OFF ASSY
02-017		MOTOR INSTAL, SWING
02-018		REDUCTION ASSY, SWING
02-019		VALVE INSTAL
02-020	01	HYDRAULIC LINES, UPPER (SUCTION, DELIVERY)
02-020	02	HYDRAULIC LINES, UPPER (SUCTION, DELIVERY)
02-021	01	HYDRAULIC LINES, UPPER (MAIN)
02-021	02	HYDRAULIC LINES, UPPER (MAIN)
02-022	01	HYDRAULIC LINES, UPPER (RETURN)
02-022	02	HYDRAULIC LINES, UPPER (RETURN)
02-023	01	CONTROLS, OPERATORS
02-023	02	CONTROLS, OPERATORS
02-024		CONTROL BOX ASSEMBLY
02-025		LEVER ASSEMBLY, PROPEL
02-026	01	CONTROL LINES, REMOTE
02-026	02	CONTROL LINES, REMOTE
02-026	03	CONTROL LINES, REMOTE
02-027	01	CONTROL LINES, REMOTE
02-027	02	CONTROL LINES, REMOTE
02-028	01	CONTROL LINES, REMOTE
02-028	02	CONTROL LINES, REMOTE
02-029		PLATE GROUP, FLOOR
02-030		CAB INSTAL
02-031		CAB INSTAL (HD)
02-032		CAB ASSEMBLY
02-033	01	GUARD INSTAL (CAB)
02-033	02	GUARD INSTAL (CAB)
02-034	01	CAB ASSY
02-034	02	CAB ASSY
02-034	03	CAB ASSY
02-035	01	CAB ASSY (HD)
02-035	02	CAB ASSY (HD)
02-035	03	CAB ASSY (HD)

MidWestTech | Kobelco SK200-6ES, SK200LC-6ES Dynamic Acera Hydraulic Excavator Pa... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

02-036		WINDOW ASSY, FR
02-037	01	DOOR ASSY, CAB
02-037	02	DOOR ASSY, CAB
02-038		SEAT GROUP
02-039		SEAT ASSY
02-040		BELT ASSY, SEAT
02-041	01	GUARD INSTAL
02-041	02	GUARD INSTAL
02-042		COVER ASSEMBLY
02-043		BONNET ASSEMBLY
02-044		COVER ASSEMBLY, UNDER
02-045		COVER ASSEMBLY, UNDER (HD)
02-046	01	PANEL ASSEMBLY, INSTRUMENT
02-046	02	PANEL ASSEMBLY, INSTRUMENT
02-047		GAUGE, CLUSTER
02-048	01	CONTROLLER GROUP
02-048	02	CONTROLLER GROUP
02-048	03	CONTROLLER GROUP
02-048	04	CONTROLLER GROUP
02-049		BATTERY INSTAL
02-050		CONDITIONER ASSEMBLY, AIR P/N YN20M00059F1
02-051	01	CONDITIONER INSTAL
02-051	02	CONDITIONER INSTAL
02-052		CONDITIONER ASSY, AIR P/N YN20M00060F1
02-053		CONDITIONER ASSY, AIR P/N LC20M00004F1
02-054		DRYER ASSEMBLY, AIR
02-055		COMPRESSOR ASSEMBLY, AIR P/N LC91V00002F2
02-056	01	COMPRESSOR ASSEMBLY, AIR
02-056	02	COMPRESSOR ASSEMBLY, AIR
02-057		ELECTRICAL ASSY, UPPER
02-058		LIGHT INSTAL, UPP
02-059		LAMP ASSEMBLY, FLASHER
02-060	01	HARNESS ASSEMBLY, UPPER
02-060	02	HARNESS ASSEMBLY, UPPER
02-060	03	HARNESS ASSEMBLY, UPPER
02-061	01	HARNESS ASSY, CAB
02-061	02	HARNESS ASSY, CAB
02-062	01	HARNESS ASSY, UPPER (FLOOR PLATE)
02-062	02	HARNESS ASSY, UPPER (FLOOR PLATE)
02-063	01	HARNESS ASSY, ENGINE
02-063	02	HARNESS ASSY, ENGINE
02-064	01	HARNESS ASSY (IT KIT)
02-064	02	HARNESS ASSY (IT KIT)
03-001		LOW GROUP
03-002		LOW GROUP (HD)
03-003		LOW GROUP P/N YN15V00011F4
03-004		LOW GROUP (HD)
03-005		SLEWING RING ASSEMBLY
03-006		IDLER ASSY, CRAWLER P/N YN52D00023F2
03-007		IDLER ASSY, CRAWLER P/N YN52D00024F2
03-008		IDLER ASSY
03-009		IDLER ADJUST ASSY
03-010		TRACK ROLLER ASSY P/N YN64D00020F1

MidWestTech | Kobelco SK200-6ES, SK200LC-6ES Dynamic Acera Hydraulic Excavator Pa... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

03-011		TRACK ROLLER ASSY P/N YN64D00002F1
03-012		ROLLER ASSY, UPPER P/N YN64D00022F1
03-013		ROLLER ASSY, UPPER P/N YN64D00014F1
03-014		SHOE ASSY P/N YN60D00054F2
03-015		SHOE ASSY (RUBBER PAD) P/N YN60D00010F6
03-016		SHOE ASSY P/N YN60D00055F2
03-017		SHOE ASSY (RUBBER PAD) P/N YN60D00011F6
03-018		SHOE ASSY P/N YN60D00039F2
03-019		SHOE ASSY (HD)
03-020	01	HYDRAULIC LINES, LOW
03-020	02	HYDRAULIC LINES, LOW
03-021	01	HYDRAULIC LINES, LOW
03-021	02	HYDRAULIC LINES, LOW
04-001		BOOM ASSY, STD 5.65M (18FT 6 IN)
04-002		BOOM ASSY, STD (HD) 5.65M (18FT 6 IN)
04-003		BOOM ASSY (2 POSITION) 5.65M (18FT 6 IN)
04-004		BOOM ASSY (2 POSITION [HD]) 5.65M (18FT 6 IN)
04-005		HYDRAULIC LINES, BOOM 5.65M (18FT 6 IN)
04-006		HYDRAULIC LINES, BOOM 5.65M (HD) (18FT 6 IN)
04-007		LIGHT INSTAL (BOOM)
04-008		ARM ASSY, STANDARD 2.94M (9FT 8IN)
04-009		ARM ASSY, STANDARD (HD) 2.94M (9FT 8IN)
04-010		HYDRAULIC LINES, ARM 2.94M (9FT 8IN)
04-011		HYDRAULIC LINES, ARM (HD) 2.94M (9FT 8IN)
04-012		BUCKET INSTAL
04-013		BUCKET ASSY, STANDARD 0.8M³ (1.05 CU YD) 0.7M³ (0.92 CU YD)
04-014		BUCKET ASSY, STANDARD 0.8M³ (1.05 CU BUCKET ASSY, STD (HD) 0.8M³ (1.05 CU YD) 0.7M³ (0.92 CU YD)
05-001		TOOL & ACCESSORY
05-002		ELEMENT KIT
06-001		COUNTERWEIGHT ASSY (WITH SLEWING FLASHER)
06-002	01	LUBE LINES, UPPER (AUTO GREASTER)
06-002	02	LUBE LINES, UPPER (AUTO GREASTER)
06-003	01	CONTROLS, OPERATORS (LONG RANGE)
06-003	02	CONTROLS, OPERATORS (LONG RANGE)
06-004		EXTINGUISHER INSTAL
06-005		ACCESSORIES
06-006		SUN VISOR ASSY
06-007		MIRROR INSTAL
06-008	01	CAB ASSY (WITH POWER WINDOW)
06-008	02	CAB ASSY (WITH POWER WINDOW)
06-008	03	CAB ASSY (WITH POWER WINDOW)
06-009	01	CAB ASSY (HD) (WITH POWER WINDOW)
06-009	02	CAB ASSY (HD) (WITH POWER WINDOW)
06-009	03	CAB ASSY (HD) (WITH POWER WINDOW)
06-009	04	CAB ASSY (HD) (WITH POWER WINDOW)
06-010		WINDOW ASSY, FR. (WITH POWER WINDOW)
06-011		LIGHT INSTAL (CAB)
06-012	01	CONTROLLER GROUP (LONG RANGE)
06-012	02	CONTROLLER GROUP (LONG RANGE)
06-012	03	CONTROLLER GROUP (LONG RANGE)
06-012	04	CONTROLLER GROUP (LONG RANGE)
06-013	01	HARNESS ASSY, UPPER

MidWestTech | Kobelco SK200-6ES, SK200LC-6ES Dynamic Acera Hydraulic Excavator Pa... Order the manual at mid-west-tech.com >