KOBELCO®

PARTS CATALOG

SK70SR-2
Short Radius
Excavator

APPLICABLE
ASN YT06-18001

S3YT00024ZE02
Issued 3/2011

MidWestTech | Kobelco SK70SR-2 Short Radius Excavator Parts Catalog | Publication S3YT00024ZE02

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

	FIGURE	SEQ.
AIR CLEANER ASSEMBLY	01-010	00
AIR CONDITIONING	01-080	05
AIR CONDITIONING	01-080	06
AIR CONDITIONING	01-080	07
AIR CONDITIONING	01-080	03
AIR CONDITIONING	01-080	04
AIR CONDITIONING	01-080	02
AIR CONDITIONING	01-080	08
AIR CONDITIONING	01-080	01
ALARM ASSEMBLY	01-088	00
ARM CYLINDER INSTALLATION	03-015	02
ARM CYLINDER INSTALLATION	03-015	01
ARM GROUP	03-023	02
ARM GROUP	03-023	01
ARM INSTALLATION	03-022	02
ARM INSTALLATION	03-022	01
ARM, LONG 2.13M	03-024	00
BATTERY ASSEMBLY	01-079	00
BOOM CYLINDER INSTALLATION	03-011	02
BOOM CYLINDER INSTALLATION	03-011	01
BOOM GROUP	03-004	00
BOOM INSTALLATION	03-001	00
BOOM, HOE 3.84M	03-002	00
BUCKET CYLINDER INSTALLATION	03-031	02
BUCKET CYLINDER INSTALLATION	03-031	01
BUCKET INSTALLATION	03-025	00
CAB INSTALLATION	01-062	12
CAB INSTALLATION	01-062	08
CAB INSTALLATION	01-062	10
CAB INSTALLATION	01-062	11
CAB INSTALLATION	01-062	14
CAB INSTALLATION	01-062	09
CAB INSTALLATION	01-062	07
CAB INSTALLATION	01-062	06
CAB INSTALLATION	01-062	05
CAB INSTALLATION	01-062	04
CAB INSTALLATION	01-062	03
CAB INSTALLATION	01-062	02
CAB INSTALLATION	01-062	01
CAB INSTALLATION	01-062	13
CAMSHAFT AND VALVE	08-004	01
CAMSHAFT AND VALVE	08-004	02
CAP ASSEMBLY	03-005	00
CAP ASSEMBLY	02-005	00
CONNECTOR ASSEMBLY	03-006	00
CONTROL ASSEMBLY, DOZER	01-018	00
CONTROL ASSEMBLY, ENGINE	01-006	00
CONTROL LINES, BLOCK	01-042	00
CONTROL LINES, BLOCK (1 OPTION)	01-043	00
CONTROL LINES, BLOCK (SENSOR BLOCK)	01-041	00
CONTROL LINES, MAIN (DOZER)	01-026	05
CONTROL LINES, MAIN (DOZER)	01-026	03
CONTROL LINES, MAIN (DOZER)	01-026	04
CONTROL LINES, MAIN (DOZER)	01-026	02
CONTROL LINES, MAIN (DOZER)	01-026	01
CONTROL LINES, MAIN (NIBBLER & BREAKER)	01-027	05

Order the manual at mid-west-tech.com >

CONTROL LINES, MAIN (NIBBLER & BREAKER)	01-027	03
CONTROL LINES, MAIN (NIBBLER & BREAKER)	01-027	04
CONTROL LINES, MAIN (NIBBLER & BREAKER)	01-027	02
CONTROL LINES, MAIN (NIBBLER & BREAKER)	01-027	01
CONTROL LINES, MULTI	01-039	03
CONTROL LINES, MULTI	01-039	02
CONTROL LINES, MULTI	01-039	01
CONTROL LINES, PROPEL	01-038	01
CONTROL LINES, PROPEL	01-038	02
CONTROL LINES, PUMP	01-037	00
CONTROL LINES, REMOTE	01-034	03
CONTROL LINES, REMOTE	01-034	01
CONTROL LINES, REMOTE	01-034	02
CONTROL LINES, REMOTE (BLOCK)	01-033	03
CONTROL LINES, REMOTE (BLOCK)	01-033	02
CONTROL LINES, REMOTE (BLOCK)	01-033	01
CONTROL LINES, REMOTE (DOZER)	01-036	00
CONTROL LINES, REMOTE (NIBBLER & BREAKER)	01-035	02
CONTROL LINES, REMOTE (NIBBLER & BREAKER)	01-035	01
CONTROL LINES, VALVE	01-029	02
CONTROL LINES, VALVE	01-029	03
CONTROL LINES, VALVE	01-029	04
CONTROL LINES, VALVE	01-029	01
CONTROLLER INSTALLATION (ROPSCAB)	01-054	03
CONTROLLER INSTALLATION (ROPSCAB)	01-054	02
CONTROLLER INSTALLATION (ROPSCAB)	01-054	01
CONTROLS, OPERATORS	01-050	07
CONTROLS, OPERATORS	01-050	08
CONTROLS, OPERATORS	01-050	05
CONTROLS, OPERATORS	01-050	06
CONTROLS, OPERATORS	01-050	04
CONTROLS, OPERATORS	01-050	03
CONTROLS, OPERATORS	01-050	01
CONTROLS, OPERATORS	01-050	02
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	08
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	07
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	05
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	06
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	04
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	03
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	02
CONTROLS, OPERATORS (NIBBLER & BREAKER)	01-051	01
COUNTERWEIGHT INSTALLATION	01-003	00
COVER ASSEMBLY, UNDER	01-073	00
CRANKSHAFT, PISTON AND FLYWHEEL	08-011	00
CYLINDER BLOCK	08-002	02
CYLINDER BLOCK	08-002	01
CYLINDER HEAD	08-006	00
CYLINDER HEAD COVER	08-007	00
CYLINDER INSTALLATION	02-010	02
CYLINDER INSTALLATION	02-010	01
DOZER ASSEMBLY (600MM SHOE)	02-013	00
DOZER GROUP	02-017	00
DOZER INSTALLATION	02-018	00
ELECTRICAL ASSEMBLY, UPPER	01-078	00
ELECTRICAL CONTROL AND OTHER PARTS	08-018	00
ELEMENT KIT	04-002	00
EMISSION PIPING	08-012	00

Order the manual at mid-west-tech.com >

ENGINE ELECTRICAL CONTROL PARTS	08-013	02
ENGINE ELECTRICAL CONTROL PARTS	08-013	01
ENGINE GASKET KIT	08-001	00
ENGINE INSTALLATION	01-005	02
ENGINE INSTALLATION	01-005	01
EXHAUST MANIFOLD	08-010	00
FAN AND FAN BELT	08-032	00
FILTERS	00-001	00
FRAME ASSEMBLY, LOW (DOZER)	02-001	00
FRAME GROUP, UPPER	01-001	00
FRAME GROUP, UPPER	01-002	00
FUEL FILTER AND BRACKET	08-019	00
FUEL INJECTION SYSTEM	08-020	02
FUEL INJECTION SYSTEM	08-020	01
FUEL INJECTION SYSTEM	08-020	03
FUEL LINES	01-012	00
FUEL TANK INSTALLATION	01-013	00
GENERATOR	08-015	00
GUARD INSTALLATION	01-069	07
GUARD INSTALLATION	01-069	03
GUARD INSTALLATION	01-069	04
GUARD INSTALLATION	01-069	05
GUARD INSTALLATION	01-069	01
GUARD INSTALLATION	01-069	10
GUARD INSTALLATION	01-069	09
GUARD INSTALLATION	01-069	08
GUARD INSTALLATION	01-069	06
GUARD INSTALLATION	01-069	02
HARNESS ASSEMBLY, BOOM	03-003	00
HARNESS ASSEMBLY, CAB	01-087	02
HARNESS ASSEMBLY, CAB	01-087	01
HARNESS ASSEMBLY, UPPER	01-088	03
HARNESS ASSEMBLY, UPPER	01-088	02
HARNESS ASSEMBLY, UPPER	01-088	01
HARNESS ASSEMBLY, UPPER	01-083	02
HARNESS ASSEMBLY, UPPER	01-088	04
HARNESS ASSEMBLY, UPPER	01-083	06
HARNESS ASSEMBLY, UPPER	01-083	07
HARNESS ASSEMBLY, UPPER	01-083	05
HARNESS ASSEMBLY, UPPER	01-083	04
HARNESS ASSEMBLY, UPPER	01-083	03
HARNESS ASSEMBLY, UPPER	01-083	01
HARNESS ASSEMBLY, UPPER (FLOOR PLATE)	01-086	03
HARNESS ASSEMBLY, UPPER (FLOOR PLATE)	01-086	02
HARNESS ASSEMBLY, UPPER (FLOOR PLATE)	01-086	01
HYD LINES, UPP (DOZER)	01-021	04
HYDRAULIC LINES, ARM (NIBBLER & BREAKER)	03-030	00
HYDRAULIC LINES, ARM 2.13M	03-029	00
HYDRAULIC LINES, ARM CYLINDER	03-017	00
HYDRAULIC LINES, BOOM	03-007	00
HYDRAULIC LINES, BOOM (NIBBLER & BREAKER)	03-008	00
HYDRAULIC LINES, BOOM CYLINDER	03-014	00
HYDRAULIC LINES, CYLINDER	02-019	00
HYDRAULIC LINES, LOWER (DOZER)	02-012	02
HYDRAULIC LINES, LOWER (DOZER)	02-012	01
HYDRAULIC LINES, PROPEL	02-015	00
HYDRAULIC LINES, PUMP	01-020	00
HYDRAULIC LINES, RETURN	01-025	02

Order the manual at mid-west-tech.com >

CONTROLS, OPERATORS (NIBBLER & BREAKER)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{YT03M00178F1}			Operators, Nibbler & Breaker
1		{YY03M00265F1}		1	Operators
2		YN03M01859P2		2	SUPPORT
3		YN26M00072P1		1	CARPET, Floor
4		YN03M02109F1		1	COVER, Assy.
5		YN03M02159P1		1	COVER ASSY
6		YN03M02161P1		2	NUT
7		YN17M01508P1		1	BUSHING
8		YN03M02110F1		1	COVER, Assy.
9		YN03M02160P1		1	COVER ASSY
10		YN17M01508P1		2	BUSHING
11		YN03M02111F1		1	COVER, Assy.
12		YN03M02162P1		1	COVER ASSY
13		YN17M01508P1		3	BUSHING
14		YY25M01033P1		1	SEAT BACK, Seat
15		YN25M01238F1		1	CROSSRAIL
16		ZM73C10020		5	BOLT, Sems
17		ZS28C08016		4	SCREW, Cap
18		ZW26K08000		4	LOCK WASHER
19		ZW16P08000		4	WASHER
20		ZS28C08020		4	SCREW, Cap
21		YN03M02112P1	BTW YT06-18001 & YT06-18441	1	COVER
21		YN03M02163P1	ASN YT06-18442	1	COVER ASSY
22		YN03M02085P2		1	GROMMET
23		ZM73C08025		4	BOLT, Sems
24		ZM66C06016		8	BOLT, Sems
25		YY03M01308P1		1	PIPE
26		YN20M01356P1		1	DIFFUSER, Grille
27		YT03M01222P1		1	GROMMET
28		ZS28C12050		1	SCREW, Cap
29		YT02C01515D7		1	GASKET, Trim
30		ZW16K12000		1	WASHER
31		YY20M01288P1	ASN YT06-18442	2	INSULATION
32		YY20M01289P1	ASN YT06-18442	2	INSULATION

MidWestTech | Kobelco SK70SR-2 Short Radius Excavator Parts Catalog | Publication S3... Order the manual at mid-west-tech.com >

PANEL ASSEMBLY, INSTRUMENT (KIY LOGO TYPE)

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		{YT17M00074F1}		AR	Instrum, Kiy Logo Type
1		{YT17M00075F1}		1	Instrum
2		YY17M01034F1		1	COVER ASSY
3		YN17M01464P1	BTW YT06-18001 & YT06-18386	1	COVER
3		YN17M01464P2	ASN YT06-18387	1	COVER
4		YN17M01435F1		1	SUPPORT, Holder Assy.
5		YN17M01436F1		1	COVER, Assy.
6		{YN17M01493P1}		1	
7		YN17M01508P1		4	BUSHING
5		YN17M01438F1	ASN YT06-18387	1	COVER, Assy.
6		{YN17M01494P1}		1	
8		YN17M01508P1		2	BUSHING
9		YN17M01437P1		1	PLUG, Cap
10		YN17M01438F1	BTW YT06-18001 & YT06-18386	1	COVER, Assy.
11		{YN17M01494P1}		1	
12		YN17M01508P1		1	BUSHING
10		YN17M01436F1	ASN YT06-18387	1	COVER, Assy.
11		{YN17M01493P1}		1	
13		YN17M01508P1		4	BUSHING
14		YY17M01036F1		1	COVER ASSY
15		YY17M01037P1		1	BRACKET
16		YY17M01038F1		1	COVER ASSY
17		YY20M01252F1		1	AIR DUCT
18		YY20M01253F1		1	AIR DUCT
19		YY20M01254P1		1	AIR DUCT
20		YT20M01219F1		1	AIR DUCT
21		YY20M01259P1		3	CAP
22		YT20M01217F1		1	AIR DUCT
22		YT20M01217F2		1	AIR DUCT
23		ZS32T50012		2	SCREW, Cross Tapping
24		YT20M01218P1		1	AIR DUCT
25		YN17M01480P1	BTW YT06-18001 & YT06-18386	1	BRACKET

MidWestTech | Kobelco SK70SR-2 Short Radius Excavator Parts Catalog | Publication S3... Order the manual at mid-west-tech.com >

BUCKET CYLINDER INSTALLATION

REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION
		YT01V00019R300		1	REPAIR KIT, Consists Of Item: 6(1), 7(1), 8(1), 9(1), 10(1), 11(1), 13(1), 14(2)
		YT01V00032R400		1	REPAIR KIT, Consists Of Item: 1(1), 17(1)
		YT01V00032R500		1	REPAIR KIT, Consists Of Item: 2(1), 19(1), 18(2)

MidWestTech | Kobelco SK70SR-2 Short Radius Excavator Parts Catalog | Publication S3... Order the manual at mid-west-tech.com >