Drott 40YR, 40ER Cruz-Air Wheeled Excavator

Service Manual

S-406062 M3

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

GENERAL

Introduction 6
Nomenclature 4, 5
Table of Contents 1, 2
Warranty 3

MECHANICAL COMPONENTS AND CONTROLS A-E

ELECTRICAL SYSTEM

Description . . . . . 1 thru 4
Trouble Shooting 4

A

ENGINE AND THROTTLE LINKAGE

Description 1, 2
Adjustments . . . . . 2 thru 4
Master Cylinder 3
Slave Cylinder 4
Trouble Shooting Master/Slave Cylinder
Hydraulic Systems (see section "C")

B

BRAKES AND BRAKE LINKAGE

General Description 1
Bleeding 2
Master Cylinder 3, 4
Swivel 5
Power System with trouble shooting information . . . . . 5 thru 7
Mico Brake Lock with trouble shooting information 8, 9
Wheel Brakes 10
Parking Brakes 11
Trouble Shooting Master/Slave Cylinder
Hydraulic Systems . . . . . 12 thru 14

C

DRIVE CONTROLS AND DRIVE LINE

Controls, with trouble shooting information . . . . . 1 thru 3
Revers-o-matic, with test procedures 3, 4
Shift and Outrigger Control Linkage 5, 6
Drop Box 6, 7
Axle Drive Unit (differential) . . . . . 8 thru 18
Trouble Shooting Differential 18
Wheel Drive Unit (planetary) . . . . . 19 thru 28
Trouble Shooting Planetary 29
Torque Specifications for Differential and Planetary Drive Units 30, 31
Steering Linkage to Drive Wheels 32
Trouble Shooting Drive Controls 33

D

SWING MECHANISM

Description 1
Swing Brake Overhaul 1
Swing Reduction Gearbox . . . . . 2 thru 8
Replacing Turntable Bearing and Positioning Swing Pinion . . . . . 8 thru 12

E

PART NUMBER 406062M3

MidWestTech | Case Drott 40YR, 40ER Cruz-Air Wheeled Excavator Service Manual | Publ... Order the manual at mid-west-tech.com >