40 Cruz-Air
B Series Excavator

Parts Catalog

S406180M3

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

GENERAL . . . . . **1 THRU 6**
- Nomenclature 5
- Parts Section Introduction 6
- Table of Contents . . . . . 1 thru 4

CHASSIS AND ATTACHING PARTS . . . . . ***7 THRU 138**
- Axle Cradles - (See Main Frame) 8,9,9A
- Boom Support 7
- Engine Shrouding and Attaching Parts *12,13,13A
- Engine Shrouding Insulation *138
- Main Frame and Attaching Parts 8,9
- Outriggers - (Rear and Optional Front) 10,11
- Outrigger Hydraulics - (See Pages 174 thru 179)

ENGINE AND DROTT ATTACHING PARTS . . . . . **14 THRU 24**
- Cummins 6V-378 Diesel Engine:
  - Air Cleaner and Attaching Parts 18
  - Engine and Attaching Parts 14,15
  - Radiator, Oil Cooler, Shrouding and Attaching Parts 20,21
- Detroit Diesel 4-53 Engine:
  - Air Cleaner and Attaching Parts 19
  - Air Compressor Lubrication and Cooling Lines - (See page 118)
  - Engine and Attaching Parts . . . . . *16 thru 178
  - Radiator, Oil Cooler, Shrouding and Attaching Parts 22,23
  - Spark Arrestor *17C
- Hydraulic Pump Drive Shafts 24

POWER TRAIN AND ATTACHING PARTS (Less Engine) . . . . . **25 THRU 73**
- Axles:
  - Introduction *25,25A,25B
  - Front Steering . . . . . *26 thru 40A
  - Rear Driving . . . . . 41 thru 49
- Drive Shafts:
  - Revers-O-Matic Drive to Transmission 68
  - Transmission to Front Axle 69
  - Transmission to Rear Axle 70
- Revers-O-Matic Drive:
  - Control Valve 64
  - Cooling Lines 71
  - Forward and Reverse Control Linkage 67
  - Input Shaft and Clutch 62,63
  - Oil Manifold 66
  - Primary Pump 65
  - Shuttle Transmission 60,61
  - Torque Converter 58,59
  - Torque Converter Housing 57
- Fuel Tank and Lines 72,73
- Wheel and Tires 56
- 4-Speed Drop Box Transmission . . . . . 50 thru 55

*Revised October 1977

MidWestTech | Case 40B Cruz-Air Excavator Parts Catalog | Publication S406180M3 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (CON'T.)

UPPER STRUCTURE WITH: BOOMS AND UPPER CONTROLS . . . . . 74 THRU 106

Booms:
- "E" Main Boom and Dippersticks with Links and Pins 88,89
- "Y" Main Boom and "Y" Tool Boom with Pins 85
- "Y" Tool Boom Extensions with Links and Pins *86

Cab and Attaching Parts . . . . . 80 thru 84
Cab Insulation 84A,84B
Functional Controls:
- Auxiliary No. 2 Control and Linkage - (For Clam Attachment) 101
- Auxiliary No. 1 Control and Linkage - (For Wrist-O-Twist or Clam Attachment) 96,97
- Crowd 90,91
- Hoist 94,95
- Swing 98,99,100
- Tool 92,93

Swing Brake 104,105
Swing Brake Control 106
Swing Motor - (See Page 194)
Swing Reducer . . . . . 102 thru 103F
Turntable Bearing, Counterweight and Attaching Parts 74,75,75A
Turntable Bearing Lubrication Line 75B
Turntable Shrouding and Attaching Parts . . . . . 76 thru 79

CONTROLS (UPPER AND LOWER) WITH HYDRAULICS . . . . . 107 THRU 145

Accelerator:
- Hydraulics . . . . . 110 thru 111B
- Linkage and Attaching Parts on Engine for:
  - Cummins 6V-378 Diesel Engine 114
  - Detroit Diesel 4-53 Engine 112,113

Master Cylinder 116,117
Pedal and Linkage in Cab 108,109
Service Swivel 131
Slave Cylinder 115
Air Lines and Components:
- Air Compressor . . . . . 119A thru 119F
- Air Compressor Cooling and Lubrication Lines for Detroit Diesel 4-53 Engine 118,119
- Air Compressor Lines to Reservoir to Air Swivel to Cross . . . . . *120 thru 121C
- Brake Actuator 134,135
- *Brake Relay Valve 139A,139B
- Digging Brake Valve 139
- Foot Brake Air Valve 132,133
- Maxibrake Air Chamber 136,137
- Parking Brake Air Lines 126,127,127B
- Park and Emergency Air Control Valve 138
- 3-Port Air Swivel 130
- Wheel Brake Air Lines From:
  - Cross to Foot Brake Air Valve to Air Swivel 122,123,123B
  - Air Swivel to Brake Actuator to Wheel Brake Cylinders 124,125

Axle Lockout Control Linkage - (Front Axle) 107
Center Swivel Group 128,129
Forward Reverse Disconnect Linkage 143B
Outrigger Valve Control Linkage 144,145
Outrigger Control Valve - (See Page 202)
Remote Shifter Control and Attaching Parts - (1st, 2nd, Hi and Lo) 142,143,143A
Steering Reversing Valve 141
Steering Reversing Valve Control Linkage 140

*Revised October 1977

MidWestTech | Case 40B Cruz-Air Excavator Parts Catalog | Publication S406180M3 Order the manual at mid-west-tech.com >

TABLE OF CONTENTS (CON'T.)

TOOL ATTACHMENTS WITH LINKS, PINS AND HYDRAULICS . . . . . 146 THRU 155
- Auxiliary No. 1 Boom Hydraulics 154,155
- Buckets:
  - Backhoe . . . . . 146 thru 147A
  - Concrete Removal 150
  - Ditch 149
  - Front Loader 148
- Clams and Hydraulics (see pages 248 thru 263)
- Ripper Tooth 151
- Wrist-O-Twist 152
- Wrist-O-Twist Hydraulics 153
- 4-In-1 Bucket 150A, 150B
- 4-In-1 Bucket Hydraulics 150C

HYDRAULIC CIRCUITS, FITTING AND HARDWARE . . . . . 156 THRU 183
- Lower Hydraulics - (Low Pressure Tubing)
  - Reservoir to Pump and Swivel to Filter to Reservoir . . . . . 156 thru 158
  - Oil Cooler 160,161
- Lower Hydraulics - (High Pressure Tubing)
  - Pump to Swivel . . . . . 156 thru 158
- Upper Hydraulics
  - Crowd Cylinder for:
    - "E" Boom 167,167A
    - "Y" Boom 166,166A
  - Hoist Cylinder 164,165
  - Swivel to 3-Spool Control Valves and Return 159,159A
  - Swing Motor 162,163
  - Tool Cylinder for:
    - "E" Boom 170,171
    - "Y" Boom 168,169
- Outrigger Hydraulics:
  - Standard Rear Outriggers . . . . . *174 thru 175B
  - Optional Front Outriggers 178,179
  - Optional Rear Outriggers - (Use with Optional Front Outriggers) 176,177
  - Pump to Outrigger Valve and Return 172,173
- Steering Hydraulics:
  - Pump to Swivel to Steering Cylinder 180,181
  - Swivel to Steering Actuator and Return 182,183

HYDRAULIC COMPONENTS AND MOUNTING HARDWARE . . . . . 184 THRU 210
- Cylinders:
  - Crowd . . . . . 185 thru 185E
  - Hoist . . . . . 185 thru 185E
  - Outrigger 187
  - Steering . . . . . 186 thru 186B
  - Tool 188
  - Wrist-O-Twist 184
- 4-In-1 . . . . . 186C
- Hydraulic Oil Filters 190,191
- Hydraulic Oil Reservoir 196
- Main Hydraulic Pump 192,193

*Revised October 1977

MidWestTech | Case 40B Cruz-Air Excavator Parts Catalog | Publication S406180M3 Order the manual at mid-west-tech.com >