DROTT
2510 Cruz-Crane

Parts Catalog

S406183M2

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

GENERAL . . . . . 1 THRU 5
Nomenclature 5
Parts Section Introduction 4
Table of Contents 1,2,3

CHASSIS AND ATTACHING PARTS . . . . . 6 THRU 14
Carrier Platform 12
Carrier Splash Guards 13
Carrier Step Group 13
Hydraulic Pump Disconnect Control Cable - (See Item 24 on Page 6)
Hydraulic Pump Disconnect Drive Shafts for:
CUMMINS NH-230 Diesel Engine 10
*DETROIT DIESEL 6-71 Engine 11
Hydraulic Pump Disconnect 8,9
Hydraulic Pump Disconnect and Attaching Parts 6,7
Main Hydraulic Pump - (See Page 104)
Spare Tire and Attaching Parts - (Front Carrier Wheels) 14,14A*
Tool Box 12

UPPER STRUCTURE WITH: BOOMS AND UPPER CONTROLS . . . . . 15 THRU 78
Auxiliary Head and Attaching Parts 69
Boom Head Block and Attaching Parts 59,60
Boom Angle Indicator 77,78
Cab:
Cab and Attaching Parts 22,23,24
Cab Insulation 28,29
Top Cab Window and Attaching Parts 25
Upper Front Cab Window and Attaching Parts 26,27
Windshield Wiper Motor, Arm and Blade 26,27
Crowd Hydraulic Hose Take-Up 74
Functional Controls for:
Auxiliary Winch 46,47,48
Crowd . . . . . 30 thru 33
Hoist . . . . . 34 thru 37
Main Winch . . . . . 42 thru 45
Swing . . . . . 38 thru 41
Winch Freefall 49,50
Headache Balls:
3-Ton 67
5-Ton 68
Jib 40' - Sections and Attaching Parts for:
1st Section 61,62
2nd Section 63,64
3rd Section 65,66
Jib 40' - Front and Rear Supports 76
32' - 80' Main Boom and Attaching Parts for:
1st Section 51,52
2nd Section 53,54
3rd Section 55,56
Main Boom Head Sheave Arrangement 57,58
Main Boom Support 75
Turntable Bearing Lubrication Line 19

Litho in U.S.A. - 7/77 - JP 750

*Revised June 1977

MidWestTech | Case DROTT 2510 Cruz Crane Parts Catalog | Publication S406183M2 Order the manual at mid-west-tech.com >