KOBELCO

SERVICE MANUAL

HYDRAULIC EXCAVATOR

SK310 III

SK310LC III

S5LC0006E

APPLICABLE:
LC04201~
YC01301-

Issued: June, 1997

MidWestTech | Kobelco SK310 III, SK310LC III Hydraulic Excavator Service Manual | Publication S5LC0006E_gb

Order the manual at mid-west-tech.com >

Book code No. S5LC0106E

KOBELCO

SHOP MANUAL

SK310 III
SK310LC III

LC01

SPECIFICATION

TABLE OF CONTENTS

1. LOCATION OF COMPONENTS 1
2. GENERAL DIMENSIONS 2
3. SPECIFICATIONS AND PERFORMANCE 4
4. TYPE OF SHOES 5
5. TYPE AND COMBINATION OF ATTACHMENTS ... 5
6. WORKING RANGES OF ATTACHMENTS 6
7. LIFTING DIAGRAM 8
8. ENGINE SPECIFICATIONS 16

KOBE STEEL, LTD.

MidWestTech | Kobelco SK310 III, SK310LC III Hydraulic Excavator Service Manual | Pu... Order the manual at mid-west-tech.com >

WIRE NO.	WIRE COLOR	WIRE SIZE	FROM	CONNECTION	TO	FUNCTION
4	RG	AVSSO. 75sq	F-1		CN-335M	CIGARETTE LIGHTER — FUSE BOX
5	YR	AVSSO. 75sq	CN-302M		CN-335M	TACHO — FUSE BOX
6A	L	AVSSO. 75sq	CN-335M		CN-320F	FUSE BOX — STARTER RELAY
6B	L	AVSSO. 75sq	CN-315F		CN-321F	RELAY ASSY — STARTER RELAY
6C	L	AVSSO. 75sq	CN-315F		CN-322F	RELAY ASSY — STARTER RELAY
6D	L	AVSSO. 75sq	CN-315F		CN-323F	RELAY ASSY — STARTER RELAY
6E	L	AVSSO. 75sq	CN-326M		CN-324F	ALARM STOP SW — STARTER RELAY
7A	GY	AVSSO. 75sq	CN-335M		CN-317F	FUSE BOX — STARTER RELAY
7B	GY	AVSSO. 75sq	CN-342F		CN-318F	AIR CONDITIONER — STARTER RELAY
7C	GY	AVSSO. 75sq	CN-302M		CN-319F	TACHO — STARTER RELAY
8	RL	AVSSO. 75sq	CN-3F		CN-335M	CLUSTER CONTROLLER — FUSE BOX
9	RB	AVSSO. 75sq	CN-308F		CN-335M	WIPER — FUSE BOX
10A	WR	AVSS1. 25sq	CN-335M		CN-317F	FUSE BOX — STARTER RELAY
10B	WR	AVSS1. 25sq	CN-302M		CN-318F	KEY SW — STARTER RELAY
10C	WR	AVSS1. 25sq	CN-339F		CN-319F	KEY SW RELAY — STARTER RELAY
11A	G	AVSSO. 75sq	CN-335M		CN-317F	FUSE BOX — STARTER RELAY
11B	G	AVSSO. 75sq	CN-7F		CN-318F	CONTROLLER SPEC — STARTER RELAY
11C	G	AVSSO. 75sq	CN-346F		CN-319F	TBI SWICH — STARTER RELAY
12	BY	AVSSO. 75sq	CN-304M		CN-335M	FLASHER SW — FUSE BOX
13	Y	AVSSO. 75sq	CN-3F		CN-335M	CLUSTER CONTROLLER — FUSE BOX
14A	GR	AVSSO. 75sq	CN-335M		CN-320F	FUSE BOX — STARTER RELAY
14B	GR	AVSSO. 75sq	CN-306M		CN-321F	WIPERSWASHER SW — STARTER RELAY
14E	GR	AVSSO. 75sq	CN-308F		CN-322F	WIPER — STARTER RELAY
14F	GR	AVSSO. 75sq	CN-333F		CN-323F	THERMAL RELAY — STARTER RELAY
15A	LW	AVSSO. 75sq	CN-335M		CN-316F	FUSE BOX — AUTO GREASE
15B	LW	AVSSO. 75sq	CN-302M		CN-316F	LEVER LOCK S.W. — AUTO GREASE
15C	LW	AVSSO. 75sq	CN-313M		CN-316F	TWO-SPEED TRAVEL S.W. — AUTO GREASE
15D	LW	AVSSO. 75sq	CN-325F		CN-316F	TWO-SPEED TRAVEL RELAY — AUTO GREASE
15E	LW	AVSSO. 75sq	CN-325F		CN-316F	TWO-SPEED TRAVEL RELAY — AUTO GREASE
15F	LW	AVSSO. 75sq	CN-314F		CN-316F	RESISTOR — AUTO GREASE
15G	LW	AVSSO. 75sq	CN-350F		CN-316F	LEVER MODE SWITCH — AUTO GREASE
16	WY	AVSSO. 75sq	CN-304M		CN-335M	WORK LIGHT SW — FUSE BOX
17A	WL	AVSSO. 75sq	CN-339M		CN-317F	FUSE BOX — STARTER RELAY
17B	WL	AVSSO. 75sq	CN-315F		CN-318F	RELAY ASSY — STARTER RELAY
17C	WL	AVSSO. 75sq	CN-315F		CN-319F	RELAY ASSY — STARTER RELAY
18A	L	AVSS1. 25sq	CN-339M		CN-316F	FUSE BOX — AUTO GREASE
18B	L	AVSS1. 25sq	CN-342F		CN-316F	AIR CONDITIONER — AUTO GREASE
18C	L	AVSS1. 25sq	CN-346F		CN-316F	HEATER — AUTO GREASE
19	GW	AVSS1. 25sq	CN-339M		CN-347F	FUSE BOX — 24V POWER SOURCE(200V)
20	R	AVSSO. 75sq	CN-304M		CN-335M	AUTO GREASE CONTROLLER — FUSE BOX
21	R	AVS25Q	CN-310M		CN-336F	BATTERY — FUSE BOX
22	Y	AVS55Q	CN-310M		CN-336F	BATTERY — FUSE BOX
23	W	AVSS1. 25sq	CN-302M		CN-336F	KEY SW — STARTER RELAY
24A	WL	AVSSO. 75sq	CN-302M		CN-316F	KEY SW — AUTO GREASE
24B	WL	AVSSO. 75sq	CN-342F		CN-316F	AIR CONDITIONER — AUTO GREASE
24C	WL	AVSSO. 75sq	CN-7F		CN-316F	CONTROLLER SPEC — AUTO GREASE
24D	WL	AVSSO. 75sq	CN-326F		CN-316F	DIODE — AUTO GREASE
24E	WL	AVSSO. 75sq	CN-327F		CN-316F	DIODE — AUTO GREASE
24F	WL	AVSSO. 75sq	CN-326F		CN-316F	DIODE — AUTO GREASE
27A	BR	AVSSO. 75sq	CN-302M		CN-320F	KEY SW — STARTER RELAY
27B	BR	AVSSO. 75sq	CN-327F		CN-321F	DIODE — STARTER RELAY
27C	BR	AVSSO. 75sq	CN-4F		CN-322F	CLUSTER CONTROLLER — STARTER RELAY
27D	BR	AVSSO. 75sq	CN-327F		CN-323F	DIODE — STARTER RELAY
28A	P	AVSSO. 75sq	CN-302M		CN-320F	KEY SW — STARTER RELAY
28B	P	AVSSO. 75sq	CN-327F		CN-321F	DIODE — STARTER RELAY
28C	P	AVSSO. 75sq	CN-313M		CN-322F	HEATER RELAY — STARTER RELAY
29	LG	AVSSO. 75sq	CN-302M		CN-312M	KEY SW — STARTER RELAY
30A	W	AVSSO. 75sq	CN-326F		CN-331F	DIODE — AUTO ORANGE
30B	W	AVSSO. 75sq	CN-339F		CN-331F	KEY SW RELAY — AUTO ORANGE
30C	W	AVSSO. 75sq	CN-309M		CN-331F	BATTERY RELAY — AUTO ORANGE
30D	W	AVSSO. 75sq	CN-312M		CN-331F	BATTERY RELAY — AUTO ORANGE
31A	WB	AVSSO. 75sq	CN-7F		CN-331F	CONTROLLER SPEC — AUTO ORANGE
31B	WB	AVSSO. 75sq	CN-326F		CN-331F	DIODE — AUTO ORANGE
31C	WB	AVSSO. 75sq	CN-339F		CN-331F	KEY SW RELAY — AUTO ORANGE
31D	WB	AVSSO. 75sq	CN-334F		CN-331F	SAFETY RELAY — AUTO ORANGE
32A	WL	AVSSO. 75sq	CN-312M		CN-334F	STARTER RELAY — SAFETY RELAY
35	WB	AVSSO. 75sq	CN-312M		CN-334F	ALTERNATOR — SAFETY RELAY
36A	BY	AVSSO. 75sq	CN-334F		CN-320F	SAFETY RELAY — STARTER RELAY
36B	BY	AVSSO. 75sq	CN-312M		CN-321F	ALTERNATOR — STARTER RELAY
36C	BY	AVSSO. 75sq	CN-3F		CN-322F	CLUSTER CONTROLLER — STARTER RELAY
36D	BY	AVSSO. 75sq	CN-304M		CN-323F	ALTERNATOR — STARTER RELAY
51	V	AVSSO. 75sq	CN-311M		CN-6F	CONTROLLER SPEC — CONTROLLER SPEC
57A	P	AVSSO. 75sq	CN-6F		CN-317F	CONTROLLER SPEC — STARTER RELAY
57B	P	AVSSO. 75sq	CN-313M		CN-318F	PRESS SW (ARM) — STARTER RELAY
57C	P	AVSSO. 75sq	CN-303M		CN-319F	BATT. RELAY SELECT SW — STARTER RELAY
64	B	AVSSO. 75sq	CN-345F		CN-6F	CONNECTOR WITH — CONTROLLER SPEC
65	OB	AVSSO. 75sq	CN-6F		CN-346F	CONTROLLER SPEC — FOR CHECK
66A	OL	AVSSO. 75sq	CN-6F		CN-317F	CONTROLLER SPEC — STARTER RELAY
66B	OL	AVSSO. 75sq	CN-4F		CN-318F	CONTROLLER SPEC — STARTER RELAY
66C	OL	AVSSO. 75sq	CN-303M		CN-319F	BUZZER STOP TIME SET — STARTER RELAY
67	O	AVSSO. 75sq	CN-6F		CN-320F	CONTROLLER SPEC — STARTER RELAY
68A	GW	AVSSO. 75sq	CN-303M		CN-7F	BUZZER POTENTIO — CONTROLLER SPEC
69	GO	AVSSO. 75sq	CN-303M		CN-7F	HOUR METER — CONTROLLER SPEC
69A	GO	AVSSO. 75sq	CN-303M		CN-7F	HOUR METER — CONTROLLER SPEC
61	WR	AVSSO. 75sq	CN-303M		CN-7F	WASHER CONDITION RECEIVE — CONTROLLER SPEC
64	LR	AVSSO. 75sq	CN-6F		CN-328F	CONTROLLER SPEC — DIODE
65A	GrR	AVSSO. 75sq	CN-328F		CN-317F	DIODE — STARTER RELAY
65B	GrR	AVSSO. 75sq	CN-201F		CN-318F	RELEASE SW — STARTER RELAY
65C	GrR	AVSSO. 75sq	CN-303M		CN-319F	POWER BOOST SW — STARTER RELAY
66A	BO	AVSSO. 75sq	CN-6F		CN-317F	CONTROLLER SPEC — STARTER RELAY
66B	BO	AVSSO. 75sq	CN-328F		CN-318F	DIODE — STARTER RELAY
66C	BO	AVSSO. 75sq	CN-303M		CN-319F	MODE SELECT SW — STARTER RELAY
67	LO	AVSSO. 75sq	CN-6F		CN-329F	CONTROLLER SPEC — DIODE
68	Y	AVSSO. 75sq	CN-303M		CN-329F	MODE SELECT SW — DIODE
69A	LB	AVSSO. 75sq	CN-6F		CN-317F	CONTROLLER SPEC — STARTER RELAY
69B	LB	AVSSO. 75sq	CN-312M		CN-318F	PRESS SW — STARTER RELAY
69C	LB	AVSSO. 75sq	CN-1F		CN-319F	FLASHER UNIT — STARTER RELAY
69A	YG	AVSSO. 75sq	CN-6F		CN-331F	CONTROLLER SPEC — AUTO ORANGE
69B	YG	AVSSO. 75sq	CN-340F		CN-331F	FOR CHECK — AUTO ORANGE
69C	YG	AVSSO. 75sq	CN-4F		CN-331F	CLUSTER CONTROLLER — AUTO ORANGE
86	PL	AVSSO. 75sq	CN-3F		CN-7F	CLUSTER CONTROLLER — CONTROLLER SPEC
87	PG	AVSSO. 75sq	CN-3F		CN-7F	CLUSTER CONTROLLER — CONTROLLER SPEC
88	YB	AVSSO. 75sq	CN-201F		CN-7F	RELEASE SW — CONTROLLER SPEC
89	YL	AVSSO. 75sq	CN-201F		CN-7F	RELEASE SW — CONTROLLER SPEC
90	GB	AVSSO. 75sq	CN-301M		CN-201F	PROPORTIONAL VALVE (ARM2) — RELEASE SW
91	YR	AVSSO. 75sq	CN-301M		CN-201F	PROPORTIONAL VALVE (BUCKET) — RELEASE SW
92	WB	AVSSO. 75sq	CN-201F		CN-314F	RELEASE SW — RESISTOR
93	SY	AVSSO. 75sq	CN-301M		CN-7F	S.VISCOUS VALVE (SWING) — CONTROLLER SPEC
94	SP	AVSSO. 75sq	CN-301M		CN-7F	S.VISCOUS VALVE (BOOM) — CONTROLLER SPEC
101	PB	AVSSO. 75sq	CN-303M		CN-4F	WASHER STOP TIME SET — CONTROLLER SPEC
102A	GB	AVSSO. 75sq	CN-3F		CN-320F	CLUSTER CONTROLLER — STARTER RELAY
102B	GB	AVSSO. 75sq	CN-328F		CN-321F	DIODE — STARTER RELAY
102C	GB	AVSSO. 75sq	CN-312M		CN-322F	FUEL SEL FILTER — STARTER RELAY
103	YG	AVSSO. 75sq	CN-312M		CN-3F	FUEL SEL FILTER — CLUSTER CONTROLLER
104	RG	AVSSO. 75sq	CN-312M		CN-3F	AIR FILTER RESTRICTION — CLUSTER CONTROLLER
105	YB	AVSSO. 75sq	CN-312M		CN-3F	WATER TEMP SW — CLUSTER CONTROLLER
106	YL	AVSSO. 75sq	CN-312M		CN-3F	COOLING LEVEL — CLUSTER CONTROLLER
107	YV	AVSSO. 75sq	CN-312M		CN-3F	L/G OIL LEVEL — CLUSTER CONTROLLER
108	GY	AVSSO. 75sq	CN-301M		CN-3F	ENG OIL LEVEL — CLUSTER CONTROLLER
109	YR	AVSSO. 75sq	CN-312M		CN-4F	THERMO SENSOR — CLUSTER CONTROLLER
110	YW	AVSO. 85sq	CN-309M		CN-4F	FUEL LEVEL — CLUSTER CONTROLLER
111	YO	AVSO. 85sq	CN-309M		CN-4F	FUEL SWITCH — CLUSTER CONTROLLER
113A	RW	AVSSO. 75sq	CN-3F		CN-331F	CLUSTER CONTROLLER — AUTO ORANGE
113B	RW	AVSSO. 75sq	CN-313M		CN-331F	TWO SPEED TRAVEL S.W. — AUTO ORANGE
113C	RW	AVSSO. 75sq	CN-325F		CN-331F	TWO-SPEED TRAVEL RELAY — AUTO ORANGE
114	BrW	AVSSO. 75sq	CN-338F		CN-3F	ENGINE OIL PRESSURE SW RELAY — CLUSTER CONTROLLER
115A	GrL	AVSSO. 75sq	CN-4F		CN-331F	CLUSTER CONTROLLER — AUTO ORANGE
115B	GrL	AVSSO. 75sq	CN-315F		CN-331F	RELAY ASSY — AUTO ORANGE
115C	GrL	AVSSO. 75sq	CN-313M		CN-331F	POWER BOOST S.W. — AUTO ORANGE
116A	RY	AVSSO. 75sq	CN-4F		CN-320F	CLUSTER CONTROLLER — STARTER RELAY
116B	RY	AVSSO. 75sq	CN-315F		CN-321F	RELAY ASSY — STARTER RELAY
116C	RY	AVSSO. 75sq	CN-309M		CN-322F	DIODE B — STARTER RELAY
117A	V	AVSSO. 75sq	CN-4F		CN-320F	CLUSTER CONTROLLER — STARTER RELAY
117B	V	AVSSO. 75sq	CN-313M		CN-321F	PRESS SW (BRAKE) — STARTER RELAY
117C	V	AVSSO. 75sq	CN-325F		CN-322F	DIODE — STARTER RELAY
117D	V	AVSSO. 75sq	CN-303M		CN-323F	MODE SELECT SW — STARTER RELAY
118	VW	AVSSO. 75sq	CN-304M		CN-340F	AUTO GREASE CONTROLLER — OUTPUT MONITOR UNIT
120	VG	AVSSO. 75sq	CN-340F		CN-3F	OUTPUT MONITOR UNIT — CLUSTER CONTROLLER
121	WL	AVSSO. 75sq	CN-201F		CN-315F	RELEASE SW — RELAY ASSY
122A	LGR	AVSSO. 75sq	CN-304M		CN-331F	FLASHER SW — AUTO ORANGE
122B	LGR	AVSSO. 75sq	CN-331F		CN-1F	AUTO ORANGE — FLASHER UNIT
122C	LGR	AVSSO. 75sq	CN-338F		CN-331F	STOP SW RELAY — AUTO ORANGE
123A	BrY	AVSSO. 75sq	CN-1F		CN-320F	FLASHER UNIT — STARTER RELAY
123B	BrY	AVSSO. 75sq	CN-309M		CN-321F	FLASHER UNIT — STARTER RELAY
123C	BrY	AVSSO. 75sq	CN-312M		CN-322F	FLASHER UNIT — STARTER RELAY
124A	BrR	AVSSO. 75sq	CN-1F		CN-320F	FLASHER UNIT — STARTER RELAY
124B	BrR	AVSSO. 75sq	CN-309M		CN-321F	FLASHER UNIT — STARTER RELAY
124C	BrR	AVSSO. 75sq	CN-312M		CN-322F	FLASHER UNIT — STARTER RELAY
125A	RB	AVSSO. 75sq	CN-304M		CN-320F	WORK LIGHT SW — STARTER RELAY
125B	RG	AVSSO. 75sq	CN-315F		CN-321F	RELAY ASSY — STARTER RELAY
125C	RG	AVSSO. 75sq	CN-315F		CN-322F	RELAY ASSY — STARTER RELAY
126A	RB	AVSSO. 75sq	CN-315F		CN-320F	RELAY ASSY — STARTER RELAY
126B	PB	AVSSO. 75sq	CN-308M		CN-321F	WORK LIGHT (L) — STARTER RELAY
126C	PB	AVSSO. 75sq	CN-312M		CN-322F	WORK LIGHT (R) — STARTER RELAY
126D	PB	AVSSO. 75sq	CN-342F		CN-323F	AIR CONDITIONER — STARTER RELAY
127A	LY	AVSSO. 75sq	CN-308M		CN-315F	WORK W — RELAY ASSY
128	BrR	AVSSO. 75sq	CN-306M		CN-333F	WIPERSWASHER SW — INTERMIT RELAY
129	Br	AVSSO. 75sq	CN-306M		CN-333F	WIPERSWASHER SW — INTERMIT RELAY
130	BrW	AVSSO. 75sq	CN-308F		CN-333F	WIPER — INTERMIT RELAY
131	BrB	AVSSO. 75sq	CN-308F		CN-333F	WIPER — INTERMIT RELAY
132	O	AVSSO. 75sq	CN-313M		CN-325F	TWO SPEED TRAVEL SW — TWO-SPEED TRAVEL RELAY
134	BG	AVSSO. 75sq	CN-309M		CN-337F	TRAVEL ALARM — TRAVEL ALARM RELAY
135	LR	AVSSO. 75sq	CN-313M		CN-337F	TRAVEL SW (TRAVEL) — TRAVEL ALARM RELAY
151B	G	AVSSO. 75sq	CN-302M		CN-313M	LEVER LOCK S.W. — LEVER LOCK S.W.
152B	LG	AVSSO. 75sq	CN-303M		CN-313M	MODE RELAY — MODE S.W.
153A	RW	AVSSO. 75sq	CN-304M		CN-320F	WORK LIGHT SW — STARTER RELAY
153B	RW	AVSSO. 75sq	CN-309M		CN-321F	RELAY WORK LIGHT(L) — STARTER RELAY
153C	RW	AVSSO. 75sq	CN-312M		CN-322F	RELAY WORK LIGHT(R) — STARTER RELAY
154	LGB	AVSSO. 75sq	CN-309M		CN-313M	WIPERSWASHER SW — WASHER MOTOR
155	PL	AVSSO. 75sq	CN-312M		CN-342F	PRESS SW — AIR CONDITIONER
157	LY	AVSS1. 25sq	CN-302M		CN-346F	HEATER SW — HEATER
158	LB	AVSS1. 25sq	CN-302M		CN-346F	HEATER SW — HEATER
159	GrG	AVSSO. 75sq	CN-302M		CN-332F	TUNER — SPEAKER
160	YG	AVSSO. 75sq	CN-302M		CN-346F	TUNER — SPEAKER
161	YR	AVSSO. 75sq	CN-304M		CN-309M	AUTO GREASE CONTROLLER — GREASE MOTOR
162	VY	AVSSO. 75sq	CN-304M		CN-309M	AUTO GREASE CONTROLLER — GREASE MOTOR
163	Gr	AVSSO. 75sq	CN-304M		CN-309M	AUTO GREASE CONTROLLER — GREASE MOTOR
164	GrB	AVSSO. 75sq	CN-304M		CN-309M	AUTO GREASE CONTROLLER — GREASE MOTOR
165	PG	AVSSO. 75sq	CN-303M		CN-315F	HORN SW — RELAY ASSY
201	BY	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
202	B	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
203	R	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
204	BG	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
205	O	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
206	BL	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
207	Y	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
208	G	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
209	L	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
210	LR	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
211	V	AVSO. 5sq	CN-306M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
212	VW	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
213	BW	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
214	BR	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
215	GR	AVSO. 5sq	CN-305M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
216	W	AVSO. 5sq	CN-303M		CN-5F	CLUSTER GAUGE — CLUSTER CONTROLLER
231	LW	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
232	WR	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
233	BrW	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
234	GW	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
235	RG	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
236	RB	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
237	B	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
238	RL	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
239	LB	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
240	YR	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
241	GR	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
242	YL	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
243	WG	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
244	YG	AVSSO. 75sq	CN-307F		CN-343M	CONTROL PANEL — AIR CONDITIONER
E1	B	AVSS1. 25sq	CN-303M		CN-341F	SPEC PANEL — SPEC PANEL
E2	B	AVSSO. 75sq	CN-315F		CN-330F	RELAY ASSY — AUTO GRAY
E3	B	AVSS1. 25sq	CN-341F		CN-330F	SPEC PANEL — AUTO GRAY
E4	B	AVSS1. 25sq	CN-341F		CN-330F	SPEC PANEL — AUTO GRAY
E5	B	AVSSSQ	CN-310M		F-1	FUSE B — BODY EARTH
E6	B	AVSSO. 75sq	CN-330F		CN-330F	AUTO GRAY — AUTO GRAY
E7	B	AVSSO. 75sq	CN-3F		CN-330F	CLUSTER CONTROLLER — AUTO GRAY
E8	B	AVSSO. 75sq	CN-341F		CN-7F	SPEC PANEL — CONTROLLER SPEC
E9	B	AVSSO. 75sq	CN-341F		CN-3F	SPEC PANEL — CLUSTER CONTROLLER
E10	B	AVSSO. 75sq	CN-341F		CN-334F	SPEC PANEL — SAFETY RELAY
E11	B	AVSSO. 75sq	CN-341F		CN-325F	SPEC PANEL — TWO-SPEED TRAVEL RELAY
E12	B	AVSS1. 25sq	CN-341F		CN-342F	SPEC PANEL — AIR CONDITIONER
E13	B	AVSSO. 75sq	CN-341F		CN-201F	SPEC PANEL — RELEASE SW
E14	B	AVSSO. 75sq	CN-341F		CN-339F	SPEC PANEL — KEY SW RELAY
E15	B	AVSSO. 75sq	CN-303M		CN-341F	SPEC PANEL — SPEC PANEL
E16	B	AVSSO. 75sq	CN-340F		CN-330F	OUTPUT MONITOR UNIT — AUTO GRAY
E17	B	AVSSO. 75sq	CN-1F		CN-330F	BUZZER — AUTO GRAY
E18	B	AVSSO. 75sq	CN-333F		CN-330F	INTERMIT RELAY — AUTO GRAY
E19	B	AVSSO. 75sq	CN-348F		CN-330F	FOR CHECK — AUTO GRAY
E20	B	AVSSO. 75sq	CN-315F		CN-330F	RELAY ASSY — AUTO GRAY
E21	B	AVSS1. 25sq	CN-347F		CN-330F	24V POWER SOURCE(200V) — AUTO GRAY
E22	B	AVSSO. 75sq	F-2		CN-330F	CIGARET LIGHTER — AUTO GRAY
E24	B	AVSSO. 75sq	CN-348F		CN-330F	SPEAKER — AUTO GRAY
E25	B	AVSSO. 75sq	CN-332F		CN-330F	SPEAKER — AUTO GRAY
E26	B	AVSSO. 75sq	CN-344M		CN-330F	CIGARET LIGHTER — AUTO GRAY
E27	B	AVSSO. 75sq	CN-308F		CN-330F	WIPER — AUTO GRAY
E28	B	AVSSO. 75sq	CN-338F		CN-330F	SPEC PANEL — AUTO GRAY
E29	B	AVSSO. 75sq	CN-338F		CN-330F	SPEC PANEL — AUTO GRAY
81	G	MVVSO. 75sq	CN-311M		CN-7F	REVOLUTION SENSOR — CONTROLLER SPEC
82	B		CN-311M		CN-7F	REVOLUTION SENSOR — CONTROLLER SPEC
83	P		CN-311M		CN-7F	REVOLUTION SENSOR — CONTROLLER SPEC
84	W		CN-311M		CN-7F	REVOLUTION SENSOR — CONTROLLER SPEC
SH1	Sr		CN-311M		CN-330F	REVOLUTION SENSOR — AUTO GRAY
82	P		CN-311M		CN-8F	REVOLUTION SENSOR — CONTROLLER SPEC
83	W	MVVSO. 75sq	CN-311M		CN-8F	REVOLUTION SENSOR — CONTROLLER SPEC
SH2	Sr		CN-311M		CN-8F	REVOLUTION SENSOR — CONTROLLER SPEC

MidWestTech | Kobelco SK310 III, SK310LC III Hydraulic Excavator Service Manual | Publication S5LC0006E_gb

Order the manual at mid-west-tech.com >