Operation & Maintenance Manual

SEAM000604

[redacted]

PC650,650LC-5
PC650SE-5
PC710,PC710SE-5

HYDRAULIC EXCAVATOR

SERIAL NUMBERS
PC650-20164
PC650LC-20164
PC650SE-20164 and up
PC710-10119
PC710SE-10119

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu PC650-5, PC650LC-5, PC650SE-5, PC710-5, PC710SE-5 Hydrauli... Order the manual at mid-west-tech.com >

5. CONTENTS

1. **Foreword** 0- 1

2. **Safety information** 0- 2

3. **Introduction** 0- 3

4. **Location of plates, table to enter serial No. and distributor** 0- 4

SAFETY

6. **General precautions** 1- 2

7. **Precautions during operation** 1- 8
   - 7.1 Before starting engine 1- 8
   - 7.2 Operating machine 1-10
   - 7.3 Transportation 1-15
   - 7.4 Battery 1-16
   - 7.5 Bucket with hook 1-17

8. **Precautions for maintenance** 1-20
   - 8.1 Before carrying out maintenance 1-20
   - 8.2 During maintenance 1-23

9. **Position for attaching safety labels** 1-27

OPERATION

10. **General view** 2- 2
    - 10.1 General view of machine 2- 2
    - 10.2 General view of controls and gauges 2- 3

11. **Explanation of components** 2- 4
    - 11.1 Machine monitor 2- 4
    - 11.2 Lamp 2-14
    - 11.3 Switches 2-15
    - 11.4 Control levers, pedals 2-19
    - 11.5 Ceiling window 2-22
    - 11.6 Front window 2-23
    - 11.7 Door lock 2-25
    - 11.8 Emergency engine stop lever 2-25
    - 11.9 Dust indicator 2-26
    - 11.10 Airconditioner 2-27
    - 11.11 Radio 2-32
    - 11.12 Fuse 2-36
    - 11.13 Controllers 2-37
    - 11.14 Tool box 2-37
    - 11.15 Grease pump 2-37
    - 11.16 Handling grease pump 2-38
    - 11.17 Handling accumulator 2-40

MidWestTech | Komatsu PC650-5, PC650LC-5, PC650SE-5, PC710-5, PC710SE-5 Hy... Order the manual at mid-west-tech.com >

12. Operation 2-42
12.1 Check before starting engine 2-42
12.2 Starting engine 2-51
12.3 Operations and checks after starting engine 2-54
12.4 Moving machine off 2-56
12.5 Steering machine 2-60
12.6 Stopping machine 2-62
12.7 Swinging 2-63
12.8 Operation of work equipment 2-64
12.9 Working mode selection 2-65
12.10 Prohibitions for operation 2-66
12.11 Precautions for operation 2-68
12.12 Precautions when traveling up or down hills 2-69
12.13 How to escape from mud 2-71
12.14 Work possible using hydraulic excavator 2-72
12.15 Replacement of bucket 2-73
12.16 Parking machine 2-74
12.17 Check after finishing work 2-75
12.18 Stopping engine 2-76
12.19 Check after stopping engine 2-77
12.20 Locking 2-77

13. Transportation 2-78
13.1 Loading, unloading work 2-78
13.2 Precautions for loading 2-80
13.3 Precaution for transportation 2-81
13.4 Parts for transport 2-82
13.5 Procedure for increasing or reducing track frame gauge 2-88

14. Cold weather operation 2-90
14.1 Precautions for low temperature 2-90
14.2 Precautions after completion of work 2-92
14.3 After cold weather 2-92

15. Long-term storage 2-93
15.1 Before storage 2-93
15.2 During storage 2-94
15.3 After storage 2-94
15.4 Starting machine after long-term storage 2-94

16. Troubleshooting 2-95
16.1 Phenomena that are not failures 2-95
16.2 Precautions on particular jobsites 2-95
16.3 If battery is discharged 2-96
16.4 Other trouble 2-100

MidWestTech | Komatsu PC650-5, PC650LC-5, PC650SE-5, PC710-5, PC710SE-5 Hy... Order the manual at mid-west-tech.com >

MAINTENANCE

17. Guides to maintenance 3- 2

18. Outlines of service 3- 6
18.1 Outline of oil, fuel, coolant 3- 6
18.2 Outline of electrical system 3- 9
18.3 Outline of hydraulic system 3-10
18.4 Releasing pressure 3-11
18.5 Bleeding air from circuit 3-12
18.6 Oil filter and level gauge positions 3-13

19. Consumable parts list 3-14

20. Use of fuel, coolant and lubricants according to ambient temperature 3-15

21. Standard tightening torques for bolts and nuts 3-19
21.1 Introduction of necessary tools 3-19
21.2 Torque list 3-20

22. Periodic replacement of critical safety parts 3-21

23. Maintenance schedule chart 3-23
23.1 Maintenance schedule chart 3-23

24. Service Procedure 3-27
24.1 Initial 100 hours service 3-27
24.2 Initial 250 hours service 3-27
24.3 When required 3-28
24.4 Check before starting 3-49
24.5 Every 10 hours service 3-54
24.6 Every 100 hours service 3-56
24.7 Every 250 hours service 3-57
24.8 Every 500 hours service 3-64
24.9 Every 1000 hours service 3-67
24.10 Every 2000 hours service 3-71
24.11 Every 4000 hours service 3-76

SPECIFICATIONS

25. Specifications 4- 2

OPTIONS, ATTACHMENTS

26. General precautions 5- 2
26.1 Precautions related to safety 5- 2
26.2 Precautions when installing attachments 5- 3

27. Handling bucket with hook 5- 4
27.1 Checking for damage to bucket with hook 5- 4
27.2 Prohibited operations 5- 4
27.3 Precautions during operations 5- 4

MidWestTech | Komatsu PC650-5, PC650LC-5, PC650SE-5, PC710-5, PC710SE-5 Hy... Order the manual at mid-west-tech.com >