Operation & Maintenance Manual

SEAM000803

[redacted]

HD325-6

DUMP TRUCK

SERIAL NUMBERS HD325-5292 and up

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu HD325-6 Dump Truck Operation & Maintenance Manual | Publicat... Order the manual at mid-west-tech.com >

5. CONTENTS

1. **Foreword** 0- 1

2. **Safety information** 0- 2

3. **Introduction** 0- 3
   - 3.1 Features 0- 3
   - 3.2 Braking in the machine 0- 3

4. **Location of plates, table to enter serial number and distributor** 0- 4
   - 4.1 Machine serial No. plate position 0- 4
   - 4.2 Engine serial No. plate position 0- 4
   - 4.3 Table to enter serial No. and distributor 0- 4

SAFETY

6. **General precautions** 1- 2

7. **Precautions during operation** 1- 7
   - 7.1 Before starting engine 1- 7
   - 7.2 Operating machine 1- 9
   - 7.3 Battery 1-13
   - 7.4 Towing 1-14

8. **Precautions for maintenance** 1-15
   - 8.1 Before carrying out maintenance 1-15
   - 8.2 During maintenance 1-17
   - 8.3 Tires 1-21

9. **Position for sticking safety labels** 1-23
   - 9.1 Position for attaching safety labels 1-23

OPERATION

10. **General view** 2- 2
    - 10.1 General view of machine 2- 2
    - 10.2 General view of controls and gauges 2- 3

11. **Explanation of components** 2- 4
    - 11.1 Machine monitor 2- 4
    - 11.2 Switches 2-23
    - 11.3 Control levers and pedals 2-30
    - 11.4 Mechatronics equipment controller 2-34
    - 11.5 Safety pin 2-34
    - 11.6 Fuses 2-35
    - 11.7 Car radio 2-37
    - 11.8 Car stereo 2-41
    - 11.9 Air conditioner 2-44

MidWestTech | Komatsu HD325-6 Dump Truck Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >

12. Operation 2- 47
12.1 Check before starting engine 2- 47
12.2 Starting engine 2- 64
12.3 Operations and checks after starting engine 2- 66
12.4 Moving machine off 2- 67
12.5 Shifting gear 2- 69
12.6 Traveling downhill 2- 70
12.7 Traveling in reverse 2- 76
12.8 Steering the machine 2- 77
12.9 Stopping the machine 2- 78
12.10 Operating dump body 2- 80
12.11 Precautions for operation 2- 82
12.12 Parking machine 2- 83
12.13 Checks after completion of work 2- 84
12.14 Stopping engine 2- 84
12.15 Checks after stopping engine 2- 84
12.16 Locking 2- 85
12.17 Handling tires 2- 86

13. Determining and maintaining travel road 2- 89
13.1 Determining travel road 2- 89
13.2 Maintaining travel road 2- 90

14. Cold weather operation 2- 91
14.1 Precautions for low temperature 2- 91
14.2 Cautions after completion of work 2- 93
14.3 After cold weather 2- 93

15. Long-term storage 2- 94
15.1 Before storage 2- 94
15.2 During storage 2- 94
15.3 After storage 2- 95
15.4 Precautions before traveling after long-term storage 2- 95

16. Troubleshooting 2- 96
16.1 After running out of fuel 2- 96
16.2 Towing machine 2- 96
16.3 If battery is discharged 2-100
16.4 Other trouble 2-104

MidWestTech | Komatsu HD325-6 Dump Truck Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >

MAINTENANCE

17. Guides to maintenance 3- 2

18. Outline of service 3- 5
18.1 Outline of oil, fuel, coolant 3- 5
18.2 Outline of electric system 3- 8

19. Wear parts list 3- 9

20. Use of fuel, coolant, and lubricant according to ambient temperature 3-10

21. Standard tightening torques for bolts and nuts 3-14
21.1 Introduction of necessary tools 3-14
21.2 Torque list 3-15

22. Periodic replacement of safety critical parts 3-16

23. Maintenance schedule chart 3-18

24. Service procedure 3-23
24.1 Initial 250 hours service 3-23
24.2 When required 3-24
24.3 Check before starting 3-36
24.4 Every 50 hours service 3-46
24.5 Every 250 hours service 3-48
24.6 Every 500 hours service 3-56
24.7 Every 1000 hours service 3-63
24.8 Every 2000 hours service 3-69
24.9 Every 4000 hours service 3-73
24.10 Every 3 years service 3-73

SPECIFICATIONS

25. Specifications 4- 2

OPTIONS, ATTACHMENTS

26. Handling payload meter 5- 2
26.1 Name of parts 5- 2
26.2 External display lamps 5- 2
26.3 Operating payload meter 5- 4

27. Selecting dump body 5-13

28. Options and attachments 5-14

MidWestTech | Komatsu HD325-6 Dump Truck Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >