Operation & Maintenance Manual

SEAM000904

[redacted]

D20A,PL,PLL-7
D20P-7A
D21A-7
D21P-7A
BULLDOZER

SERIAL NUMBERS
D20A-7-78604
D20PL,PLL-7-62454
D20P-7A-78604 and up
D21A-7-78604
D21P-7A-78604

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu D20A-7, D20PL-7, D20PLL-7, D20P-7A, D21A-7, D21P-7A Bulldoz... Order the manual at mid-west-tech.com >

5. CONTENTS

1. **Foreword** 0-1

2. **Safety information** 0-2

3. **Introduction** 0-3

4. **Location of plates, table to enter serial No. and distributor** 0-4

SAFETY

6. **General precautions** 1-2

7. **Precautions during operation** 1-7
   - 7.1. Before starting engine 1-7
   - 7.2. Operating machine 1-9
   - 7.3. Transportation 1-12
   - 7.4. Battery 1-13
   - 7.5. Towing 1-15

8. **Precautions for maintenance** 1-16
   - 8.1 Before carrying out maintenance 1-16
   - 8.2 During maintenance 1-18

9. **Position for sticking safety labels** 1-23

OPERATION

10. **General view** 2-2
    - 10.1. General view of machine 2-2
    - 10.2. General view of controls and gauges 2-3

11. **Explanation of components** 2-5
    - 11.1. Meters and lamps 2-5
    - 11.2. Switches 2-8
    - 11.3. Control levers and pedals 2-10
    - 11.4. Fuse box 2-16

12. **Operation** 2-17
    - 12.1. Check before starting engine 2-17

[Only those using D20A, PL, PLL-7, D20P-7A need read this section in 12A. Operation.]

12A. Operation 2-26
- 12A.1.4 Operations and checks before starting engine 2-27
- 12A.2. Starting engine 2-29
- 12A.3. Operations and checks after starting engine 2-33
- 12A.4. Moving machine off 2-34
- 12A.5. Steering machine 2-36
- 12A.6. Stopping machine 2-38
- 12A.7. Shifting gear, shifting between forward and reverse 2-39
- 12A.8. Precautions for operation 2-41
- 12A.9. Work possible using bulldozer 2-42
- 12A.10. Parking machine 2-43
- 12A.11. Check after finishing work 2-44
- 12A.12. Stopping engine 2-45
- 12A.13. Check after stopping engine 2-45
- 12A.14. Locking 2-46

MidWestTech | Komatsu D20A-7, D20PL-7, D20PLL-7, D20P-7A, D21A-7, D21P-7A Bu... Order the manual at mid-west-tech.com >

[Only those using D21A-7, D21P-7A need read this section in 12B. Operation.]
12B. Operation 2-47
12B.1.4 Operations and checks before starting engine 2-48
12B.2. Starting engine 2-50
12B.3. Operations and checks after starting engine 2-53
12B.4. Moving machine off 2-54
12B.5. Shifting gear 2-55
12B.6. Shifting between forward and reverse 2-56
12B.7. Steering machine 2-57
12B.8. Stopping machine 2-59
12B.9. Precautions for operation 2-60
12B.10. Work possible using bulldozer 2-61
12B.11. Parking machine 2-62
12B.12. Check after finishing work 2-63
12B.13. Stopping engine 2-64
12B.14. Check after stopping engine 2-64
12B.15. Locking 2-65
[Only those using the machines given in ( ) need read the following items.]
12.16. Tips for longer undercarriage life (D20PL, PLL-7, D20P-7A, D21A-7) 2-66
12.17. Handling rubber shoes (D20A-7, D20P-7A, D21A-7, D21P-7A) 2-69

13. Transportation 2-75
13.1. Loading, unloading work 2-75
13.2. Precautions for loading 2-76
13.3. Lifting machine 2-77
13.4. Precautions for transportation 2-80

14. Cold weather operation 2-81
14.1. Precautions for low temperature 2-81
14.2. Precautions after completion of work 2-83
14.3. After cold weather 2-83

15. Long-term storage 2-84
15.1. Before storage 2-84
15.2. During storage 2-84
15.3. After storage 2-85

16. Troubleshooting 2-86
16.1. After running out of fuel 2-86
16.2. If battery is discharged 2-87
16.3. Other trouble 2-91

MidWestTech | Komatsu D20A-7, D20PL-7, D20PLL-7, D20P-7A, D21A-7, D21P-7A Bu... Order the manual at mid-west-tech.com >

MAINTENANCE

17. Guides to maintenance 3-2

18. Outlines of service 3-5
18.1. Outline of oil, fuel, coolant 3-5
18.2. Relating to electric system 3-8

19. Wear parts list 3-9

20. Use of fuel, coolant and lubricants according to ambient temperature 3-10

21. Standard tightening torques for bolts and nuts 3-14
21.1. Introduction of necessary tools 3-14
21.2. Torque list 3-15

22. Periodic replacement of safety critical parts 3-16

23. Maintenance schedule chart 3-18

24. Service procedure 3-21
24.1. Initial 250 hours service 3-21
24.2. When required 3-22
24.3. Check before starting 3-44
24.4. Every 50 hours service 3-50
24.5. Every 250 hours service 3-51
24.6. Every 500 hours service 3-56
24.7. Every 1000 hours service 3-61
24.8. Every 2000 hours service 3-69
24.9. Every 4000 hours service 3-70

SPECIFICATIONS

25. Specifications 4-2

OPTIONS, ATTACHMENTS

26. General precautions 5-2
26.1. Precautions related to safety 5-2

27. Using seat belt 5-3
27.1. Seat belt (for fixed type) 5-3
27.2. Seat belt (for suspension type) 5-5

28. Handling suspension seat 5-7

MidWestTech | Komatsu D20A-7, D20PL-7, D20PLL-7, D20P-7A, D21A-7, D21P-7A Bu... Order the manual at mid-west-tech.com >